ETL Inc.
#584 Sangwhal-ri,
Kanam-myon, Yoju-kun,
Kyonggi-do, 469-880, Korea

KORI TECH Co., Ltd.
USB READER/WRITER
MODEL : KT-RWA03

1 of **1**

SD

USB READER/WRITER
- DD1 -

Features of this products

- Compatible with MMC and SD cards
- Transfer content to and from your computer using a USB port
- Includes exclusive PC driver software
- Buss Power Supply (No AC adapter necessary)
- Red LED indicates access
- Write protect switch prevents accidental erasures (SD Memory Card only)
- Windows 98/ME/2000/XP, Mac OS 8.1 onwards applicable

Requirements for Users

- In order to use the products, you require to have the below software and hardware environment.

- IBM-PC Compatible Device or Management System Devices attached to USB port.
- Microsoft Windows98/ME/2000/XP
- Over Mac OS 8.1.

Contents of the Products

< DDI Mainboard >   < USB Connecting >   < CD >   < Manual >

Names of each parts and their functions

SD/MMC
Card Inserting Slots

USB Connecting Terminal

LED Indicating

Method of Hard-ware Installation

Method of Driver Installation

- The way to install Driver in Windows 2000/XP

  - Windows can read Removable Disk automatically without using additional Driver if you connect USB Cable with PC.

- The way to install Driver in Windows 98/ME

  1. Connect USB Cable with PC. (See Method of Hard-ware Installation for more information.)

  2. When you can see a new Hard-ware wizard Window on the new screen, insert provided CD into CD-ROM Drive.

  3. When a new hardware wizard appears, choose "install the software automatically(recommended)", then press the button "Next".

  4. When the below windows appear, select "CD-ROM Drive" only, then press the button "Next".

  5. When you find the driver, push the button "Next" to make installation proceed.

  6. If you can see "Removal Driver" on windows after you install Driver, it means that installation was achieved.

Manual

- When you connect USB Cable with PC(after Driver Installation), you will see "Removal Driver" on Explorer.At the momnet, if PC read USB exactly, a lamp on the device will be turned on. When you access, LED will be flickering.

- The way to download programe from the Internet.

  1. Log in. after you get a membership from Koritech's Homepage (www.koritech.co.kr)

  2. Program will be downloaded after you do "Click Download Menu Click Download Button for Geneal Members."

Suggestions

  1. Do not pull out Cable or Card while you are using the products.
  2. Do not pull our the card until LED stop flickering.