
Federal Communications Commission (FCC) Notice

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits of a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in particular installations, if this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

1. Reorient / Relocate the receiving antenna.
2. Increase the separation between the equipment and receiver.
3. Connect the equipment into an outlet on a circuit different from that the receiver is connected.
4. Consult the dealer or an experienced radio / TV technician for help.

CAUTION: Changes or modifications not expressly approved by the manufacturer responsible for compliance could void the user's authority to operate the equipment.

Disclaimer

The following does not apply to any country where such provisions are inconsistent with local law:

KYE Systems Corp. makes no warranties with respect to this documentation, whether expressed or implied. All material is provided "as is". This includes, but is not limited to, any implied warranties of merchantability and fitness for a particular purpose. The information covered in this document is subject to change without notice. KYE Systems Corp. assumes no responsibility for any errors that may appear in this document.

All brand names mentioned in this manual are trademarks or registered trademarks of their respective companies.


Copyright © 2000 KYE Systems Corp. All rights reserved.

Hardware Installation


Hardware Installation

Note: Always turn off your computer before you connect or disconnect your mouse and keyboard unless you're using a USB device in Win98 or above. If you have a PC with the PC 99 spec, then the mouse port and keyboard port are green and purple respectively.

1. Connect the receiver's green mouse connector to the computer's 6-pin mouse port.
Connect the receiver's purple keyboard connector to the computer's 6-pin keyboard port.



2. Install two AAA batteries in the mouse and two AA batteries in the keyboard.



3. The Wireless 2.4G TwinTouch+ provides 16 separate channels. Please make sure the mouse, keyboard and receiver is all the same channel. The default channel is established on ch. 1.

4. Turn on your computer.



Warning:

1. When you use Wireless 2.4G TwinTouch+ on a desk that is made of metal, try using a pad and reduce the receiving distance.
2. You can only set up one Wireless 2.4G TwinTouch+ at a time. But if you have up to 16 sets additional in an area of 10 square meters, more interference will occur between the receiver and your keyboard and mouse.
3. If you feel the mouse does not move smooth as usual or the keyboard does not work when typing, that the batteries have lost their charge, so please replace them. Also, the wireless icon will be blinking "red" when there is a battery-low situation.




4. The Wireless 2.4G TwinTouch+ with radio frequency gives you free movement and an enjoyable experience. For optimal performance, place the receiver far away from the 2.4GHz devices, such as the microwave oven, 2.4GHz Wireless LAN, and etc.

Software Installation

1. Make sure the mouse and keyboard is connected to the computer.
2. Put the Setup disk (or CD) into the disk drive.
3. Follow the instructions on the screen to finish the software installation.

Factory Setting

1. Mouse:



2. Keyboard:



1. Rewind: Previous track of audio or video CD's
2. Play & Pause: Play and pause of audio or video CD's
3. Stop: Stop play of audio or video CD's
4. Forward: Next track of audio or video CD's
5. Vol.-& +: decrease or increase volume
6. My favorite: Open my favorite folder
7. E-mail: Open mail folder
8. Back: See last page when viewing the Internet
9. www: Open browser in Netscape or IE
10. Forward: Go to next page when viewing the Internet
11. Sleep: Turn system into sleep mode

