







## User manual for 2K9A0523 module

### 1. Location of 2K9A0523 module

MFP installs module in this area.



Front cover opens for replacing toner container.



Toner container is removed.



Multi Function Printer.



## **2. Toner container monitoring system**

Our multi function printer performs communication with Module and Tag of the toner container and monitors the toner container.

## **3. Compliance for FCC and IC rules**

Our module, 2K9A0523 complies with Part 15 of FCC and IC rules.

Changes or modifications not expressly approved by the party responsible for compliance could void the user' s authority to operate the equipment.

Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.