


# Operating Guide of the Remote

## Remote Overview



### ● Massage Function

**10 MIN 20 MIN 30 MIN** The light on the top of the remote indicates a 10, 20, or 30 minute timer setting.

**TIMER/ALL OFF** The TIMER/ALL OFF button allows you to select a 10, 20 or 30 minute massage time. You can also turn off the massage with this button.

**MASSAGE** The MASSAGE button activates head and foot massage. Press again to turn it off.

**HEAD ↑** Increase the head massage intensity.  
**HEAD ↓** Decrease the head massage intensity.

**FOOT ↑** Increase the foot massage intensity.  
**FOOT ↓** Decrease the foot massage intensity.

**6 massage intensities to chose from**

### ● Adjustment function

**HEAD ↑** Lift the head section of the base  
**HEAD ↓** Lower the head section of the base

**FOOT ↑** Lift the foot section of the base  
**FOOT ↓** Lower the Foot section of the base

**TILT ↑** Lift the head tilt  
**TILT ↓** Lower the head tilt

**LUMBAR ↑** Lift the Lumbar support  
**LUMBAR ↓** Lower the Lumbar support

### ● Adjustment function

**Z GRAV** Z GRAV preset position adjusts your legs to a higher level than your heart helping to relieve pressure off the lower back and improve blood circulation.

**—** Flat preset position  
**~** Relax preset position

**~** TV/PC preset position  
**☀** Turn on/off the under-bed Light

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment OFF and ON, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna
- Increase the separation between the equipment and receiver
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected
- Consult the dealer or an experienced radio/TV technician for help.

Note:

The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.

### FCC RF Safety Caution Statement:

This equipment complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. This equipment must be installed and operated in accordance with provided instructions and must not be co-located or operating in conjunction with any other antenna or transmitter. End-users and installers must be provided with antenna installation instructions and transmitter operating conditions for satisfying RF exposure compliance.