

User manual of the Remote controller

Model Name: SFD-Y-14,SFD-Y-18

Press **TIMER** button: set the massage intervals with each press of the button (10, 20, 30 min). when the timing is over. All massage motor will automatically stop.

SFD-Y-14

Press **ALL OFF** button: All the massage motors will stop working.

Press **HEAD** button: control the rise and fall of the headboard.

Press **FOOT** button: control the rise and fall of the footboard.

Press **TILT** button: control the rise and fall of the tiltboard.

Press **LUMBAR** button: control the rise and fall of the lumbarboard.

Press **FLAT** button: under any position, the bed will return the flat position.

Press **ZERO G** button: under any position, the bed will return the ZERO G position.

Press **TV/PC** button: under any position, the bed will return the TV/PC position.

Press **LONGE** button: under any position, the bed will return the LONGE position.

Press **HEAD +/-**: adjust the HEAD vibrating strength.

Press **FOOT +/-**: adjust the FOOT vibrating strength.

Adjust Frequency: Manually select the frequency of code automatically.

SFD-Y-18

Press **BACK** button: control the rise and fall of the backboard.

Press **FOOT** button: control the rise and fall of the footboard.

Press **FLAT** button: under any position, the bed will return the flat position.

Press **MEMORY** button: under any position, the bed will return the MEMORY position.

FCC STATEMENT:

1.This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions:

1). The device may not cause harmful interference

2). The device must accept any interference received, including interference that may cause undesired operation

2.Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.