
### Installation Guide







Wifi Receiver

#### Caution

After installed, the WIFI and BT must keep away from the human body

greater than 20cm!

The WIFI and BT can not use in the computers!



Go to the App Store, search and download the corresponding APP for our beds.

A: For single bed, make sure the remote is programed for the bed (If not, refer to "Program Remote for one bed" on the bed owner's manual), and then follow the procedure below:

1. Unplug the bed/beds, then insert the Wi-fi wireless receiver into

the control box. 2. Plug the bed and then (within 10 seconds) press and hold down the "Head Down" and "Foot Down" buttons on the remote until the remote "beeps" three times and two timer lights flash three times,

indicating Wi-fi is ready for use on your device. B: For two split beds, Firstly synchronize the beds with remote

(Refer to "Program Remotes for Two Split Bases" on the bed owner's manual), then follow the procedure below:

1. Unplug both beds, then insert the Wi-fi wireless receiver into the

control box. 2. Plug the first bed (leave the 2nd bed unplugged). Then (within 10 seconds) press and hold down the "Head Down" and "Foot Down"

buttons on the remote until the remote "beeps" three times and two timer lights flash three times, indicating Wi-fi is ready for use for the first bed.


3. Plug the second bed, then (within 10 seconds) press and hold down the "Head Down" and "Foot Down" buttons on the remote until the remote "beeps" three times and two timer lights flash three times, indicating Wi-fi is ready for use for the second bed.


After steps of either A or B, follow below procedure to use Wi-fi:

Go to "Setting" on your iPad or iPhone, Click Wi-fi to the "on" position. Then chose the address of the bed in setting. Enter the APP you have downloaded, input the original password "123456", then APP control is ready for use.

#### **Operation Guide of Bluetooth interface**

For the bluetooth receiver, go to "Setting" on your iPad or iPhone, Click







Enter the APP "SOFTIDE BLE m" or "Softide ble h".



bluetooth to the "on" position.





This APP requires the password. The default password is "123456". Then slide the screen to left and chose the address of the

## **Operation Guide of Wifi interface**







Go to "Setting" on your iPad or iPhone, Click wifi to the "on" position. Then chose the address of the bed in setting as the pic shows.









Enter the APP "Softide w002" or "Softide w005".


This APP requires the password. The original password is "123456".

# Interface control instruction:









Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC

interference to radio or television reception, which can be determined by turning the equipment OFF and ON, the user is encouraged to try to correct the interference by one or more of the following measures: Reorient or relocate the receiving antenna

> Increase the separation between the equipment and receiver Connect the equipment into an outlet on a circuit different from that to which the receiver is connected

Consult the dealer or an experienced radio/TV technician for help.

Note:

modifications could void the user's authority to operate the equipment. Conditions for Use:

The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such

# This device complies with Part15 of the FCC Rules. Operation is subject

to the following two conditions: (1) This device may not cause harmful interference, and

(2) This device must accept any interference received, including interference that may cause undesired operation.

To satisfy FCC RF exposure requirements for mobile and base station transmission devices, a separation distance of 20 cm or more should be maintained between the antenna of this device and persons during operation. To ensure compliance, operation at closer than this distance is not recommended. The antenna(s) used for this transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.