

## User Manual

## INTRODUCTION

**Morphibians** are unique 4x4 amphibious vehicles with full function radio control. This rugged vehicle can traverse the toughest terrain and drive to water instantly! With the full function R/C handset you can control all the action from a distance away!

## OPERATION TIPS AND HELPFUL HINTS

- Avoid playing in salt water, this may cause rust to form.
- If your vehicle starts to lose power, it may experience loss of functions and performance. If this happens simply replace the batteries in vehicle and handset.
- Your **Morphibian R/C** is operated by radio waves. It is possible that the vehicle may not perform properly due to interference with devices such as cordless phones, hair dryer, radio, walkie-talkie or other radio-controlled toys.
- **Morphibian** vehicles are designed to take on water. To improve on-water performance, after playing with the R/C in water, it is advised to drain the water out of the hull. Drainage holes are located at the bottom on the vehicle.
- After playing in water wipe your **Morphibian** dry with a clean dry towel.
- Do not operate during electrical storms.
- Operate only in fresh water with little to no current.
- Do not operate in water during heavy winds.
- Avoid wetting the antenna on the vehicle.
- Avoid reducing the length of the antenna on the vehicle.


## INSTALLATION OF BATTERIES

### BATTERY REQUIREMENTS

- Handset: 2 x AAA SIZE alkaline (1.5v) batteries.
- Vehicle: 3 x AA SIZE alkaline (1.5v) batteries.

### Vehicle

1. Unscrew the roof with a Phillips screwdriver to expose the battery compartment.
2. Unscrew the battery door and insert 3-AA batteries with polarities shown inside the battery compartment.
3. Replace the battery cover and screw shut.
4. Replace the roof and screw shut.
5. Turn switch ON to start your Morphibian.




### Handset


1. Unscrew the battery cover on the underside of the Handset controller with a Phillips screwdriver.
2. Insert 2-AAA battery with the polarities show inside the battery compartment.
3. Replace the battery cover and screw shut.

## HOW TO INSTALL ANTENNA-TUBE

Pass the antenna wire through the antenna-tube and insert the tube into the antenna-tube holder.




## HOW TO PLAY




**FORWARD:**

press both keys forward




**REVERSE:**

press both keys back



**TURN LEFT:**

push right key to turn left



**TURN RIGHT:**

push left key to turn right

## SAFETY PRECAUTIONS

- Please read instructions thoroughly before operating this vehicle.
- Adult supervision is recommended. Keep out of reach of children 3 and under.
- Children should be aware of the dangers associated with playing near water before operating near or around water.
- Always select a safe place to play. Never drive your vehicle on populated streets.
- Keep fingers, hair and loose clothing away from tires, wheel hubs and motors while the vehicle is switched on.
- Do not use chemicals on the **Morphibian** or transmitter, they can deform or damage the product.
- Do not mix different brands of batteries.
- Do not mix new and used batteries.
- Do not mix alkaline, standard (Carbon-Zinc) or rechargeable (Ni-Cd) batteries.
- Batteries must be inserted with the correct polarities as shown in the battery compartments.
- Exhausted batteries should be removed from the vehicle and disposed of properly. Do not dispose in fire as batteries may leak or explode.
- Batteries should be replaced by an adult.
- Please keep the instructions for future reference.

## FCC NOTICE


This equipment has been tested and found to comply with limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy if not installed and used in accordance with the instructions, and may cause harmful interference to radio communications. However, this is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

**NOTE:** Changes or modifications not expressly approved by the manufacturer could void user's authority to operate this device.

The radio circuitry in your vehicle and remote controller is sensitive. Radio interference can affect the control of your vehicle. You may have to choose another location to operate your vehicle.

**Toll Free Hot Line: 800-816-1135**



Copyright ©2004 Kid Galaxy, Inc.  
Morphibian Series



**WARNING:**

**CHOKING HAZARD - Small parts  
Not for children under 3 years.**