

MISSING SOMETHING? / BESOIN DE PIÈCES DE RECHANGE ? / ¿TE FALTA ALGO? / FEHLT ETWAS? / MANCA QUALCOSA?



USA/CANADA
parts.KidKraft.com

EUROPEAN REGIONS
parts.KidKraft.eu

AUSTRALIA
parts.KidKraft.au

Welcome to the KidKraft family

We do our very best to ensure accuracy in every order, but occasionally we miss something. That's why our warranty covers every single part of your new product for 90 days after purchase. If you are missing parts or find any damage, it's easy to order replacements at **parts.KidKraft.com** in the US and **parts.kidkraft.eu** in Europe. You can also review your warranty, download assembly instructions and more by visiting **KidKraft.com**.

Bienvenue dans famille Kidkraft

Nous faisons de notre mieux pour assurer l'exactitude dans chaque commande, mais parfois nous manquons quelque chose. C'est pourquoi notre garantie couvre chaque partie de votre nouveau produit pendant 90 jours après l'achat. S'il vous manque des pièces ou si vous, c'est facile de commander des pièces de rechange chez **parts.KidKraft.com** aux États-Unis et **parts.kidkraft.eu** en Europe. Vous pouvez également consulter votre garantie, télécharger les instructions d'assemblage et plus encore en visitant **KidKraft.com**.

Bienvenido a la Familia Kidkraft

Hacemos nuestro mejor esfuerzo para asegurar la precisión en cada orden, pero a veces se nos olvida algo. Por este motivo, nuestra garantía cubre cada parte de su nuevo producto por los próximos 90 días después de su compra. Si a le falta alguna parte o si consigue algún daño en el producto, es muy sencillo solicitar un remplazo en **parts.KidKraft.com** en los Estados Unidos y en **parts.kidkraft.eu** en Europa. También puede revisar su garantía, descargar instrucciones de ensamblaje y mucho más visitando **KidKraft.com**.

Willkommen zu KidKraft Family

Wir geben unser Bestes, bei jeder Bestellung sicherzustellen, dass höchste Sorgfalt geboten wird, aber vereinzelt kann es vorkommen, dass wir etwas übersehen. Aus diesem Grund deckt unsere Garantie jedes einzelne Teil Ihres neuen Produkts für die Dauer von 90 Tagen nach Erwerb ab. Sie können ganz einfach Ersatzteile bei **parts.KidKraft.com** in den USA und **parts.KidKraft.eu** in Europa bestellen, sollten Teile fehlen oder Beschädigungen vorliegen. Besuchen Sie **KidKraft.com**, um unter anderem die Garantie einzusehen und Aufbauanleitungen herunterzuladen.

Benvenuti nella famiglia KidKraft


Facciamo del nostro meglio per garantire la precisione in ogni ordine, ma ogni tanto qualcosa può sfuggire. Ecco perché la nostra garanzia copre ogni singola parte del nuovo prodotto per 90 giorni dopo l'acquisto. In caso di parti mancanti o se si riscontrano danni, basta semplicemente richiedere la sostituzione su **parts.KidKraft.com** negli Stati Uniti e **parts.kidkraft.eu** in Europa. E anche possibile controllare la garanzia, scaricare le istruzioni di montaggio e altro ancora visitando **KidKraft.com**.

Batch Code
Code de lot
Código De Lote
Chargennummer
Numero del lotto:



REV 08/24/2020





Parts and Hardware
 Pièces et matériel
 Partes y Piezas Para Instalación
 Teile und Befestigungsmaterial
 Parti e componenti meccanici



KidKraft®

5904-1785



5903-122



1753-SL



791-122



791-1785



1756-122




1756-1785




788-SL x 2




5905-2287 x 5




5906-3115 x 5





5907-1585 x 5



5908-123 x 5




5864 x 5





x 2

5058-WT


A	x 9	E	x 4	I	x 2	S	x 2
----------	------------	----------	------------	----------	------------	----------	------------

**40 mm**White / Blanco / Blanc /
Weiß / Bianca**40 mm**Yellow / Jaune / Amarillo /
Gelb / Giallo**25 mm**Gray / Gris / Gris /
Grau / Grigio

B	x 33	F	x 26	J	x 3
----------	-------------	----------	-------------	----------	------------

**40 mm**Gray / Gris / Gris /
Grau / Grigio**40 mm****25 mm**

C	x 1	G	x 1	K	x 3
----------	------------	----------	------------	----------	------------

**40 mm****40 mm**

Blue

**11 mm**

D	x 4	H	x 3	L	x 20
----------	------------	----------	------------	----------	-------------

**40 mm**

Silver /

**25 mm**White / Blanco / Blanc /
Weiß / Bianca

Parts and Hardware
Pièces et matériel
Partes y Piezas Para Instalación
Teile und Befestigungsmaterial
Parti e componenti meccanici


All hardware dimensions are approximate.
Toutes les dimensions du matériel
sont approximatives.
Todas las dimensiones de las herramientas
son aproximaciones.



KidKraft®


Step
Étape
Paso
Schritt
Fase

1




Step
Étape
Paso
Schritt
Fase

2



Step
Étape
Paso
Schritt
Fase


3



KidKraft®


Step
Étape
Paso
Schritt
Fase

4




Step
Étape
Paso
Schritt
Fase

5



Step
Étape
Paso
Schritt
Fase


6



KidKraft®


Step
Étape
Paso
Schritt
Fase

7




Step
Étape
Paso
Schritt
Fase

8



Step
Étape
Paso
Schritt
Fase


9



KidKraft®


Step
Étape
Paso
Schritt
Fase

10




Step
Étape
Paso
Schritt
Fase

11



Step
Étape
Paso
Schritt
Fase


12



KidKraft®


Step
Étape
Paso
Schritt
Fase

13



Step
Étape
Paso
Schritt
Fase


14



KidKraft®


Step
Étape
Paso
Schritt
Fase

15




Step
Étape
Paso
Schritt
Fase

16




Step
Étape
Paso
Schritt
Fase

17




Step
Étape
Paso
Schritt
Fase

18




Step
Étape
Paso
Schritt
Fase

19



Step
Étape
Paso
Schritt
Fase


20



KidKraft®


Step
Étape
Paso
Schritt
Fase

21




Step
Étape
Paso
Schritt
Fase

22



Step
Étape
Paso
Schritt
Fase


23



KidKraft®


Step
Étape
Paso
Schritt
Fase

24



Step
Étape
Paso
Schritt
Fase


25



KidKraft®


Step
Étape
Paso
Schritt
Fase

26



Step
Étape
Paso
Schritt
Fase


27



KidKraft®


Step
Étape
Paso
Schritt
Fase

28



Step
Étape
Paso
Schritt
Fase


29



KidKraft®


Step
Étape
Paso
Schritt
Fase

30



Step
Étape
Paso
Schritt
Fase


31



KidKraft®


Step
Étape
Paso
Schritt
Fase

32



Step
Étape
Paso
Schritt
Fase


33



KidKraft®


Step
Étape
Paso
Schritt
Fase

34



Step
Étape
Paso
Schritt
Fase


35



KidKraft®


Step
Étape
Paso
Schritt
Fase

36



Step
Étape
Paso
Schritt
Fase


37



KidKraft®


Step
Étape
Paso
Schritt
Fase

38



Step
Étape
Paso
Schritt
Fase










39



KidKraft®

Step
Étape
Paso
Schritt
Fase


40



KidKraft®


Step
Étape
Paso
Schritt
Fase

41




Step
Étape
Paso
Schritt
Fase

42



Step
Étape
Paso
Schritt
Fase


43



KidKraft®


Step
Étape
Paso
Schritt
Fase

44



Step
Étape
Paso
Schritt
Fase


45



KidKraft®


Step
Étape
Paso
Schritt
Fase

46



Step
Étape
Paso
Schritt
Fase


47



KidKraft®


Step
Étape
Paso
Schritt
Fase

48



Step
Étape
Paso
Schritt
Fase


49



KidKraft®


Step
Étape
Paso
Schritt
Fase

50



Step
Étape
Paso
Schritt
Fase


51



KidKraft®


Step
Étape
Paso
Schritt
Fase

52




Step
Étape
Paso
Schritt
Fase

53




KidKraft®




Step
Étape
Paso
Schritt
Fase

A1





Step
Étape
Paso
Schritt
Fase

A2



Step
Étape
Paso
Schritt
Fase

A3



KidKraft®

QUICK START GUIDE

- 1 Make sure both your Echo device and the *KidKraft Alexa 2-in-1 Kitchen & Market* are powered on.
- 2 Open the Alexa app.
- 3 Select Devices.
- 4 Select Echo & Alexa.
- 5 Select the Echo device you want to pair with your Alexa Gadget.
- 6 Select Pair Alexa Gadget, and then select the Alexa Gadget you want to pair.
- 7 Enable the skill and launch it by saying:
“Alexa, launch KidKraft Kitchen.”

Note: If needed, verify parental consent to access child-directed skills within the Alexa app on your phone, or at


www.amazon.com/myh/vpc/intro?clientId=Alexa_rw_vpc

Relaunch skill if needed once parental consent is established.



QUICK PLAY GUIDE

- 1 Make sure both your Echo device and the *KidKraft Alexa 2-in-1 Kitchen & Market* are powered on.
- 2 Say, "Alexa, launch KidKraft Kitchen" to begin playing.
- 3 Press the Play Button to start a game.
- 4 Insert a Recipe Card into the Card Reader to cook some food.
- 5 Try turning on the stove and cook some food in the pan.
- 6 Place some food on the Check-Out Scanner to do some shopping.
- 7 As you play, Alexa will ask you a question from time to time. You can respond to her and she'll react based on your answer.



FCC warning:

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC RF radiation exposure limits set forth for an uncontrolled environment.

IC warning:

- English:

This device complies with Industry Canada licence-exempt RSS standard(s).

Operation is subject to the following two conditions: (1) This device may not cause interference, and (2) This device must accept any interference, including interference that may cause undesired operation of the device.

- French:

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes:

- (1) l'appareil ne doit pas produire de brouillage, et
- (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

This equipment complies with IC RF radiation exposure limits set forth for an uncontrolled environment.

« ce matériel est conforme aux limites d'exposition aux rayonnements rf de ic énoncés dans un autre environnement.