

# Model: BE-826

## Important Radio FCC Information

This device complies with Part 15 of the FCC Rules, operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

**Warning:** Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**Note:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instruction, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is needed.
- Consult the dealer or an experienced radio/TV technician for help.

## A Consumer Guide to Product Safety

This unit has been designed and manufactured to assure your personal safety. Improper use can result in potential electrical shock or fire hazards. Please read all safety and operating instructions carefully before installation and use. Keep these instructions handy for future reference. Take special note, and adhere to all warnings on the unit and in the instruction and service manual.

1. **Water and Moisture** - The unit should not be used near water. For example, near a bathtub, washbowl, kitchen sink, laundry tub, in a wet basement, or near a swimming pool, etc.
2. **Ventilation** - The unit should be situated so that its location or position does not interfere with its proper ventilation. For example, it should not be situated on a bed, sofa, rug, or similar surface that may block the ventilation openings; or placed in a built-in installation, such as bookcase or cabinet that may impede the flow of air through the ventilation openings.
3. **Heat** - The unit should be situated away from heat source such as radiators, heat register, stoves, or other appliances (including amplifiers) that produce heat.
4. **Power Sources** - The unit should be connected to a power supply only of the type described in the operating instructions or as marked on the appliance.
5. **Grounding or Polarization** - This product is equipped with a polarized alternating current line plug (a plug having one blade wider than the other). This plug will fit into the power outlet only one way. This is a safety feature. If you are unable to insert the plug fully into the outlet, try reversing the plug. If the plug should still fail to fit, contact your electrician to replace your obsolete outlet. Do not defeat the safety purpose of the polarized plug.
6. **Power Cord Protection** - Power-supply cords should be routed so that they are not likely to be walked on or pinched by items placed upon or against them. Paying particular attention to cords at plugs, convenience receptacles, and the points where they exit from the unit.
7. **Cleaning** - The unit should be cleaned only as recommended by the manufacturer.
8. **Nonuse Periods** - The power cord of the unit should be unplugged from the outlet when it is to be left unused for a long period of time.

9. **Object and Liquid Entry** - Care should be taken so that objects do not fall and liquids are not spilled into the enclosure through openings.
10. **Damage Requiring Service** - The appliance should be serviced by qualified service personnel when:
  - A. The power-supply cord or plug has been damaged.
  - B. Objects have fallen into or liquid has been spilled into the enclosure.
  - C. The unit has been exposed to rain.
  - D. The unit has been dropped or the enclosure damaged.
  - E. The unit does not appear to operate normally or exhibits a marked change in performance.
11. **Servicing** - The user should not attempt to service the unit beyond that described in the user's operating instructions. All other servicing should be referred to qualified service personnel.

## **Installation**

**Note:** The BE-826 base is operating by AC supply and the wireless MIC is operating by DC supply. To ensure the wireless MIC operation, you must install 2 "AAA" batteries. Read through this Instruction Book carefully before install battery or plug in AC adapter.

## **Battery installation**

1. Switch the wireless MIC Power On/Off switch to Off position.
2. Open the battery door on the wireless MIC by screw driver.
3. Install 2 "AAA" alkaline batteries, while making sure that the polarity is correct as shown within the battery compartment.
4. Close the battery compartment door.

### **We recommend**

- Removing batteries if unit is not used for more than 30 days.

## **AC Power Connection**

1. Switch the Base Power On/Off switch to Off position.
2. Plug-in the adaptor to the wall power plug then connect to the DC jack located on the back of the Base unit.

## **Maintenance**

- Place the unit on a level surface away from sources of direct sunlight or excessive heat.
- Protect your furniture when placing your unit on a natural wood and lacquered finish. A cloth or other protective material should be placed between it and the furniture.
- Clean your unit with a soft cloth moistened only with mild soap and water. Stronger cleaning agents, such as Benzine, thinner or similar materials can mar the surface of the case.

## **Connect to you TV/VCR**

**Important** – You must connect the BE-826 to your TV/VCR to show pictures and sound. Your TV/VCR must have AV input connector.

1. Using the AV cable to connect the BE-826 Base unit to your TV or VCR. Must sure color on the wires is matching to your TV/VCR connector.
2. If you have MONO TV/VCR only then you can switch the MONO/ST. switch to MONO and just connect the white wire. On the other hand, switch the MONO/ST. switch to ST.
3. Make sure to set your TV/VCR properly to show AV input.

### **Become a Star**

1. Must sure all connection is correct and turn on your TV/VCR and set it to AV in mode.
2. To turn on the unit by turn the Power On/Off switch on the base unit. The Power ON Indicator will light up.
3. You can see pictures on your TV too. You became a Star now.
4. You can also sing by using wireless MIC or normal wire MIC. Also, by connecting external CD player then you can sing with your favor songs.
5. To adjust loudness, adjust MIC-1 VOL, MIC-2 VOL or Master VOL for best result.
6. You can also adjust ECHO or PITCH to change you voice.