


—Product description—



This diagram shows the multi-function key on the back of the device. It is a small, rectangular button with a Type-C port symbol. The key is labeled with the following text:

- Type-C
- 多功能键
- 音量+
- 音量-

开启用户手机蓝牙功能(或其他蓝牙设备),并进行搜索或扫描,此时手机会搜索到附近所有的蓝牙设备,点击搜索到的耳机名称:YYK-525,并输入密码 0000 (目前大部分手机不需要密码)成功配对连接后,耳机指示灯熄灭,表示配对连接成功!此时可以进行手机电话、听歌

1. 长按 ON/OFF 键 1 秒

2. 单击 ON/OFF 键

- 1.初次开始使用的情况下,从充电盒子里拿出耳机撕掉保护膜。把耳机放回充电仓耳机就会开始充电并自动关机。当耳机从充电仓里取出,耳机就会自动开机。
- 2.当耳机不使用时,放回充电仓会自动关机。

- 1.从充电仓拿起开机
- 2.耳机红、蓝交替闪烁(配对模式)
- 3.打开手机/平板的设置---蓝牙---打开蓝牙---搜索---YYK-525
---配对/连接---播放音乐。

打开电脑设置-设备-蓝牙和其他设备-开启蓝牙--添加蓝牙或其他设备
-搜索蓝牙设备-YYK-525-配对/连接-播放音乐。
注意:如果电脑没有蓝牙,请插入蓝牙适配器,下载蓝牙驱动后再
正常使用。

耳机在关机状态下，ON/OFF键长按8秒。将耳机放入充电仓，耳机会自动关机并开始充电。取出耳机后，耳机会自动开机，重置就完成。

- 1.把耳机放入充电仓内，耳机就会自动关机然后开始充电，充电仓显示屏亮起，显示充电仓当前电量，说明充电仓正在给耳机正在充电。
- 2.耳机充满电后，耳机指示红灯就会灭掉。

1. 请使用手机适配器给充电仓充电, 可以使用电脑Type-c线或者其他Type-c接口的充电器进行充电。
2. 充电仓数字显示屏指示, 说明正在给充电仓充电。充满电为100。

版本	V5.1
支持蓝牙	A2DP,AVRCP,HFP,HSP,EDR
通信距离	≤10m
频率	2.402GHz-2.480GHz
喇叭阻抗	13Ω±10%
待机时间	400小时
通话时间	10-12小时
音乐播放时间	10-12小时
耳机电池容量	100mAh
充电仓电池容量	500mAh
耳机充电时间	约1.5小时
充电仓充电时间	约1.5小时
产品重量	71g

生活防水 (出汗、下雨、洗脸、淋浴等, 水里游泳等除外)

* 请注意手机的蓝牙信号不能在水中传输

水上

水下

关于手机传输距离如下图所示



1. 请不要拆卸/重新组装产品, 以免发生故障或火灾。
2. 请避免接触腐蚀性液体, 以免损坏产品。
3. 不要放在-10摄氏度以下或者60摄氏度上的极端温度下。
4. 远离小孩或宠物。
5. 不要让手机接触尖锐物品, 否则容易刮花。
6. 请不要在雷雨天使用手机避免产生电击。
7. 1个月以上不使用的话, 为了安全运行, 请定期充电, 保养。
8. 由于蓝牙耳机信号不能在水中传输, 游泳潜水将会导致信号断开或者中断。

1. 蓝牙的距离是10m, 请确保没有障碍物, 手机需要靠近耳机
2. 如有其他手机或者设备连接过该耳机, 请先解除配对
3. 请重新启动蓝牙设备, 然后尝试重设耳机

- 请检查手机网络是否正常,网速是不是比较慢,音乐是不是正在加载中。
- 蓝牙的距离是10m,请确保没有障碍物,手机需要靠近耳机。
- 周围环境的干扰或者磁场太强将会影响蓝牙信号传输。
- 打开手机蓝牙界面,点击接触配对,删除配对记录,搜索蓝牙,再次配对。
- 你可以重启手机或者重置耳机。

请确保耳机有足够电量。另外耳机将自动断开蓝牙连接10min，将耳机重新放入充电仓，拿起耳机将自动开机。

1. 请确保充电线或者手机充电器是良好状态且正确连接。
2. 有可能接触不良。用手指按耳机，并将耳机的充电触点完全连接到充电盒。
3. 耳机的充电触点可能脏，多尘或出汗。放回充电盒充电时，请用酒精或者布擦拭。
4. 耳机请擦干后再放回充电盒充电，耳机指示灯亮起。
5. 如果听到“Low Battery”的提示音，请为耳机充电。当充电盒LED指示灯显示达到“100”时，请为充电盒充电。请注意不要使耳机和充电盒中的电量耗尽，可能会缩短内置锂电池的使用寿命。


高质量的耳机,为了延长使用寿命,请参考以下说明:

1. 请让本品远离高温、高温、腐蚀环境。
2. 请防止本品被撞击,跌落,弯曲,浸泡等。
3. 请不要拆卸耳机或者充电器。
4. 请不要让本品一直过度充电,这样会降低的使用寿命。
5. 如果它引起任何不适感或者疼痛,请停止使用本品。
6. 使用由受监管的制造商认证的DC 5V-1A适配器。

反复充电和放电耳机可能会导致电池性能随时间降低,这对所有可充电电子产品来说都是正常的。


- 1.蓝牙耳机1个
- 2.充电座1个
- 3.Type-c充电线
- 4.说明书1本

—Product description—



A diagram of a Type-C USB connector. Labels with leader lines point to the following components: Type-C (the connector itself), Switch (the top button), Volume+ (the middle button), and Volume- (the bottom button).

Make sure the headset is off, press and hold the multifunction key for about 3 seconds until the blue light comes on once, Then the red and blue lights flash alternately (at this time it enters the pairing state) and waits for the connection.



Call Siri
Long press on the on button for 1s.

Close Siri
Click the on key

1. In the first time use, take the earbuds from the charging bin and peel off the protective film. Once put into the charging bin, the earbuds will turn off and initiate recharging automatically. When taken out from the charging bin, the earbuds will turn on automatically.
2. After use, put the earbuds into the charging bin, and it will turn off automatically.

1. Take the earbuds out of the charging bin and it will start work automatically.
2. The red and blue lights will flash alternatively (entering pairing mode)

3. Access the Settings of mobile phone/tablet -- Wireless -- Search -- YK-525 -- Pair/Connect -- Play music.

Notes: If the computer has no Wireless function, please insert a Wireless adaptor, and download a Wireless driver for normal functioning.

When the headset is off, press the on / off key for 8 seconds. Put the headset into the charging compartment, and the headset will automatically turn off and start charging. After taking out the headset, the headset will turn on automatically, and the reset is completed.

1. put the headset in the charging bin, the headset will be automatically turned off and then charged.
The display lights up to show the current power of the charging chamber, indicating that the charging chamber is charging the headset.
2. When the headset is fully charged, the red light of the headset indicator will be off

1. Please use a mobile phone adapter to recharge the charging bin. You may charge via a Type-C cable connected to a computer, or other charger with a Type-C interface.
2. The digital display of the charging bin will indicate the recharging process, and 100 battery level means fully recharged.

Version	V5.1
Wireless support	A2DP,AVRCP,HFP,HSP,EDR
Communication range	≥10m
Frequency band	2.402GHz-2.480GHz
Electrical impedance	130±10%
Standby time	400h
Call time	About 10-12h
Music playing time	About 10-12h
Earbuds battery capacity	100mAh
Host battery capacity	500mAh
Charging bin recharging time	About 1.5h
Charging time of headset	About 1.5h
Weight	71g

* Note that the Wireless signal of mobile phones can't be transmitted in water.

The transmission distance of the mobile phone is shown in the following chart



1. Please avoid disassemble/reassemble the product in case of failure or fire accident.
2. Please keep away from corrosive liquids to prevent the product from damage.
3. Please avoid exposure to extreme temperatures below 10°C, or above 60°C.
4. Please keep beyond the reach of kids or pets.
5. Please mind contact with sharp objects to avoid scratch.
6. Please avoid use in thundering and raining days to prevent damage or electrical shock.
7. In the case of non-use for about a month, please charge regularly for maintenance.
8. As the Wireless signal cannot transmit in water, it is not suitable for swimming for diving.

Why wireless pairing failure:

1. The Wireless range is 10m; please ensure no obstacles and place the mobile phone close to the earbuds.
2. If the earbuds are connected to other mobile phone or devices, please disconnect first.
3. Please reboot the Wireless device and reset the earbuds.

1. Please ensure the charging cable or mobile phone charger is in a good state and with proper connection.
2. To ensure proper connection, press the earbuds to fully connect the charging points to the charging bin.
3. The earbud charging points might be stained with dust or sweat. When place them into the charging bin for recharging, please clean with alcohol or cloth.
4. Please wipe the sweat on the earbuds before putting into the charging bin, and the indicator lights will turn on.

Please ensure sufficient battery level. In addition, the earbuds will automatically disconnect Wireless for 10mins. Place the earbuds back to the charging bin and they will restart after recollecting.

1. Please ensure the charging cable or mobile phone charger is in a good state and with proper connection.
2. To ensure proper connection, press the earbuds to fully connect the charging points to the charging bin.
3. The earbud charging points might be stained with dust or sweat. When place them into the charging bin for recharging, please clean with alcohol or cloth.
4. Please wipe the sweat on the earbuds before putting into the charging bin, and the indicator lights will turn on.
5. Once the prompt "Low Battery" appears, please recharge the earbuds. When the number displayed on the LED lights on the charging bin reaches "10", please recharge the charging bin. Please pay attention to not using up the battery of the earbuds and charging bin, as it may shorten the service life of the built-in lithium battery.

To guarantee the service life of the quality earbuds, please refer to the instructions as follows:

1. Please keep away from high temperature, high humidity and corrosive environment.
2. Please avoid bumping, falling, bending, soaking, and etc..
3. Please do not disassemble the earbuds or charging bin.
4. Please do not overcharge for a long time, which will shorten the service life.
5. In the case of feeling any comfort or pain, please stop using the product.
6. Please use certified DC 5V-1A adapter from manufacturer under the supervision of regulatory authorities. Repeated charging and discharging will impair the battery performance over time, which is normal for all rechargeable electronic products.

1. Earbuds * 1
2. Charger * 1
3. Type-C charging cable * 1
4. User Manual * 1

FCC Warning 15.19 Labeling requirements. This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. 15.21 Information to user. Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. 15.105 Information to the user. Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC	Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:	-Reorient or relocate the receiving antenna. -Increase the separation between the equipment and receiver. -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. -Consult the dealer or an experienced radio/TV technician for help. FCC RF Radiation Exposure Statement: 1.This Transmitter must not be co-located or operating in conjunction with any other antenna or transmitter. 2.This equipment complies with RF radiation exposure limits set forth for an uncontrolled environment.	This equipment should be installed and operated with minimum distance 5mm between the radiator and your body.
---	--	---	--