

Item: Bluetooth speaker



Description:

KTS-88 it is the 2 times 3W Bluetooth speaker, With A2DP and Handfree .

Remark:

1. keep out of reach of children!
2. Pls use the original accessories
- 3.If unit have problem, pls contact with the seller.

Disassemble the unit by User is not allow

4. Keep good ventilated environment when charge the unit, do not keep near inflammables, oxidizers and explosive

B. Specification:

1. Size : 197*61*70MM	9. Charge port: Micro USB
2. Weight : --- g	11. Aux in jack : 3.5MM
3. Battery output : DC3.7 ~ 4.2V	12. Amplifier : Class D power amplifier
4. Charge input : DC 5V-600mAh	13. Bluetooth effective distance : 10M
5. Battery capacity : 600mAh	14. Microphone: effective distance 50CM
6. Speakers Driver : 3W*1+Radiator passive	15. Working/Playback Time @ 50% volume: 4 hours

7. Bluetooth Ver.: 2.1+EDR	16. Frequency Response : 150hz-18khz
8. Charging time : 2 hours	17. Speaker size: 40MM

Operation guide

A: Connect to the Bluetooth device

1 .Turn on unit firstly, KTS-88 will have the indicate tune, the

Indicate LED is "BLUE".

Turn on the Bluetooth function on your mobile or other device and search for the speaker, model name "KTS-80". Then Pair the device.

4, Once device is paired Bluetooth will automatically connect when unit is turned on subsequently.

B: "- "

Short press :

- 1、 Aux in Mode : No function
- 2、 Bluetooth mode : change to the last track
- 3, USB and Micro SD model: Change to the last track

Long press :

- 1、 Aux in mode: No function
- 2、 Bluetooth mode : Decrease the volume
- 3, USB and micro SD model: Decrease the volume

B: “+”

Short press :

- 1、 Aux in Mode : No function
- 2、 Bluetooth mode : change to the next track
- 3, USB and Micro SD model: Change to the next track

Long press :

- 1、 Aux in mode: Increase the volume
- 2、 Bluetooth mode : Increase the volume
- 3, USB and micro SD model: Increase the volume

C. “▶||/↶”

Short press

- 1、 Aux in mode : Mute
- 2、 Bluetooth mode : Play or Pause or answer/hand up the call
- 3, USB and Micro SD mode: Play or Puase

Long press

- 1、 Aux in mode : Change the mode
- 2、 Bluetooth mode: Change the mode
- 3, USB or Micro SD mode: Change the mode

Function:

Aux-in

Change to the Aux in mode, and Using the audio cable connect to the unit Aux in Jack, it will automatically shift its status and will become AUX-IN. Long time press the "-" and "+" button to decrease and increase the Volume.

Charging

Plug the USB cable into speaker MICRO USB port and connect to power source.

Red LED will on when charging.

When charging is complete, the red LED will be off.

Accessories:

Audio Cable

Charging Cable

Manual

Certification: