

EN

SOUNDLOGIC™

WIRELESS MULTIFUNCTION BLOCK PARTY SPEAKER



80014

INSTRUCTION MANUAL

**PLEASE READ ALL INSTRUCTIONS CAREFULLY AND RETAIN FOR FUTURE
USE**

PACKAGING CONTENTS

Rechargeable Speaker
Micro USB cable
3.5mm Aux cable
Instruction Manual

GETTING STARTED

E

Remove product from packaging. Read instructions carefully before using the product and retain them for future reference. Retain packaging to store the product, or dispose of (or recycle it) safely and properly .


KEY FEATURES



Bluetooth speaker compatible with Bluetooth devices such as iPad , iPhone, Android , Windows phone ,smart phone ,tables , computers and more
Answer and make calls with the built in microphone (require connection with a cellular phone)
Support USB/TF card.
Karaoke Function
Rechargeable Lithium Battery

INSTRUCTION FOR USE

Charging the internal battery
Fully charge the unit before use.
Connect the USB cord to the port on the back of the speaker and insert the other end into a port on

DESCRIPTION OF PARTS



1. Switch: Switch on and off the unit
2. DC-5V: Please use the original charging cable to charge. The red LED is on when charging .
3. AUX: Audio input jack when connect .Enable the sound source connection active devices (PC, digital media player, mobile phones and other audio-visual products).
4. USB Slot : Used to read the MP3 files in FAT32 format with maximum size of 32GB.
5. TF Slot: Used to read the MP3 files in FAT32 format with maximum size of 32GB
6. Karaoke hole.
7. Mode Key :Press to change and select the current mode.
8. Play/Pause : Under USB/TF/Bluetooth mode, short press for play and pause.
9.  :Under USB/TF/Bluetooth mode. Short press to move to previous channel/track.
10.  :Under USB/TF/Bluetooth mode. Short press to move to next channel/track.
11. - :Press the button to decrease the volume.
12. + : Press the button to increase the volume.

PAIRING YOUR SPEAKER

Your speaker will work best if it is within 10 meters of your smart device. You may experience sound briefly cutting off if you are out of range or if your wireless connection is weak. Make sure Bluetooth is enabled on your smart phone or tablet before starting the pairing process.

1. Turn on the speakers by flipping the Power Switch to the "On" position. The speaker will "beep" & the blue LED will start blinking rapidly .
2. From your smart phone or tablet, find a list of nearby devices and choose " 80014 speaker ".
3. Enter "0000" if asked. The speaker will "beep" again & the Blue LED rapidly blinking will be off when pairing is complete!
4. If you failed to pair it within the time frame or you want to pair with a new device please follow the steps outline above .

TAKING CALLS ON YOUR SPEAKER WHILE ON BLUETOOTH MODE

When there is an oncoming call , you can pick it on your phone ,and answer with the built-in mic inside the speaker

AUX FUNCTION OF THE SPEAKER

Turn on the speaker.

Plug the 3.5mm auxiliary cable into the aux port of the speaker, and the other end of the cable connects to the audio device(such as cellphone /computer/tablet . etc)




Select your favorite song as the source device and play .

Long press + to increase the volume and Long press - to decrease the volume .

Note :Functions like skip backwards, skip forward etc. can be only controlled through source , while playing in Auxiliary mode .

USB /TF CARD

Insert the U flash memory or Micro-TF card into the USB /TF slot. Unit will read the MP3 format

music automatically . Press  to Play/Pa use , Short press  or  to Prev and Next, Long press - and + to turn down and turn up the volume .

CHARGING

Please use the original charging cable to charge .

Red LED on while charging .

SPECIFICATIONS

BT version	:V4.2
BT range	:8-10m
Power input (V&A)	:5V 1A
Speaker output	:10W
Battery type	:Rechargeable Li-on Battery
Battery capacity	:800mAh
Impedance	:2ohm
Frequency range	:100Hz - 18kHz
Size	:150mm*96mm*227mm
Charging time	:Up to 3 hours
Playtime	:Up to 2 hours (70% volume)

WARNING

Keep away from water and moisture.
Keep away from heat sources.
Do not disassemble.

Disposal of your old product and battery



Your product is designed and manufactured with high quality materials and components, which can be recycled and reused.



This symbol on a product means that the product is covered by European Directive 2012/19/EU.



This symbol on a product means that the product contains a built-in rechargeable battery covered by European Directive 2013/56/EU which cannot be disposed of with normal household waste.

We strongly advise you to take your product to an official collection
Inform yourself about the local separate collection system for electrical and electronic products and rechargeable batteries. Follow local rules and never dispose of the product and rechargeable batteries with normal household waste.
Correct disposal of old products and rechargeable batteries helps prevent negative consequences for the environment and human health.



The packaging is made entirely of recyclable materials, which you may dispose of at local recycling facilities.



The product and packaging materials are recyclable, dispose of it separately for better waste treatment. The Triman logo is valid in France only.



Contact your local refuse disposal authority for more details of how to dispose of your worn-out product.

Made in China

Reinhard NL
Netwerk 140-142
1446 WR Purmerend
The Netherlands



Federal Communications Commission (FCC) Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does

cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Warning: Changes or modifications made to this device not expressly approved by Shenzhen KingBoard Technology Co., Ltd. may void the FCC authorization to operate this device.

Note: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.