

SYLVANIA

Bluetooth Speaker

MODEL NO: SP776-PDQ_DG

INSTRUCTION MANUAL



The picture is only provided for reference. Please refer to the actual unit !

SYLVANIA is a registered trademark of OSRAM Sylvania Inc. used under license.

Instructions for use

Please read all instructions carefully

Getting started

Remove the unit from the box

Remove any packaging from the product.

Place the packaging inside the box and store for safekeeping

In the box

Bluetooth Speaker

USB charging cable

Instruction Manual

Features

-Bluetooth wireless connection functionality

-Built-in rechargeable battery

-Support USB/TF card

-FM radio ,search and record

Safety Instructions

Keep the unit away from heat sources, direct sunlight, humidity, water and any other liquids

Do not use the unit if it has been dropped or damaged in any way.

Repairs to electrical equipment should only be performed by a qualified electrician. Improper repairs may place the user at serious risk.

Do not put objects into any of the openings. Keep the unit free from dust, lint etc.

Do not use this unit for anything other than its intended use
Keep the unit out of reach of children

This product is not a toy

Do not use abrasive cleaning solvents to clean

To minimize the risk of fire or electrical shock, avoid operating in wet conditions such as rain or humidity



Do not operate around water (e.g. bathroom, swimming pool etc.)

Do not expose to excessive heat such as sunshine, fire etc
Never immerse the unit in water or any other liquid for cleaning purposes

Warning: Changes or modifications to this unit not expressly approved by the part responsible for compliance could void the user's authority to operate the equipment.

FCC Radiation Exposure Statement

The device has been evaluated to meet general RF exposure requirement. The device can be used in fixed/mobile (min20cm) exposure condition without restriction.



TF slot:	Used to read the Mp3 files In FAT 32 format with maximum size of 32GB
USB slot	Used to read the Mp3 files In FAT32 format with maximum size of 32GB
	Under FM/USB/TF/Bluetooth mode, short press to move to previous channel/track, Press and hold to decrease the volume
	Under USB/TF/Bluetooth mode, short press for play and pause; Under FM mode, Short press for automatic search.
	Under FM/USB/TF/Bluetooth mode, short press to move to next channel/track, Press and hold to increase the volume
Mode	Mode shift button. Short press and shift to bluetooth/FM mode default mode will be wireless connection mode
DC-5V	One end of the cable should be inserted In DC 5V. another end with USB jack be inserted In USB port of the PC or other charging device with standard DC5V jack. The indicate LED is on when charging.

INSTRUCTION FOR USE

Charging the speaker

This unit has a built in rechargeable battery.

Before using it for the first time we recommend you use the USB cable to

charge the battery fully.

Connect USB charging cable to the USB port or USB wall charger(Not included)

And connect other side to the USB charging slot of the speaker.

The

battery charging LED indicator illuminates while the speaker is being charged.

Pairing your device with Bluetooth speaker

Pairing the Bluetooth with Bluetooth devices(phone or music device)

Turn the VOL knob to turn the speaker ON and the Bluetooth mode will on automatically, you will hear a tone

Place the speaker and Bluetooth device (phone or music device)so that they are no further than 20 feet apart;

Activate the Bluetooth function on your Bluetooth device (phone or music device). Please refer to the manufacturer's instructions for instructions on enabling Bluetooth on your device.

Once you have activated Bluetooth on your device, select the pairing name "Sylvania SP776" from the list of available Bluetooth devices.

If required, enter the password 0000 to confirm to pairing.

Once paired successfully, you will hear a tone indicating pairing successful. You can now start to use the speaker.

Once you have paired the speaker with a device, the speaker will remember this device and will pair automatically when the device's Bluetooth is activated and in range. You do not need to re-pair any previously connected devices.

The speaker will attempt to automatically connect to the last device it was paired with when Bluetooth mode turns on. If you want to pair it with a new device, please turn off your last Bluetooth device (phone or music device) then use your new device to search and select the pairing name.

Once the speaker is paired with your device the music will transmit directly to the speaker. Please refer to your device's user manual for further information.

Function Summary

Listening to Music

Once the speakers are paired with your device you can stream music

wirelessly through the portable speaker, Select the track you wish to listen to and it will be streamed to your Bluetooth speaker, and you can use your device to control the Volume and skip tracks.

USB/ TF card playback

After the speaker is turned on, insert the USB/TF card to the slot will start to play the music automatically, and the Bluetooth mode will be disconnect.

FM radio

After pressing M button to change to FM radio status, press ►|| button to search channel automatically. This operation will scan all FM stations and pre-record them to memory. The scan procedure will take several minutes to complete and should not be interrupted.

Please Note

- Not all mobile phones support all the functions listed above
Please refer to your cell phone s user's manual for further information

- Certain functions and indication tones may vary depending on your mobile phone.

Cleaning & Maintenance

Turn OFF the speaker if it is left unattended and before cleaning.

Never immerse the speaker into water and please use a dry cloth for

Cleaning.

Storage

- Turn OFF the power when you not in use, clean and store safety.

Do's and Don'ts

Read the following recommendations before using the speaker.

Following these you will be able to enjoy the product for many years

- Don't use abrasive cleaning solvents to clean the speaker.
- Do not expose the speaker to extremely high or low temperature as this will shorten the life of electronic devices, distort certain plastic parts.
- Don't dispose of the speaker in a fire as it will result in an explosion
- Don't expose the speaker to contact with sharp objects as this

will cause scratches and damage

- Don't attempt to disassemble the speaker as it may get damaged if you are not professional
- Do not expose the speaker to heat or fire. Avoid storage in direct sunlight.
- Do not subject the speaker to mechanical shock
- Do not add any fluids or solids to your speaker
- Do not use the speaker if it has been damaged in any way

Specifications

Bluetooth specification	Bluetooth V4.2
Operating distance	10 meters(max.)
Speaker drive size	3inch
Speaker power	5W
Frequency response	100Hz-20KHz
Signal to noise ratio	$\geq 85\text{dB}$
Charging time	About 2hours

Note: Battery life & charging time may vary based on usage & types of devices used.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected
- Consult the dealer or an experienced radio/TV technician for help

This device complies with Part 15 of the FCC Rules Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received including interference that may cause undesired operation.

For service assistance and product information, please call
1-800-968-9853.

Curtis International Ltd.

7045 BECKETT DRIVE, UNIT 15, MISSISSAUGA, ON, L5S 2A3