

WELCOME! YOU ARE NOW ABOUT TO EMBARK ON AN AMAZING VR EXPERIENCE!

IMPORTANT PARTS & FEATURES



1. Open button - press to open cover
2. Action Trigger - enhances Experience with Google Cardboard apps & more
3. Focus/Distance Adjustments - Left/Right (Focus) and Forward/Back (Distance)

1



4. Universal Phone Caddy - for smartphones up to 6" wide
5. Built-in Controls
6. Retractable Earbuds - for a true, immersive experience
7. Lens System - blue tint, anti-glare
8. 3-Point Adjustable Strap - comfortable and secure
9. Game Controller - designed for comfort and pre-mapped to game

2

CHARGING YOUR VR HEADSET

The battery must be fully charged prior to use. It takes approximately 1.5 hours to fully charge your VR Headset (from depleted unit).

Indicator Light RED - unit charging
Indicator Light BLUE - unit fully charged

Via AC Adapter/Wall Charger:
Using the provided Micro USB cable, connect your VR Headset (Micro USB port) to the AC Adapter (USB port).



Micro USB Port for Charging

3

STEP 1 DOWNLOAD APP

STEP 2 PLACE MOBILE DEVICE *



WORKS WITH VR APPS

- Search your app store for VR apps.
- See our remote section on page 8 for apps that will enhance your VR experience with your remote.

* Remove phone from case; fits up to 6 in. wide (without a case).



- Open the app on your device.
- Open the cover by pressing the OPEN button. Place your mobile device as shown above.
- Make sure the split line is correctly aligned with the center mark. Close cover.

4

STEP 3 WEAR THE VR HEADSET


- Adjust the straps to fit your head.

- Adjust focus (left/right) and distance (forward/back) for the best image.



5

BUILT-IN CONTROLS



- 1 POWER ON / OFF
- 2 VOL - / PREVIOUS
- 3 PLAY / PAUSE
- 4 VOL + / NEXT
- 5 INDICATOR LIGHT
- 6 Micro-USB Port for charging

VOL + / NEXT
Press and Hold to Go Forward

VOL - / PREVIOUS
Press and Hold to Go Back

PLAY / PAUSE
Press 1x to start
Press 1x again to pause

Built-in controls do not have the functionality of a game controller. The built-in controls enable the user to Start, Stop, Fast Forward, Rewind, Pause and Skip for a particular app as well as for music. PLEASE NOTE - Not all apps will work with built-in controls. Please check the app/operating system you are using to determine the functionality of the built-in controls.

6

FOR THE ULTIMATE VR EXPERIENCE, USE THE RETRACTABLE EARBUDS.

Pull each earbud out gently until it locks. Do not over extend.



7



VR HEADSET BLUETOOTH PAIRING INSTRUCTIONS

Make sure the Bluetooth function is available on your mobile phone. Specific pairing procedures may be different depending on the device. For detailed information, please refer to the User Guide for your cell phone.

- The battery in the VR Headset must be fully charged prior to use. If the battery is low, the indicator light will flash RED.

1. Keep the distance between the mobile phone and the VR Headset within 3 feet (for pairing only).
2. Press and hold the to turn the VR Headset ON.
3. Activate the Bluetooth function on your mobile phone to search for Bluetooth devices. The indicator light on the VR Headset will start flashing BLUE / RED to begin pairing. Look for and select "Dream Vision VR" in the device display list.
4. When Bluetooth pairing is successful, the indicator light will flash BLUE.
5. Your VR Headset is now ready for use.

- If no device connection is made within 5 minutes of the VR Headset switched on, the VR Headset will automatically switch off to save power.
- After a successful pairing, devices will memorize each other and automatically pair the next time.

9

BLUETOOTH® GAME CONTROLLER IOS AND ANDROID COMPATIBLE



360° ROCKER

POWER ON / OFF
(Press and Hold)

Trigger Buttons



APPS THAT WORK WITH THE REMOTE:

iOS:

- Flight Simulator by Beenoculus
- 3D Donnington Castle VR
- Most apps that use the iCade protocol

Android:

- StarVRracer
- 4 Rooms
- VR Jet Fighter Simulation, and many more.

10

GAME MAPPED CONTROLLER BLUETOOTH PAIRING INSTRUCTIONS

Make sure the Bluetooth function is available on your mobile phone. Specific pairing procedures may be different depending on the device. For detailed information, please refer to the User Guide for your cell phone.

- Make sure to install 2 AAA Batteries inside the VR Controller (included). Do not mix old and new batteries.

1. Keep the distance between the mobile phone and the VR Controller within 3 feet (for pairing only).
2. Press and hold the to turn the VR Controller ON.
3. Activate the Bluetooth function on your mobile phone to search for Bluetooth devices. The indicator light on the VR Controller will start flashing BLUE to begin pairing. Look for and select "DV Controller" in the device display list.
4. When Bluetooth pairing is successful, the indicator light will stop flashing.
5. Your VR Controller is now ready for use.

- If no device connection is made within 5 minutes of the VR Controller switched on, the VR Controller will automatically switch off to save power.
- After a successful pairing, devices will memorize each other and automatically pair the next time.

11

FAQs

Q: VR image is blurry

A: Check the smart phone screen line is lined up to the center. If phone screen is properly centered, adjust focal distance and object distance until images become clear.

Q: Action button does not work.

A: The action button is app specific, it does not work with all apps. It is up to the app developer to make it work within their app.

Q: VR Controller does not control the game.

A: The included VR controller does not work with all games. Due to different developing methods and protocols, it is not compatible with all games. Please contact the game developer to find out if this controller is supported.

NOTE: We cannot guarantee controller compatibility to any games or apps.

12

PRECAUTIONS

- Do not drop VR unit as it may damage the device.
- Avoid any strong impact to VR unit as this may damage the device.
- Do not pull apart or dismantle the VR unit in any way.

Works for people with Myopia 600° or less.

TECHNICAL SPECIFICATIONS

Product Name: 3-D VIRTUAL GLASSES
Model: VR PRO GEN 1
Material: ABS + PC Eco-friendly material
Resolution: Based on the video source
Color Bit: Based on the video source
HD Lens: 42mm diameter
Zoom-in: 1.5-2x
Viewing Angle: 70°-90°degrees
Fits Phone Screen Size: 3.5-6 in.
Compatibility: Supports Android and IOS smart phones
Virtual Viewing: Simulates 100 inch screen display

Focal Distance: Adjustable
Object Distance: Adjustable
Dimension: 7.8" x 5" x 4.2" inches
Frequency Response: 20Hz - 20kHz
Resistance: 32Ω ±15% Sensitivity: -58 ± 3dB
Frequency Range: 2402-2480MHz
Earbuds: Fits in ear canal without MIC
Wireless connection: Bluetooth
Retractable Earbuds Pull-out
Cable Length: 7.5 inches
Cushioning materials: Foam + Vinyl

USA
DISTRIBUTED BY • DISTRIBUIDO POR:
ALDI INC., BATAVIA, IL 60510
www.aldi.us

AFTER SALES SUPPORT - SERVIZIO POSTVENDITA
@ 646-670-8190 support@vr.com
MODEL: DV18R0000R PRODUCT CODE: 5470 112051

2
YEAR WARRANTY
MADE IN CANADA

13

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

14