




HP Wireless Mini Speaker S6000 HP 袖珍喇叭 BT-120

Quick Setup





© Copyright 2013 Hewlett-Packard Development Company, L.P.

The information contained herein is subject to change without notice. The only warranties for HP products and services are set forth in the express warranty statements accompanying such products and services. Nothing herein should be construed as constituting an additional warranty. HP shall not be liable for technical and editorial errors or omissions contained herein.

First Edition: January 2013

3











16

	LED	狀態	指示器
	1 HP logo LED	開啟	白色
	2 Bluetooth® LED	鏈接	白色
		搜索設備	琥珀色
		配對	白色快閃
		配對成功	白色
		配对失败	琥珀色慢闪
		低电池	琥珀色
	3 Battery LED	充电時	琥珀色
		充满	绿色



