

DOOR AND PANEL PARTS

For Models: KUDS30IXBL7, KUDS30IXWH7, KUDS30IXBT7, KUDS30IXSS7

UNDERCOUNTER
DISHWASHER


KitchenAid®

(Black)

(White)

(Biscuit)

(Stainless)



Illus. No.	Part No.	DESCRIPTION
1		Literature Parts
	W10321621	Instructions, Installation
	W10395348	Energy Guide
	W10300928	Guide, Use & Care English/French
	W10300596	Guide, Use & Care Spanish
	W10321878	Tech Sheet/English
	W10321879	Tech Sheet/French
2		Arm, Hinge
	8534854	Left
	8534853	Right
3	W10321449	Vapor Barrier Assembly
4	W10385107	Insulation, Toe Panel
5		Access Panel
	W10368715	Black
	W10368716	White
	W10368717	Biscuit
6		Panel, Full Front (Includes Items 8 & 9)
	W10195532	Black
	W10195533	White
	W10195534	Biscuit
	W10195531	Stainless
7	W10315897	Insulation, Front Panel
8		Nameplate
	W10243392	Black
	W10243393	White
	W10243394	Biscuit
	W10243391	Stainless
9		Pocket Assembly
	W10195653	Black
	W10195654	White
	W10195655	Biscuit
	W10195656	Stainless
10	3400071	Screw
11		Fastener
	W10331789	Black
	W10331793	White
	W10331794	Biscuit
12	304392	Screw
13	W10194911	Bracket, Panel Control
14	W10354790	Block, Foam
15	W10350437	Insulation, Three Layer

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CONTROL PANEL AND LATCH PARTS


For Models: KUDS30IXBL7, KUDS30IXWH7, KUDS30IXBT7, KUDS30IXSS7

(Black)

(White)

(Biscuit)

(Stainless)



Illus. No.	Part No.	DESCRIPTION
1	W10386813	Console Assembly Black
	W10386814	White
	W10386815	Biscuit
	W10386816	Stainless
2	W10195237	Clip, Control
3	W10401190	Box, Connector
4	W10348409	Screw
5	W10380262	Latch Assembly (Includes Switch)
6	W10461372	Control, Electronic
7	W10194937	Brace, Connector
8	W10195718	Handle Black
	W10195833	White
	W10195834	Biscuit
	W10195835	Midnight Grey
9	W10195666	Jumper

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

INNER DOOR PARTS


For Models: KUDS30IXBL7, KUDS30IXWH7, KUDS30IXBT7, KUDS30IXSS7

(Black)

(White)

(Biscuit)

(Stainless)



Illus. No.	Part No.	DESCRIPTION
1	W10348409	Screw, Door
2	8281217	Screw
3	W10480715	Inner Door & Mastic Assembly
4	W10195543	Seal-Door Bottom


Illus. No.	Part No.	DESCRIPTION
5	W10195837	Barrier, Vapor Door
6	3400071	Screw
7	W10385977	Shield, Dispenser
8	W10304408	Dispenser, Assembly

Illus. No.	Part No.	DESCRIPTION
10	W10195007	Seal, Console/Door
11	W10434893	Wiring Harness
12	W10177098	Screw
13	W10462232	Bracket Dispenser


FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

FILL, DRAIN AND OVERFILL PARTS

For Models: KUDS30IXBL7, KUDS30IXWH7, KUDS30IXBT7, KUDS30IXSS7
 (Black) (White) (Biscuit) (Stainless)



Illus. No.	Part No.	DESCRIPTION
1	W10195037	Lever, Overfill Switch
2	8531412	Hose, Inlet
3	W10316375	Water Inlet (Also Order Items 4)
4	8531323	Gasket
5	W10213826	Nut, Inlet (Also Order Item 4)
6	371505	Clamp, Hose
7	W10316814	Fill Valve Assembly
8	304392	Screw
9	W10195039	Switch, Overfill Control
10	W10195035	Standpipe, Overfill (Also Order #11)
11	8531743	Gasket, Flat
12	W10195038	Nut, Standpipe
13	W10195036	Float & Retainer Assembly
14	W10292152	Miscellaneous Parts Bag (Contains 2 Hose Clamps, Screws & 2 Under Counter Brackets)
15	370445	Clamp, Hose
16	W10195750	Drain Loop with Check Valve Assembly
17	W10316376	Flapper



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

TUB AND FRAME PARTS


For Models: KUDS30IXBL7, KUDS30IXWH7, KUDS30IXBT7, KUDS30IXSS7

(Black)

(White)

(Biscuit)

(Stainless)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

TUB AND FRAME PARTS

For Models: KUDS30IXBL7, KUDS30IXWH7, KUDS30IXBT7, KUDS30IXSS7

(Black)

(White)

(Biscuit)

(Stainless)

Illus. No.	Part No.	DESCRIPTION
1	W10390308	Tub Assembly (Also Includes Heater Assembly)
2	3400924	Retainer, Push
3	W10300924	Seal, Door
4	W10082838	Plug, Tub
5	W10300779	Strike, Plate
6	3400014	Screw
7	W10179427	Seal, Cabinet
8	W10275523	Side Shield (Right & Left)
9	W10084086	Door, Balance Assembly
10	3367670	Screw
11	8269145	Bracket, Undercounter
12	3400074	Screw
13	W10195330	Wheel, Tub
14	W10348411	Screw
15	8268977	Wheel Leg
16	8524584	Leveler, Leg
17	3378128	Washer Pronged Cup
18	8270020	Spring, Door Balance
19	3400892	Screw
20	8268991	Cover, Terminal Box
21	W10158291	Cable, Door Assembly
22	W10292870	Protector
23	304666	Retainer, Push
24	8573239	Shield, Sound Tub
25	W10300703	Bracket, Thermostat
26	W10339563	Thermostat
27		Spacer, Tub/Brace
	W10195630	Left
	W10195631	Right
28	W10195367	Insulation Bottom
29	8572661	Actuator, Assembly
30	W10082769	Motor, Wax
31	8539404	Wrap-Tie

PUMP AND MOTOR PARTS


For Models: KUDS30IXBL7, KUDS30IXWH7, KUDS30IXBT7, KUDS30IXSS7

(Black)

(White)

(Biscuit)

(Stainless)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

PUMP, WASHARM AND MOTOR PARTS

For Models: KUDS30IXBL7, KUDS30IXWH7, KUDS30IXBT7, KUDS30IXSS7

(Black)

(White)

(Biscuit)

(Stainless)

Illus. No.	Part No.	DESCRIPTION
1	8534952	Accumulator Assy.
2	8283527	Shield
3	W10348405	Screw
4	8572618	Sump With Seal
5	8268375	Check Valve, Sump
6	W10083957	Chopper Assy.
7	9741232	Screw
8	8531857	Protector, Inlet
9	W10239404	Motor Assembly
10	3400217	Screw
11	W10084567	Screen, Separation
12	W10237169	Sump & Motor Assembly
13	W10300599	Tab, Sump
14	8533949	Nut
15	8558995	Pump, Drain
16	W10142656	Volute w/Seal (Also Order Items 19 & 21)
17	8269144	Hose, Drain
18	W10239401	Motor
19	8531018	Washer
20	8531017	Impeller
21	8268403	Face Seal Assembly (Also Order Item 19)
22	8269146	Hose Clamp
23	W10134017	Optical water Indicator
24	W10334457	Capacitor

UPPER WASH AND RINSE PARTS


For Models: KUDS30IXBL7, KUDS30IXWH7, KUDS30IXBT7, KUDS30IXSS7

(Black)

(White)

(Biscuit)

(Stainless)



Illus. Part
No. No. DESCRIPTION

- 1 W10077859 Feed Tube Assembly (Also Includes Item 3)
- 2 W10349488 Screw
- 3 8557720 Sprayarm, 3rd Level
- 4 W10118464 Fastener. Push-In


Illus. Part
No. No. DESCRIPTION

- 5 W10082867 Mount
- 6 W10323424 Manifold
- 7 W10082832 Hanger
- 8 8268433 Seal
- 9 W10082831 Probe
- 10 W10082841 Sprayarm
- 11 W10077600 Manifold, Turbozone
- 12 W10077903 Valve Assembly

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

HEATER PARTS

For Models: KUDS30IXBL7, KUDS30IXWH7, KUDS30IXBT7, KUDS30IXSS7
 (Black) (White) (Biscuit) (Stainless)



Illus. No.	Part No.	DESCRIPTION
1	W10329322	Heater Element Assembly (Also Includes Item 2)
2	717273	Washer, Heater Element
3	8268548	Nut, Heater Element
4	3400931	Retainer, Spring Grip
5	W10343251	Shield, Heater Nut

NOTE: If heater element is removed, it must be replaced.

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

UPPER RACK AND TRACK PARTS


For Models: KUDS30IXBL7, KUDS30IXWH7, KUDS30IXBT7, KUDS30IXSS7

(Black)

(White)

(Biscuit)

(Stainless)



Illus. No.	Part No.	DESCRIPTION
1	W10312791	Dishrack, Upper
2	W10350376	Adjuster Assy
3	W10267076	Clip, Dispenser Guard
4	W10324563	Track, Assembly
5	W10282826	Handle, Dishrack

Illus. No.	Part No.	DESCRIPTION
6	W10195622	Stop, Track Non-Removable
7	W10077844	Clip, No Flip
8	W10320664	Housing, Adjuster Left Hand
	W10320665	Housing, Adjuster Right Hand
9	W10250160	Clip-Lock Adjuster Arm

Illus. No.	Part No.	DESCRIPTION
10	W10250162	Cover, Adjuster
11	W10195839	Strap, Tether Adjuster
12	W10195840	Positioner, Adjuster
13	8562030	Tine, Row
14	W10082853	Clip, Pivot
15	8539102	Positioner, Dual

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

LOWER RACK PARTS


For Models: KUDS30IXBL7, KUDS30IXWH7, KUDS30IXBT7, KUDS30IXSS7

(Black)

(White)

(Biscuit)

(Stainless)



Illus. No.	Part No.	DESCRIPTION
1	W10056271	Lower Rack
2	W10195416	Wheel & Transport Assembly
3	W10195723	Basket, Silverware
4	W10056272	Tine, Row
5	W10078215	Retainer, Tine Row
6	W10078227	Clip, Pivot
7	W10482109	Basket, Utensil
8	W10175279	Retainer, Tine Row

LOWER WASHARM AND STRAINER PARTS


For Models: KUDS30IXBL7, KUDS30IXWH7, KUDS30IXBT7, KUDS30IXSS7

(Black)

(White)

(Biscuit)

(Stainless)



Illus. No.	Part No.	DESCRIPTION
1	W10320510	Washarm Assembly
2	W10077899	Cap, Internal Rear Feed (Also Order Item 3)
3	8268340	Seal, Sprayarm
4	W10077898	Hub, Lwr Sprayarm (Also Order Item 3)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OPTIONAL PARTS (NOT INCLUDED)
 For Models: KUDS30IXBL7, KUDS30IXWH7, KUDS30IXBT7, KUDS30IXSS7
 (Black) (White) (Biscuit) (Stainless)

Illus. No.	Part No.	DESCRIPTION
<u>ACCESSORIES</u>		
	Side Panel Kits	
	8171656	White
	8171657	Black
	8171658	Biscuit
	8171659	Stainless Steel
	Custom Panel & Trim Kit	
	8212489	Black
	Drain Hose	
	3385556	12 Ft.
	Vinyl Touch-Up (4oz.)	
	676453	White
	676455	Grey
	4396853	Silver Atlantis
	Moisture Barrier Kit	
	4396277	Kit

Illus. No.	Part No.	DESCRIPTION
<u>PAINT, TOUCH-UP (1/2oz.)</u>		
	72017	White
	72032	Black
	4392899	Biscuit
	4396603	Meteorite
<u>PAINT, PRESSURIZED SPRAY (12 oz.)</u>		
	350930	White
	285006	Superior Black
	4392901	Biscuit
<u>PAINT, BULK (1 qt.)</u>		
	799344	White (Uncut)
	4392900	Biscuit

Illus. No.	Part No.	DESCRIPTION
<u>POWER CORD KIT</u>		
	4317824	Power Cord Kit (Includes Power Cord & Misc. Hardware)
<u>ANTI-TIP KIT</u>		
	8171477	Floor Mount Kit
	8212560	Side Mount Kit
<u>DISHRACK REPAIR</u>		
	4396838	White
	4396840	Grey
	4396854	Silver Atlantis