


# COOKTOP, BURNER AND GRATE PARTS

For Models: KGCS166GBL2, KGCS166GWH2, KGCS166GBT2, KGCS166GSS2  
(Black) (White) (Biscuit) (Stainless Steel)

36" GAS COOKTOP

**KitchenAid®**



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# COOKTOP, BURNER AND GRATE PARTS


For Models: KGCS166GBL2, KGCS166GWH2, KGCS166GBT2, KGCS166GSS2  
 (Black) (White) (Biscuit) (Stainless Steel)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1		LITERATURE PARTS	6		Cap, (RF)(LR)	11		Grate, Filler
	LIT4455834	Installation Instructions		3191729	White		3191281	White
	LIT3193071	Use & Care Guide		3191728	Black		3191280	Black
	LIT3192099	Wiring Diagram		3191730	Biscuit		3191282	Biscuit
	LIT3191638	Safe Cooking Tips		3192486	Use w/Stainless Steel Model		3192483	Use w/Stainless Steel Model
	LIT3192742	LP Conversion Instructions	7		Cap, (CR)	12		Knob, Control (4)
2		Collar, Knob		3191732	White		3191923	White
	3192165	White		3191731	Black		3191922	Black
	3192164	Black		3191733	Biscuit		3191925	Biscuit
	3192167	Biscuit		3192487	Use w/Stainless Steel Model	15		Holder, Orifice
3	3193091	Seal, Foam	8		Cap, (RR)		9754182	RF - LR
4		Nameplate		3191735	White		9754188	LF
	3191516	White		3191734	Black		9754187	RR
	3191514	Black		3191736	Biscuit		9754186	Center
	3191920	Biscuit		3192488	Use w/Stainless Steel Model	16		Head, Burner
5		Cooktop	9		Cap, (LF)		8273216	RF - LR
	3191256	White		3191738	White		4455849	LF
	3191255	Black		3191737	Black		8273214	RR
	3191295	Biscuit		3191739	Biscuit		8273215	Center
	3191258	Stainless Steel		3192489	Use w/Stainless Steel Model	18	4449809	Screw
			10		Grate, Burner	20	3368921	Screw
				3191486	White			
				3191485	Black			
				3191487	Biscuit			
				3192485	Use w/Stainless Steel Model			

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# BURNER BOX, GAS VALVES, AND SWITCHES

For Models: KGCS166GBL2, KGCS166GWH2, KGCS166GBT2, KGCS166GSS2  
(Black) (White) (Biscuit) (Stainless Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# BURNER BOX, GAS VALVES, AND SWITCHES

For Models: KGCS166GBL2, KGCS166GWH2, KGCS166GBT2, KGCS166GSS2  
 (Black) (White) (Biscuit) (Stainless Steel)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	3191557	Rail, Burner	7	3192819	Rail, Center	16	3191325	Tubing, Gas Burner (RR)
2	6610013	Pipe, Manifold	8	3185829	Bolt, Gas Valve	17	3191327	Tubing, Gas Burner (LR)
3	3191292	Valve, Gas Burner (RF)(LR)	9	3400843	Screw	18	3191462	Shield, Heat (2)
4	3191387	Seal, Shaft	10	3192491	Bracket, Mainfold	19	3191332	Tubing, Gas Burner (CR)
5	3191293	Valve, Gas Burner (RR & CR)	11	3196160	Screw	21	3177120	Regulator, Pressure
6	3192157	Valve, Gas Burner (LF)	12	3191336	Harness & Switches	22	4455862	Burner Box
			14	3191324	Tubing, Gas Burner (RF)	27	8522424	Module Spark
			15	3191326	Tubing, Gas Burner (LF)			

## PARTS NOT ILLUSTRATED

Illus. No.	Part No.	DESCRIPTION
Following Parts Not Illustrated		

- 3192231 Cord, Power
- 4173634 Bushing
- 3179557 Screw
- 3183401 Bracket, Mounting
- 4167077 Tinnerman Nut

### Miscellaneous

- 3188310 Hardware, Mounting
- 3192741 Conversion Kit  
Natural Gas To L.P.

### WIRING HARNESS PARTS

- 3192229 Harness,  
Ignitor 15" (2)
- 4455861 Wire, Ground
- 3192230 Harness,  
Ignitor 28" (2)