

Illus. No.	Part No.	DESCRIPTION
1	W10344643	Literature Parts Installation Instructions
	W10328280	Owners Manual
	W10346742	Tech Sheet
2	W10347750	Cap, Burner 17K (RF)
	W10347754	5K(RR)
	W10347755	12K(LR)
	W10347764	9.5K(LF & Center)


Illus. No.	Part No.	DESCRIPTION
4	W10345848	Burner 9.5K(LF & Center)
	W10345845	16/17K (RF)
	W10345846	5K (RR)
	W10345847	12K (LR)
5	W10347690	Cooktop
6	W10507562	Panel, Manifold

Illus. No.	Part No.	DESCRIPTION
7	W10351694	Knob, Control (4)
	W10351695	(1)
8	W10347694	Grate, Burner Black, Side
9	W10347695	Grate, Burner Black, Center
10	W10351722	Shield, Heat-Knob
11	W10345998	Screw, Burner Head

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# CONTROL PANEL PARTS

For Models: KGRS206XSS3  
(Stainless)




Illus. No.	Part No.	DESCRIPTION
1	W10340740	Endcap, Left Hand
	W10340735	Endcap, Right Hand
2	W10340823	Heat Shield, Visor
3	W10351683	Panel, Backguard
4	W10340771	Overlay
5	W10340844	Heat Shield
6	W10340724	Rear Cover
7	W10340766	Control
8	W10315160	Cover, Main Wire

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# CHASSIS PARTS

For Models: KGRS206XSS3  
(Stainless)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# CHASSIS PARTS


For Models: KGRS206XSS3

(Stainless)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	W10347158	Oven Flue	14	W10347457	Shield, Oven Side	31	W10346268	Socket, Light
2	W10346958	Clip, Side	15	W10413010	Cord, Power	32	W10346855	Bulb, Light
3	W10357267	Bracket, Support Oven Front	16	W10347007	Shield, Rear Wall	33	W10346874	Lens, Oven Light
4		Bracket, Lockdown	17	W10347289	Shield, Flue	34	W10346877	Retainer, Lens
	W10369888	RH	18	W10347288	Shield, Heat	35	W10347448	Cover, Fan
	W10369890	LH	19	W10346230	Cover, Rear Main	36	W10346266	Bottom, Oven
5	W10355276	Blade, Fan	20	W10347323	Bracket, Harness	37	W10347247	Sensor, Oven
6	W10347003	Bracket, Support Chassis	21	W10347310	Insulation, Oven Back	38	W10347453	Nut, Fan Blade
7	W10347008	Gasket, Flue	22	W10346955	Latch, Oven Door	39	W10347314	Baffle, Bake Burner
8	W10347438	Motor, Door Latch	23	W10346234	Brace, Oven Top	40	W10347441	Shield, Front Burner
9	W10347435	Rod-Latch	24	W10347308	Insulation, Oven Wrapper	41	W10347661	Bracket, Air Dam
10	W10347275	Screw, Oven Bottom	25	W10347277	Spacer, Oven Door	42	W10347440	Shield-Main Front
11	W10355274	Glide, Outer (For RH & LH)	26	W10346263	Foot-Level Rear Plastic	43	W10346265	Rack, Oven
12	W10346267	Switch, Oven Light	27	W10346264	Foot-Level Front Metal	44	W10359189	Insulation, Main Front
13		Side Panel	28	W10347458	Kit, Anti-Tip	45	W10347271	Shield, Wool Lower
	W10346237	Black, RH	29	W10347318	Bracket, Hinge	46	W10346993	Shield, Heat Lower
	W10346238	Black, LH	30		Shield, Side	47	W10347449	Motor, Fan
	W10346239	White, RH		W10356076	RH	48	W10347442	Bracket, Motor Mount
	W10346240	White, LH		W10356077	LH			

# MANIFOLD PARTS

For Models: KGRS206XSS3  
(Stainless)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# MANIFOLD PARTS

For Models: KGRS206XSS3  
(Stainless)


Illus. No.	Part No.	DESCRIPTION
1	W10411614	Manifold, Pipe
2		Valve, Burner
	W10315168	12K (LR)
	W10315171	5K (RR)
	W10315173	17K (RF)
	W10315175	9.5K (LF & Center)
4	W10411591	Tubing, Gas
5	W10345838	Harness, Igniter Includes Switches
6	W10346033	Bracket, Regulator
7	W10411589	Regulator,
8		Orifice
	W10346170	9.5K (LF & Center)
	W10346166	12K (LR)
	W10346164	17K (RF)
	W10346165	5K (RR)
10	W10346034	Tube, Valve to Regulator
11	W10346068	Baffle, Broil Burner
12	W10346056	Ignitor, Broil
13	W10346063	Burner, Broiler
14	W10346057	Baffle, Oven Burner
15	W10346064	Elbow, Fitting
16	W10346062	Tube, Valve to Mixer
17		Ignitor/Orifice Assembly
	W10345917	9.5K (LF)
	W10345914	12K (LR)
	W10345909	17K (RF)
	W10345910	5K (RR)
	W10345919	9.5K (Center)
19	W10346130	Ignitor, Bake
20	W10346052	Burner, Oven
21	W10345839	Module, Spark
22	W10346047	Valve, Safety
23	W10346140	Screw, Ignitor/Orifice

## Following Parts Not Illustrated

W10346171	Spuds, LP Gas (Kit of 5)
W10346229	Harness, Ignitor
W10346138	Cover, Broil Ignitor
W10345844	Bracket, Support Spark Module

# DOOR PARTS

For Models: KGRS206XSS3  
(Stainless)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# DOOR PARTS


For Models: KGRS206XSS3  
(Stainless)

Illus. No.	Part No.	DESCRIPTION
1	W10350605	Handle, Door
2	W10370043	Screw, Door Panel
3	W10370042	Washer, Door
4	W10347855	Liner, Door
5	W10347853	Glass, Inner
6	W10352006	Bracket, Glass
7	W10350610	Spacer, Door Handle
8	W10347852	Insulation, Door
9	W10348012	Frame, Door Glass
10	W10352004	Hinge, Door
11	W10507565	Glass, Outer Door
12	W10370041	Screw, Door
13	W10347850	Retainer, Shield-Wool
14	W10348015	Bracket, Airwash Glass
15	W10350617	Bracket, Glass Spacer-Door Glass
16	W10348010	Seal, Door
17	W10357317	Door Panel
18	W10113961	Nameplate
19	W10348011	Glass, Door Inner



# DRAWER PARTS

For Models: KGRS206XSS3  
(Stainless)



<u>Illus. No.</u>	<u>Part No.</u>	<u>DESCRIPTION</u>
-------------------	-----------------	--------------------

1	W10347679	Drawer, Utility
2	W10347683	Liner, Drawer Front Frame
3	W10507559	Panel, Drawer
4	W10350605	Handle, Drawer
5		Glide, Drawer
	W10347664	LH
	W10347665	RH

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# OPTIONAL PARTS (NOT INCLUDED)

For Models: KGRS206XSS3  
(Stainless)

<b>Illus.</b>	<b>Part</b>	
<b>No.</b>	<b>No.</b>	<b>DESCRIPTION</b>

---

## REFINISHING MATERIAL

242756 Touch-Up  
Self-Clean(1/2 Pt)

## ACCESSORY PARTS

W10123240 Broiler Pan

## WIRING HARNESS PARTS

W10347662 Harness, Main