

Wood Grain LED Digital Alarm Clock


KACLKWDLEDA

Quick Start Guide

Features

- Calendar covering years 2000 to 2099
- Displays time, month, date and temperature
- 12/24 hour display format options
- 3 different alarm tones
- Mains powered or battery powered to suit your requirements

Product Layout



Note: when powering your alarm clock via the mains power, please remove any batteries from inside the unit to prevent battery decay or leakage which will damage the product.

Product Setup and Usage

- When turned on, press the 'SET' button for 3 seconds to enter settings mode. In this mode, you can set the Year, Month, Date, 12H/24H, Hour, Minute and Alarm.
- When editing any of the settings above, simply press the UP or DOWN button until the correct value is showing, then press SET to select the value.
- If you set a value incorrectly, you can renew the settings back to their factory default by pressing the RESET button.
- When using the 12 hour display format, PM hours are signified by the LED light on the top corner lighting up.