

USER GUIDE

KYGO A3/600
Wireless Headphones



Kygo Life unites my love of music with modern Scandinavian design. The aim is to develop top-quality audio equipment that sounds amazing and looks great. Future classics that capture the euphoric feeling of my music.

Like my approach to everything, Kygo Life is driven to continually improve. So as each product evolves it embraces the latest technology and focuses on perfecting the details until I'm absolutely happy the end result is the best it can be.

I hope that by creating new and inspiring audio experiences you'll enjoy listening to your favourite tunes even more.

A stylized, handwritten signature in black ink, appearing to read 'KGD'.

KYRRE GØRVELL-DAHLL
Creative Director, Kygo Life

ENGLISH

Getting Started

Congratulations on purchasing your new Kygo A3/600 headphone! Before using this product, you should read this manual and familiarize yourself with the Bluetooth functions of your mobile phone or other devices.

ENGLISH

Introduction

The Kygo A3/600 headphone allows you to listen to your music wirelessly from your mobile phone, tablet, or other Bluetooth® enabled device. It delivers powerful and clear sound. The built-in microphone also allows you to answer calls from your phone.

Precautions

Please refer to this Users' Manual before using to ensure proper use. The contents stated herein may be modified from time to time for better service as the product properties and functions are subject to change without prior notice.

For the sound performances of the product, never use it in too cold, too hot, too dusty or humid places, especially:

1. Moist or underwater conditions.
2. Near the heater or hi-temperature services or solarization.
3. In hazardous locations or in places apt to fall.
4. Never disassemble the combination audio.

ENGLISH

Do not use any diluents or volatile liquids to clean your headset and make sure to use only a charger from the qualified manufacturer.

In order to avoid electric shocks and product damage, do not attempt to dismantle, repair or modify the product.

This product or its battery cannot be disposed -with the household waste, therefore it must be returned to a collection point to be recycled. Please check with your local authorities for details.


ENGLISH

Features

1. 3.5mm music line-in function
2. Supports connection with 2 phones or devices
3. The headphone battery power status is displayed on iOS
4. AAC sound quality

ENGLISH

Basic Buttons Operation



"V+" button:

Short press to increase volume; Long press to go for the next track.

Multifunction button:

Power on/power off/answer a call/ end a call/reject a call/ pause/ play music.

"V-" button:

Short press to decrease volume; Long press to go to the previous track.

ENGLISH

General Function

When charging

The RED LED is on when the battery is charging. The RED LED is off when battery is fully charged.

When using the earphone

The RED and BLUE LEDs blink alternately when the headphone is in the pairing mode. Standby mode: the BLUE LED flashes rapidly. Music playback mode: the BLUE LED flashes slowly. The RED LED blinks with sound alert when the battery has low power.

Battery charging

The headphone comes with a built in rechargeable battery. Before using it for the first time we recommend you charge the battery fully. Only use the supplied micro USB cable to charge the headphone. Please charge for 3 hours. Connect the micro USB connector of the charging cable into the micro USB port of the headphone. Connect the other end of the USB cable to your computer's USB port or to an optional USB wall charger (not included).

The RED LED is on when the battery is charging. The RED LED is off when the battery is fully charged.

Switching on / off on

Switch ON: Press and hold the MFB for about 3 seconds, until the LED flashes BLUE.

Switch OFF: Press and hold the MFB for about 3 seconds, until the LED flashes RED.

Listen to music

When the headphone is successfully paired with your Bluetooth® device, simply start to play music on your device and you can enjoy the music wirelessly in your headphone.

Volume up in music mode: Short press the V+ key. You will hear a beep tone when the maximum volume level is reached.

Volume down in music mode: Short press the V- key. You will hear a beep tone when the minimum volume level is reached.

Go to the next song of your playlist: Long press on the V+ key.

Go to the previous song of your playlist: Long press on the V- key.

Play/Pause music: Short press on the MFB to pause the music. Short press again to resume the playback.

Hands-free function

You can answer calls from your mobile phone when the headphone is paired with your mobile phone. If you receive a call when listening to music, your music will pause automatically and you will hear your phone ringtone in the headphone.

Answer a call: Short press the multifunction button.

Reject a call: Press and hold the MFB button for 2 seconds until a beep tone is heard.

End a call: Short press the multifunction button.

Volume up in conversation mode: press volume "+" key. When the volume has reached the maximum level, you will hear a beep tone.

Volume down in conversation mode: press volume "-" key. When the volume has reached the minimum level, you will hear a beep n tone.

Bluetooth Pairing

You need to pair the headphone with your Bluetooth® enabled device (smartphone, tablet, mp3 player, computer, etc.) before enjoying the music wirelessly with the earphone.

Enter in pairing mode

Be sure that the headphone is in power off status first, then press and hold the MFB for about 5 seconds, until the RED and BLUE LEDs blink alternately. Then release the MFB button, the device is now in the pairing mode.

Pairing the headphone with Bluetooth® devices

1. Make the headphone- enter into the pairing mode (please refer to above section)
2. Place the Bluetooth® headphone and Bluetooth® device (phone, tablet, music device) within 1 meter from each other.
3. Activate the Bluetooth® function on your Bluetooth® device. Please refer to the manufacturer's manual for instructions on enabling Bluetooth® on your device. After searched, select "KYGO A3/600" in the device list on the Bluetooth® device.
4. If you are prompted for a password, enter the "0000" and press "connect" (only some Bluetooth® devices will ask for a password).

ENGLISH

5. When the connection is successful, a sound emitted from headphone and BLUE LED will quickly flash a few times indicating the pairing is successful.

Please note the pairing process on the headphone will last for around 3 minutes. If no devices are paired within around 3 minutes, the headphone will automatically return to standby mode. If the pairing is unsuccessful, turn off the headphone first and then re-pair again following the above steps.

Re-connecting to Bluetooth® devices

Every time the headphone is switched on, it will connect to the nearest and the last connected device automatically.

When the headphone is in standby mode and doesn't connect to any device, short press the MFB button and it will connect to last connected device automatically.

Note: Headphones can be paired with two devices simultaneously.

Mobile Devices Supported

In theory, it can support all equipment with Bluetooth®-enabled phone or music device that supports Advanced Audio Distribution Profile (A2DP) and Audio Video Remote Control Profile (AVRCP). In order for Bluetooth® devices to communicate with one another properly, they must utilize the same Bluetooth® profile. To determine the profiles supported by your device, please refer to the device's user guide. Certain Bluetooth features including those listed may not be supported by all compatible Bluetooth®-enabled devices, and/or the functionality of such features may be limited in certain devices.

Troubleshooting

- **Bluetooth pair and connection fail**
Other mobile device or equipment has been connected before connection, and has not left yet and Bluetooth cannot be switched off. When connection feature is employed again, the Bluetooth device will automatically search for this previously connected Bluetooth device for connection. First turn off the Bluetooth feature of the previously connected Bluetooth device and the next Bluetooth device can search, pair and connect normally.
- **The LED does not turn on and the Bluetooth device is not available**
Bluetooth device has not operated for a long time, and may come into dormant state. Press the MFB on the device for a longer time to activate it.

- **Short Bluetooth connection distance**

There is a barrier between the mobile device and Bluetooth headphone, so please clear it away.

- **Bluetooth may be normally connected and played, but sometimes, there is interrupted**

1. There is a barrier between mobile device and Bluetooth headphone, so please clear it away.
2. The distance between the Bluetooth device and connected device is too far away, out of the transmission range. Please put them closer.
3. The battery of headphone is discharged, please recharge it.

If you are experiencing other problems not listed here or you need help with your device, you can send an email to info@kygolife.com and we'll support you.

ENGLISH

Warning

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment .

ENGLISH

Warning

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Warning

Important Safety Instructions

To prevent possible hearing damage, do not listen at high volume levels for long periods.



Please use appointed battery in case of explosion risk, please dispose of lifeless battery under guidance. Recycle your phone

The WEEE logo (shown at the left) appears on the product to indicate that this product must not be disposed off or dumped with your other household wastes. You are liable to dispose of all your electronic or electrical waste equipment by relocating over to the specified collection point for recycling. Of such hazardous waste.

ENGLISH

Specifications

Bluetooth® version:	v4.2
Wireless range:	10m
Playing time:	23 hours
Standby time:	200 hours
Driver size:	40mm
Impedance:	36Ω
Frequency response (±3dB):	20Hz- 20kHz
Sensitivity (@1kHz):	119 +-3dB
Dimensions:	19 × 17 × 7.5 cm
Weight:	175 g

* Battery life and charging time may vary, depending on the usage and device type.

DUTCH

Aan de slag

Gefeliciteerd met de aanschaf van uw Kygo A3/600 hoofdtelefoon! Lees voor eerste gebruik deze gebruikershandleiding door voor wat betreft de Bluetooth functies van je mobiele telefoon en andere apparaten.

DUTCH

Inleiding

Met de Kygo A3/600 hoofdtelefoon kun je draadloos luisteren naar muziek van je mobiele telefoon, tablet of ander Bluetooth® apparaat. De hoofdtelefoon geeft een krachtig en helder geluid. Met de ingebouwde microfoon kun je tevens oproepen van je telefoon beantwoorden.

DUTCH

Let op

Lees deze gebruikershandleiding zorgvuldig door om te zorgen dat je het product op de beste wijze gebruikt. De inhoud kan veranderd worden wanneer producteigenschappen zonder voorafgaande aankondiging aangepast worden voor een betere gebruikerservaring.

Voor goede productprestaties, gebruik dit product niet in plaatsen die te koud, te heet, te stoffig of te vochtig zijn, in het bijzonder:

1. In vochtige omgevingen of onder water.
2. Bij een verwarming, warmtebron of direct zonlicht.
3. In gevaarlijke omgevingen of plaatsen waar het product kan vallen.
4. Demonteer deze combinatie-audio nooit!

DUTCH

Gebruik geen oplosmiddelen of vluchtige vloeistoffen om de headset te reinigen. Gebruik alleen een door de fabrikant goedgekeurde batterijoplader.

Om elektrische schok en schade aan het product te voorkomen, het product niet zelf demonteren, repareren of modificeren.

U mag dit product en de batterij niet afvoeren met je huishoudelijk afval maar moet deze inleveren bij een verzamelpunt voor recycling. Neem contact op met uw gemeente voor meer informatie.

DUTCH

Eigenschappen

1. 3,5 mm muziekfunctie via kabel
2. Ondersteunt verbinding met 2 telefoons of apparaten
3. De batterijlading wordt getoond via iOS
4. AAC sound quality