



# **WIRELESS PORTABLE SPEAKER**



LK-1545

Congratulations on purchasing the Lax-Max Wireless Portable Speaker Please read this instruction manual prior to using this unit.

### Features:

- •Wireless Connection
- TWS Function
  Support USB/TF card
  FM Radio



USB Charging Cable: 1 piece



#### Control Panel

- DC 5V IN: Use included charging cable to charge unit. (Adaptor not included).
   USB Slot: Insert USB Drive to listen stored tracks.
   TF Card Slot: Insert TF card to listen stored tracks.
- Power ON/OFF: Turn ON/OFF Unit's power supply.
- I ◀ ◀ /V-: Select previous track in Bluetooth/USB/TF Card Modes, Select previous preset frequency in FM mode. Long press to decrease the volume.
- ▶ I /V+: Select next track in Bluetooth/USB/TF Card Modes. Select next preset frequency in FM mode. Long press to increase the volume.
- ▶||/SCAN: Play or Pause in Bluetooth/USB /TF Card Mode. When in FM mode, short press to scan for available frequencies.
- \* Change light mode
   Mode/TWS: Toggle between source Bluetooth/USB/TF Card/FM Radio. When in Bluetooth mode, long press will be in TWS mode.

#### Bluetooth Connection

Use Bluetooth mode to stream music from a Bluetooth enabled player (eg., smartphone, or tablet device). A device must be paired with the unit before using them together for the first time.

• Make sure Bluetooth is enabled on your device and that it's next to the unit before attempting

- to pair it.

  Turn on the unit and set it to Bluetooth mode (press the mode button). The unit will automatically
- Intrinsities time and see it to broke out move (piless the intoe button). The unit will automatically enter pairing mode.
   Use your device to search for nearby Bluetooth devices. The speaker will be listed as "LK1545" Select "LK1545" from the list of found/available devices.

# **TWS Connection**

- TWS connection: TWS connection is only for two active speakers of same model, cannot support quantity over 2 PCS.
   Turn on two same speakers, press the MODE button to switch to BLUETOOTH mode for both
- speakers.

  Long press the MODE (TWS) button on one speaker. Then two speakers will automatically connect together.

  Pair your Bluetooth: use your device to search and connect for nearby Bluetooth devices.
- The pairing name is "LK1545"

## USB/TF Card

- Insert the USB or TF card into the USB/TF slot, It will read the MP3 format music automatically.
- Press ▶|| to Play/Pause, press I ◀ ◀ and I ◀ ◀ to Prev. and Next, long press thel ◀ ◀ and I ◀ ◀

#### FM RADIO

- Press the MODE button to change to FM radio mode,
- Press the ▶|| button to scan for available frequencies.
- Once it is done scanning, you can short press I ◀ ◀ or I ◀ ◀/+ to move forward or backward. Long press the I◀ ◀ and I◀ ◀/+ buttons to decrease and increase the volume.

# **FCC Statement**

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that impression to the properties of the properties of

# ECC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter