

2 in 1 Portable Earbuds

LK807

1, TWS Earbuds Technical Parameters

Wireless version: wireless V5.0

Transmission distance: 10M

Battery: 30mAh

Charging voltage: 3.7V

Support profile: A2DP/HFP/HSP/AVRCP

2. Speaker Technical Parameters

Battery: 3.7V 1500mah

Frequency response:120HZ-18KHZ

Speaker Power: 4Ω/5W

Size: L46mm*W46mm*H126.5mm

Weight: 170 g

Key instructions:

Power charging

Power bank


Speaker power control

Speaker battery indicator

Earbuds control

Earbuds indicator

Product Feature:



1. Earbuds pair automatically

- A. TWS earbuds will turn on automatically when pick out earbuds from the charging case with speaker power off.
- B. Earbuds will connect with another one to be TWS mode after turning on with voice prompt.
- C. Turn on the BT on your device, you can search for your pairing name LK807 from your wireless device to wirelessly connect to your earbud. You will hear "Connected" when pairing is complete.

2. Earbuds pair by hand

- A. double-click the button of L/R control when earbuds turn on, with voice prompt and LED indicator flashing slowly
- B. Turn on the BT on your device, you can search for your pairing name LK807 from your wireless device to wirelessly connect to your earbud. You will hear "Connected" when pairing is complete.

3. Speaker pairing

- A. Turn on the unit and it will automatically enter into Bluetooth pairing mode.
- B. Use your device to search for nearby Bluetooth devices. Our speaker pairing name – LK807

C. Select “LK807” from the list of found/available devices.

3. Speaker case charging

A. Put the earbuds into the case for charging automatically, the red light of the earbud is on when charging, and the light will be off when fully charged.

B. Press the speaker button for battery power indication.

C. Press the power button about 4 seconds to turn ON/OFF the speaker, it will be switched to speaker mode if you put earbuds back into the charging case.

Touch key function:

A. Hands-free call: short press the R/L key to answer/hang-up calls,

B. Long press R/L earbud about 3 seconds to reject the coming call.

C. When play music, short press the key to play / pause

D. When play music, double-click the button on left earbud for previous track, double-click the button on right earbud for next track

E. Triple-click R/L control for SIRI

Note:

1. The left and right earbud may also be used as a mono earbud.

2. if the earbuds fail to be TWS for some reason, please turn off it, and clear the wireless connection record on the device, then re-start the earbuds for TWS automatic pairing and connect the wireless device again

Pls pay attention to below points:

1. The charging case is used as a power bank, the current has certain restrictions, pls don't play the speaker and charge from the case at the same time, or it will not be used normally caused by overload, you would need to set-up again by charging.

2, please pull out the charging cable when fully charged

FCC Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.