

### General Description

Lansitec temperature and humidity sensor is based on the advanced LoRa modulation and powered by lithium battery with 5-year operation time. It offers cost effective LoRaWAN end device for a variety of application. It's IP64 enclosure and long operation time offers low maintenance and is ideal for outdoor use. Sensor work mode can be adjusted via LoRa network.

Lansitec sensors family is fully compatible and plug & play for LoRaWAN network operation.

### Applications

- Weather station
- Heating
- Drying
- Ventilation & air conditioning systems
- Smart Agriculture
- Building automation

#### Key features

- Powered by lithium thionyl chloride battery: 5 years of operation for 1 uplink 2 minutes.
- Extended industrial operating temperature:
- -40°C to +85°C.
- Outdoor use: IP64 enclosure.
- Accuracy:
  - $\pm 5\%$  RH typically from 20% RH to 80% RH at 25°C.
  - $\pm 0.3^\circ\text{C}$  typically from +5°C to +60°C.
- LoRaWAN compatible:
  - Class A, uplink rate programmable from 10 seconds to 24 hours.
- Change uplink cycle via wireless, configurable by server via downlink command
- Operating frequency bands (Option at order):
  - 900MHz, < 25mW radiated power

## 1. Product specifications

The tables below give the electrical specifications and performance of the temperature and humidity measurement.

Table 1 General electrical characteristic

ITEMs	Parameter	Specifications	Unit
<b>Structure</b>	Size	84 X 114 X 55	mm
<b>Electrical Characteristics</b>	power supply	3.6V battery	V
	Sleep current	5uA	uA
		Transmit current	120mA@17dBm set
	45mA@14dBm set		mA
	Uplink cycle	10 minutes in default	minutes
		Set by downlink command from server	
Battery life	More than 5 years with 5minutes cycle	years	
	More than 10 years with 10minutes cycle	years	
<b>Operating Range</b>	Temperature	-40 to 85	°C
	Humidity	0 to 100	%RH

Table 2 Temperature measurement performance

Parameter	Condition	Min	Typ.	Max	Units
<b>Resolution</b>	14bit		0.01		°C
<b>Accuracy</b>	Typ.		+/-0.3		°C
<b>Operating Range</b>	Extended	-40		85	°C
<b>Long Term Drift</b>	Normal		<0.04		°C

Table 3 Humidity measurement performance

Parameter	Condition	Min	Typ.	Max	Units
<b>Resolution</b>	12bit		0.04		%RH
<b>Accuracy</b>	Typ.		+/-3.0		%RH
<b>Nonlinearity</b>			<0.1		%RH
<b>Operating Range</b>	Extended	0		100	%RH
<b>Long Term Drift</b>	normal		<0.5		%RH

## 2. Application Information

### 2.1 Function

The sensor works in OTAA and Class A mode. DEVEUI, APPEUI and APPKEY are stored in the sensor and is necessary for joining a network. DEVEUI is labeled at the back of the device. APPEUI, APPKEY should be provided by each application. Lansitec will help to configure this before shipping.

After power on and join the Lora network, sensor will send registration message to Application Server(AS). If AS doesn't reply, sensor will retry for 5 times before switching to default mode (periodically report mode). Configuration information of the sensor is included in this registration message for AS to validate.

Sensor starts to work after receiving acceptance response or no AS reply after 5 times registration trial. Temperature and humidity will be reported to AS periodically. The duty cycle is configurable by commands from AS. Temperature and humidity acquisition and report period is 10 minutes by default.

According to LoRaWAN specification, downlink response time is decided by uplink duty cycle, user should refer the needed response time to choose uplink duty cycle. Detailed downlink and uplink definition are described below.

### 2.2 Uplink Message

#### 2.2.1 Register

Bytes	1	1	1	1	2	2
Item	TYPE	SMODE	POWER	CFG	TH	CRC

TYPE field

Bit	Name	Value	Description
7~4	TYPE	0x1	Message type. AS can use it to identify different uplink messages.
3	ADR	0: OFF 1: ON	ADR (Adaptive Date Rate) status
2~0	MODE	0x01~0x07	Current working scheme which should be one of SMODE

SMODE field

Bit	Name	Value	Description
-----	------	-------	-------------

7~0	SMODE	0x01: AU920 0x02: CLAA 0x04: CN470 0x08: AS923 0x10: EU433 0x20: EU868 0x40: US915	Data scheme supported by tracker. This field is preserved by Lansitec and will be configured before shipping.
-----	-------	--	--

### POWER field

Bit	Name	Value	Description
7~3	POWER	0~31	Configured transmit power (dBm)
2~0	Reserved	0x0	Reserved for future use. If MODE is CLAA, it indicates the frequency sweep mode of the tracker: 1: A mode 2: B mode 3: C mode 4: D mode 5: E mode 6: All frequency sweep Refer to CLAA China 470M-510M Band Using network technology requirements for detailed information.

### CFG field

Bit	Name	Value	Description
7~4	DR	0~15	Data Rate(DR0~DR15).
3	REPTIND	0~1	Indicates whether report the H&T if the value is the same. Default value is 0, means always report.
2~0	Reserved	0x0	Reserved for future use.

### TH field

Bit	Name	Value	Description
15~0	TH	1~65535	The period of temperature and humidity report, unit 10s.

### CRC field

Bit	Name	Value	Description
15~0	CRC		CRC16 of previous fields with TYPE bits set to 0, the polynomial is . AS only need to compare this data field with the AS stored one to judge whether configuration changed.

## 2.2.2 Periodical temperature and humidity

<b>Bytes</b>	<b>1</b>	<b>1</b>	<b>1</b>	<b>1</b>	<b>1</b>	<b>1</b>	<b>2</b>
<b>Item</b>	TYPE	VOL	RSSI	TEMP_INT	TEMP_FRA	HUMIDITY	CRC

### TYPE field

Bit	Name	Value	Description
7~4	TYPE	0x2	Message type, AS can use it to identify different uplink messages.
3~0	CHGSTATE	0x0: power cable disconnected 0x5: power cable connected charging 0x6: power cable connected charge complete	Status of battery charging.

### VOL field

Bit	Name	Value	Description
7~0	VOL	0~100	Battery left (unit: percentage)

### RSSI field

Bit	Name	Value	Description
7~0	RSSI	0~160	Received Signal Strength Indication (unit: -1dBm)

### TEMP\_INT field

Bit	Name	Value	Description
7~0	TEMP_INT	-127~127	Integer part of temperature. Bit7 indicates the sign, 1 means below zero. (unit: °C)

### TEMP\_FRA field

Bit	Name	Value	Description
7~0	TEMP_FRA	0~99	fractional part of temperature (unit: °C)

### HUMIDITY field

Bit	Name	Value	Description
7~0	HUMIDITY	0~100	Humidity (unit: %)

### CRC field

Bit	Name	Value	Description

15~0	CRC		Same CRC16 as calculated in register message. This can be used for server to check if any configuration mismatch.
------	-----	--	--

### 2.2.3 Acknowledge

<b>Bytes</b>	<b>1</b>	<b>1</b>
<b>Item</b>	TYPE	MSGID

TYPE field

Bit	Name	Value	Description
7~4	TYPE	0xF	Message type, AS can use it to identify different uplink messages.
3~0	RESULT	0: success 1: failure	Process result of any downlink message that need acknowledge

MSGID field

Bit	Name	Value	Description
7~0	MSGID	0~255	The MSGID field of corresponding downlink message

## 2.3 Downlink

### 2.3.1 Register acceptance

<b>Bytes</b>	<b>1</b>
<b>Item</b>	TYPE

TYPE field

Bit	Name	Value	Description
7~4	TYPE	0x1	Message type, tracker can use it to identify different downlink messages.
3~0	RESULT	0: success 1: illegal tracker 2: server busy	Register result

### 2.3.2 Lora configuration

<b>Bytes</b>	<b>1</b>	<b>1</b>	<b>1</b>
<b>Item</b>	TYPE	DR	MODE

TYPE field

Bit	Name	Value	Description
7~4	TYPE	0x8	Message type, tracker can use it to identify different downlink messages.
3	ADR	0: OFF 1: ON	ADR (Adaptive Date Rate) status
2~0	Reserved	0x0	Reserved for future use. If MODE is CLAA, it indicates the frequency sweep mode of tracker: 1: A mode 2: B mode 3: C mode 4: D mode 5: E mode 6: all frequency sweep

### DR field

Bit	Name	Value	Description
7~4	DR	0~15	Data Rate(DR0~DR15)
3	REPTIND	0~1	Indicates whether report the H&T if the value is the same. Default value is 0, means always report.
2~0	Reserved	0	Reserved for future use

### MODE field

Bit	Name	Value	Description
7~5	MODE	0x1:AU920 0x2:CLAA 0x3:CN470 0x4:AS923 0x5:EU434 0x6:EU868 0x7:US915	Configure mode.
4~0	POWER	0~31	Configure transmit power (unit dBm)

## 2.3.3 Sensor configuration

Bytes	1	2
Item	TYPE	TH

### TYPE field

Bit	Name	Value	Description
7~4	TYPE	0x9	Message type, tracker can use it to identify different downlink messages.

3~0	Reserved	0x0	Reserved for future use.
-----	----------	-----	--------------------------

TH field

Bit	Name	Value	Description
15~0	TH	1~65535	The period of temperature and humidity report, unit 10s.

### 2.3.4 Command request

<b>Bytes</b>	<b>1</b>	<b>1</b>
<b>Item</b>	TYPE	MSGID

TYPE field

Bit	Name	Value	Description
7~4	TYPE	0xA	Message type, tracker can use it to identify different downlink messages.
3~0	COMMAND	0x1: register request 0x2: device reset	Requested command. 0x1 used to request the tracker to send register message. 0x2 used to reset the device.

MSGID field

Bit	Name	Value	Description
7~0	MSGID	0~255	Server generated sequence number of downlink messages that need MSGID. Tracker will respond ACK with this number, otherwise AS should resend the message.

## 3. Mechanical structure and Assembly

### 3.1 Dimension

### 3.2 Battery installation

Battery holder is inside the sensor. Just insert the 3.6V battery to the holder, the sensor will start work with a default cycle. Please follow steps below when install a new battery.

Step1: Remove the cover.

Step2: Install the battery.


Step3: Reset the device.

Step4: Close and fix the cover again.

**Note: Don't inverse the polarity of the battery when insert the holder!!!**

### 3.3 Sensor Fixation

On the back of the housing, there are 4 screw mounting holes which are isolated from inside of the device. With this delicate design, the sensor could work in IP64 condition. Customer can use these 4 screw mounting holes for outdoor fixture. Refer to Figure 3 below for the detailed information of the screw mounting holes.



**Figure 3. Screw mounting holes for outdoor fixture**

### 3.4 Battery information

Lithium/thionyl chloride battery with PN ER34615 is used in the sensor, which could operate in -55 to +85 °C.

### Please Read Carefully:

Information in this document is provided solely in connection with Lansitec products. Lansitec reserve the right to make changes, corrections, modifications or improvements, to this document, and the products and services described herein at any time, without notice.

All Lansitec products are sold pursuant to Lansitec's terms and conditions of sale.

Purchasers are solely responsible for the choice, selection and use of the Lansitec products and services described herein, and Lansitec assumes no liability whatsoever relating to the choice, selection or use of the Lansitec products and services described herein.

No license, express or implied, by estoppel or otherwise, to any intellectual property rights is granted under this document. If any part of this document refers to any third-party products or services it shall not be deemed a license grant by Lansitec for the use of such third-party products or services, or any intellectual property contained therein or considered as a warranty covering the use in any manner whatsoever of such third party products or services or any intellectual property contained therein.

UNLESS OTHERWISE SET FORTH IN LANSITEC'S TERMS AND CONDITIONS OF SALE Lansitec DISCLAIMS ANY EXPRESS OR IMPLIED WARRANTY WITH RESPECT TO THE USE AND/OR SALE OF Lansitec PRODUCTS INCLUDING WITHOUT LIMITATION IMPLIED WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE (AND THEIR EQUIVALENTS UNDER THE LAWS OF ANY JURISDICTION), OR INFRINGEMENT OF ANY PATENT, COPYRIGHT OR OTHER INTELLECTUAL PROPERTY RIGHT.

LANSITEC PRODUCTS ARE NOT DESIGNED OR AUTHORIZED FOR USE IN: (A) SAFETY CRITICAL APPLICATIONS SUCH AS LIFE SUPPORTING, ACTIVE IMPLANTED DEVICES OR SYSTEMS WITH PRODUCT FUNCTIONAL SAFETY REQUIREMENTS; (B) AERONAUTIC APPLICATIONS; (C) AUTOMOTIVE APPLICATIONS OR ENVIRONMENTS, AND/OR (D) AEROSPACE APPLICATIONS OR ENVIRONMENTS. WHERE LANSITEC PRODUCTS ARE NOT DESIGNED FOR SUCH USE, THE PURCHASER SHALL USE PRODUCTS AT PURCHASER'S SOLE RISK, EVEN IF LANSITEC HAS BEEN INFORMED IN WRITING OF SUCH USAGE, UNLESS A PRODUCT IS EXPRESSLY DESIGNATED BY LANSITEC AS BEING INTENDED FOR "AUTOMOTIVE, AUTOMOTIVE SAFETY OR MEDICAL" INDUSTRY DOMAINS ACCORDING TO LANSITEC PRODUCT DESIGN SPECIFICATIONS. PRODUCTS FORMALLY ESCC, QML OR JAN QUALIFIED ARE DEEMED SUITABLE FOR USE IN AEROSPACE BY THE CORRESPONDING GOVERNMENTAL AGENCY.

Resale of Lansitec products with provisions different from the statements and/or technical features set forth in this document shall immediately void any warranty granted by Lansitec for the Lansitec product or service described herein and shall not create or extend in any manner whatsoever, any liability of Lansitec.

Lansitec and the Lansitec logo are trademarks or registered trademarks of Lansitec in various countries.

Information in this document supersedes and replaces all information previously supplied.

The Lansitec logo is a registered trademark of Lansitec. All other names are the property of their respective owners.

© 2015 LANSITEC - All rights reserved

<http://www.lansitec.com>

### Federal Communications Commission (FCC) Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

**Note:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Warning: Changes or modifications made to this device not expressly approved by **Nanjing Lansitec Information Technology Co., LTD** may void the FCC authorization to operate this device.

**Note:** The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.

The distance between user and products should be no less than 20cm