

USER'S GUIDE



FLATRON

777FN

User's Guide
Benutzerhandbuch
Manuel d'utilisation
Guida Utente
Guia del Usuario
Manual do proprietário
Handleiding

Please read this manual carefully before operating your set.
Retain it for future reference.
Record model number and serial number of the set.
See the label attached on the back cover and quote this
information to your dealer when you require service.

Contents

ENGLISH

Introduction	A1
Connecting the Monitor	A2
Making use of USB (Universal Serial Bus) Feature	A3
Location and Function of Controls.....	A5
Control Panel Function.....	A6
On Screen Display (OSD) Control Adjustment ...	A8
On Screen Display(OSD) Selection and Adjustment	A9
Sound Selection and Adjustment	A11
Video Memory Modes.....	A12
Troubleshooting.....	A13
Specifications	A14

DEUTSCH

Einleitung.....	B1
Anschließen.....	B2
Verwendung des USB (Universal Serial Bus)	B3
Ort und Funktion der Bedienelemente	B5
Bedienelemente der Bildkontrolle	B6
On Screen Display (OSD) Anpassung.....	B8
OSD Einstellung und Auswahlssymbole	B9
Ton Einstellung und Auswahlssymbole.....	B11
Videospeichermodi.....	B12
Störungen.....	B13
Produktbeschreibung.....	B14

FRANÇAIS

Introduction	C1
Branchement du Moniteur	C2
Utilisation du USB (Bus en série universel)	C3
Nomenclature et Fonctions	C5
Fonctions du Panneau de Commande	C6
Réglage des Commandes Affichage Écran	C8
Options de sélection et de Réglage OSD (affichage écran)	C9
Son de Sélection et de Réglage.....	C11
Mise en Mémoire de Modes Vidéo	C12
Quelques Conseils en Cas D'incident	C13
Spécifications D'entree.....	C14

ITALIANO

Introduzione	D1
Collegamento del Monitor	D2
Utilizzo dell'USB (Universal Serial Bus).....	D3
Posizione e Funzione dei Conandi di Controllo	D5

Funzione del Pannello di Controllo	D6
Controllo Regolazione On Screen Display (OSD)....	D8
Elementi di Selezione e Regolazione dell'OSD ...	D9
Suono di Selezione e Regolazione	D11
Modalità di Memoria Video	D12
In Caso di Problemi.....	D13
Specifiche	D14

ESPAÑOL

Introducción	E1
Conectando del Monitor	E2
Utilización del USB (Bus de serie universal)	E3
Ubicación y Funcion de los Controles.....	E5
Función del Panel de Control.....	E6
Ajuste del Control de Exhibición en Pantalla (OSD).....	E8
Ajuste del OSD y Selección de Elementos.....	E9
Ajuste del Sonido y Selección de Elementos	E11
Modos de Memoria de Video	E12
Sugerencias para Localizar las Fallas	E13
Especificaciones.....	E14

PORTUGUÊS

Introdução	F1
Conectando o Monitor.....	F2
Utilização de USB (Universal Serial Bus)	F3
Posição dos Controles e Descrição	F5
Funções do Painel de Controle	F6
Ajuste On Screen Display(OSD).....	F8
Ajustes OSD e Itens de Seleção	F9
Ajustes Som e Seleção	F11
Modos de Memória de Vídeo	F12
Resolvendo Problemas	F13
Especificações.....	F14

NEDERLANDS

Inleiding.....	N1
De Monitor Aansluiten.....	N2
Gebruikmaken van de USB (Universele Seriele Bus)	N3
De plaatsing en de werking van de knoppen	N5
Het bedieningspaneel.....	N6
Bediening via het beeldscherm OSD (On Screen Display)	N8
Kiezen en instellen via het OSD-systeem	N9
Selectie en aanpassing van het geluid	N11
Modi voor videogeheugen	N12
Problemen oplossen	N13
Specificaties.....	N14

FCC Warning

Class B Computing Device

Information to the User

This equipment has been tested and found to comply with the limits for a class B digital device pursuant to part 15 of FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help and for additional suggestions.

The user may find the following booklet prepared by the Federal Communications Commission helpful: "How to Identify and Resolve Radio-TV Interference Problems." This booklet is available from the U.S. Government Printing Office, Washington, D.C. 20402, Stock No. 004-000-00345-4.

FCC Warning

The user is cautioned that changes or modifications not expressly approved by the manufacturer could void the user's authority to operate the equipment.

NOTE: In order for an installation of this product to maintain compliance with the limits for a Class B device, shielded cables must be used.

Introduction

Thank you for purchasing a high resolution monitor. It will give you high resolution performance and convenient reliable operation in a variety of video operating modes.

ENGLISH

Features


- The monitor is a 17 inches (16.0 inches viewable) intelligent, microprocessor based monitor compatible with most analog RGB (Red, Green, Blue) display standards, including IBM PC*, PS/2*, Apple*, Macintosh*, Centris*, Quadra*, and Macintosh II family.
- We accomplished to adapt the fusion design and technology to the monitor. Soft touch buttons on the front panel are simple and allow you to conveniently adjust a variety of image controls. The absolute flat screen and screen surface treatment eliminate distracting glares.
- USB(Universal Serial Bus) ports at the side of the monitor are prepared for the USB cable and hub. You can easily and flexibly connect USB - designed devices-such as a mouse, keyboard or printer- to the monitor for true Plug and Play function.
- This monitor provides audio function. Thanks to built in audio function in the speaker, you can easily separate speakers from the monitor and place them where you want.
- Digitally controlled auto-scanning is done with the micro-processor for horizontal scan frequencies between 30 and 70kHz, and vertical scan frequencies between 50-160Hz.
- This monitor is capable of producing a maximum horizontal resolution of 1280 dots and a maximum vertical resolution of 1024 lines.
- Plug and play capability if supported by your system.
- This monitor has DDC 2B function.*
- Compliant with the following regulated specifications :*
 - EPA ENERGY STAR
 - Swedish MPR II
 - Swedish TCO '95

**For detailed information, please refer to the Reference Guide provided .*

Connecting the Monitor

To set up the monitor, ensure that the power is turned off to the monitor, computer system, and other attached devices, then follow these steps:

- 1 Connect the speakers as described in below picture.
- 2 Connect the 15 pin VGA connector of the supplied signal cable to the output VGA video connector on the PC and the matching input connector on the rear of the monitor. The connectors will mate only one way. If you cannot attach the cable easily, turn the connector upside down and try again. When mated, tighten the thumbscrews to secure the connection.
- 2 Locate the appropriate MAC to VGA adapter block at your local computer store. This adapter changes the high density 3 row 15 pin VGA connector to the correct 15 pin 2 row connection to mate with your MAC. Attach the other end of the signal cable to the side of the adapter block with 3 rows.
Connect the attached adapter block/signal cable to the video output on your MAC.
- 3 One end of the AC power cord is connected into the AC power connector on the back of the monitor. The other end is plugged into a properly grounded three-prong AC outlet.
- 4 Power ON the PC, then the monitor.
- 5 If you see the **SELF DIAGNOSTICS** message, check the signal cable and connectors.
- 6 After using the system, power OFF the monitor, then the PC.






* **NOTE** : For Apple Macintosh use, a separate plug adapter is needed to change the 15 pin high density (3 row) D-sub VGA connector on the supplied cable to a 15 pin 2 row connector.

Making use of USB (Universal Serial Bus) Feature


USB (Universal Serial Bus) is an innovation in connecting your different desktop peripherals conveniently to your computer. By using the USB, you will be able to connect your mouse, keyboard, printer, and other peripherals to your monitor instead of having to connect them to your computer. This will give you greater flexibility in setting up your system. USB allows you to connect chain up to 120 devices on a single USB port, and you can “hot” plug (attach them while the computer is running) or unplug them while maintaining Plug and Play auto detection and configuration. This monitor has an integrated self-powered USB hub, allowing up to 4 other USB devices to be attached it.

USB connection

1. Connect the upstream port of the monitor to the downstream port of the USB compliant PC or another hub using the USB cable (Computer must have a USB port).
2. Connect the USB compliant peripherals to the downstream ports of the monitor.



Making use of USB (Universal Serial Bus) Feature




- NOTE**
- To activate the USB hub function, the monitor must be connected to a USB compliant PC(OS) or another hub with the USB cable(enclosed),
 - When connecting the USB cable, check that the shape of the connector at the cable side matches the shape at the connecting side.
 - When the monitor is not plugged into an electric socket, the peripherals connected to the downstream ports will not operate.
 - Even if the monitor is in a power saving mode, USB compliant devices will function when they are connected the USB ports(both the upstream and downstream) of the monitor.

USB specifications


USB standard	Rev. 1.1 complied self-powered hub
Downstream power supply	500mA for each (MAX)
Communication speed	12 Mbps (full), 1.5 Mbps (low)
USB port	1 Upstream port 4 Downstream ports

Location and Function of Controls

Front View











Rear View



Control Panel Function

Front Panel Controls




Control	Function
 Sound Menu	To adjust sound menu.
 Sound Mute	Used to select mute on (means sound off) and mute off (means sound on).
 MIC	Built-in Microphone.
 OSD Button	Use this button to enter or exit the on screen display.
 ▲▼/◀▶ Button	Use these buttons to choose or adjust items in the on screen display.
 SET Button	Use this button to enter a selection in the on screen display.
 Power ON/OFF Button	Use this button to turn the monitor on or off.
Power (DPMS) Indicator	This Indicator lights up green when the monitor operates normally. If the monitor is in DPM (Energy Saving) mode (stand-by/suspend/power off), this indicator color changes to amber.



Left Side Jacks

Headphone Jack	Headphone Jack that automatically mutes the speaker volume when headphone is attached.
Speaker Jack	Used to connect the speaker(supplied).

Rear Panel Jacks



Mic. Out	Connects microphone sound to PC via cable.
Audio In	Connects speaker sound to PC via cable attachment.

Audio Features

A major feature of this monitor is its built-in audio system. This conveniently integrates a stereo audio amplifier and speakers without taking up any more space. Because the monitor is designed like this, you can easily upgrade to audio capable multimedia applications by attaching your PC with sound card to the back of this monitor. It will result in significantly less cabling and space requirements.


On Screen Display (OSD) Control Adjustment

Making adjustments to the image size, position and operating parameters of the monitor are quick and easy with the On Screen Display Control system. A quick example is given below to familiarize you with the use of the controls. Following section is an outline of the available adjustments and selections you can make using the OSD.

NOTE

- Allow the monitor to stabilize for at least 30 minutes before making image adjustment.





To make adjustments in the On Screen Display, follow these steps:






- 1** Press the **OSD Button**, then the main menu of the OSD appears.
- 2** To access a control, use the **▲** or **▼** Buttons. When the icon you want becomes highlighted, press the **SET Button**.
- 3** Use the **▲▼/◀▶** Buttons to adjust the item to the desired level.
- 4** Accept the changes by pressing the **SET Button**.
- 5** Exit the OSD by Pressing the **OSD Button**.

On Screen Display(OSD) Selection and Adjustment

You were introduced to the procedure of selection and adjusting an item using the OSD system. Listed below are the icons, icon names, and icon descriptions of the items that are shown on the Menu.

OSD Adjust	Description
 <p>The OSD menu for BRIGHTNESS CONTRAST shows a central sun icon with a value of 66 and a slider between 0 and 100. Below it is a contrast icon with a value of 100 and a slider between 0 and 100. A vertical menu on the left contains icons for RGB, PRESET, TEMP, RED, GREEN, BLUE, and a star icon.</p>	<p>Brightness Used to adjust the brightness of the screen.</p> <p>Contrast Adjust the display to the contrast desired.</p>
 <p>The OSD menu for COLOR shows PRESET options for 6500K and 9300K. Below are sliders for TEMP, RED, GREEN, and BLUE. A vertical menu on the left contains icons for RGB, PRESET, TEMP, RED, GREEN, BLUE, and a star icon.</p>	<p>PRESET 6500K/ 9300K To appear the displays color temperature. • 6500K:Slightly reddish white. • 9300K:Slightly bluish white.</p> <p>TEMP User easily color set without adjustment Red, Green and Blue (R/G/B).</p> <p>RED To set your own color levels.</p> <p>GREEN To set your own color levels.</p> <p>BLUE To set your own color levels.</p>
 <p>The OSD menu for POSITION shows a central image with a value of 66 and a slider between 0 and 100. Below it is a horizontal position icon with a value of 45 and a slider between 0 and 100. A vertical menu on the left contains icons for RGB, PRESET, TEMP, RED, GREEN, BLUE, and a star icon.</p>	<p>Vertical Position To move image up and down.</p> <p>Horizontal Position To move picture image left and right.</p>
 <p>The OSD menu for SIZE shows a central image with a value of 49 and a slider between 0 and 100. Below it is a horizontal size icon with a value of 64 and a slider between 0 and 100. A vertical menu on the left contains icons for RGB, PRESET, TEMP, RED, GREEN, BLUE, and a star icon.</p>	<p>Vertical Size To adjust image height.</p> <p>Horizontal Size To adjust image width.</p>


On Screen Display(OSD) Selection and Adjustment

OSD Adjust	Description
	<p>Side Pincushion To correct the bowing in and out of the image.</p> <p>Side pincushion balance To correct the balance of both sides bowling.</p> <p>Trapezoid To correct geometric distortion.</p> <p>Parallelogram This control adjusts for a skewing of the screen image.</p> <p>Tilt To correct image rotation.</p> <p>Corner Top To correct the irregular distortion of the displayed image.</p> <p>Corner Bottom To correct the irregular distortion of the displayed image.</p>
	<p>VIDEO LEVEL This item is used to select the monitor's input signal level. The normal level used for most PC's is 0.7V. When the screen suddenly gets brightened or blurry, please select 1.0V and try again.</p> <p>DDC To select the DDC function(ON/OFF).</p> <p>LANGUAGE To choose the language in which the control names are displayed.</p> <p>OSD POSITION To adjust position of the OSD window on the screen.</p> <p>BEEP To select beep ON or OFF.</p>
	<p>DEGAUSS To manually demagnetize the screen which may show some image or color incorrectly.</p> <p>RECALL If the monitor is operating in a factory preset mode, this control will reset the image to the factory preset mode.</p> <p>MOIRE This item allows you to reduce the moire (Moire is caused by interference Horizontal Scan Line with the periodical dot screen). It is normally OFF(H:0/V:0). The moire adjustments may affect the focus of the screen. The screen image may shake slightly while the moire reduction function is on.</p> <p>PURITY Use to adjust the overall purity of the image if the color appears uneven.</p>

Sound Selection and Adjustment

You were introduced to the procedure of selection and adjusting an item using the OSD system. Listed below are the icons, icon names, and icon descriptions of the items that are shown on the main Menu.

To make adjustments in the On Screen Display, follow these steps:



OSD Adjust	Description
	VOLUME Raises or lowers audio level.
	TREBLE Raises or lowers treble level.
	BASS Raises or lowers Bass level.
	BALANCE Changes balance of left/right speaker level.
	MICROPHONE Enables or disables microphone usage.

Video Memory Modes

The monitor has 36 memory locations for display modes, 11 of which are factory preset to popular video modes.

Display Modes (Resolution)

	Display Modes (Resolution)	Horizontal Freq.(kHz)	Vertical Freq.(Hz)
1	VESA 640 x 480	37.50	75
2	VESA 800 x 600	46.88	75
3	VESA 800 x 600	53.68	85
4	VESA 1024 x 768	68.677	85
5	VESA 640 x 400	31.47	70
6	VESA 640 x 480	31.47	60
7	VESA 800 x 600	37.88	60
8	VESA 640 x 480	43.27	85
9	MAC 832 x 624	49.75	75
10	VESA 1024 x 768	60.02	75
11	VESA 1280 x 1024	63.98	60

User Modes

- Modes 12-36 are empty and can accept new video data. If the monitor detects a new video mode that has not been present before or is not one of the preset modes, it stores the new mode automatically in one of the empty modes starting with mode 12.

If you use up the 25 blank modes and still have more new video modes, the monitor replaces the information in the user modes starting with mode 12.

Recalling Display Modes

- When your monitor detects a mode it has seen before, it automatically recalls the image settings you may have made the last time you used that mode.

You may, however, manually force a recall of each of the 11 preset modes by pressing the Recall button. All preset modes are automatically recalled as the monitor senses the incoming signal.

The ability to recall the preset modes is dependent on the signal coming from your PC's video card or system. If this signal does not match any of the factory modes, the monitor automatically sets itself to display the image.

Troubleshooting

Check the following before calling for service.

SELF DIAGNOSTICS message.

- The signal cable is not connected, or is loose. Check and secure the connection.

OUT OF FREQUENCY message appears.

- The frequency of the signal from the video card is outside the operating range of the monitor.

* Horizontal Frequency : 30-70kHz

* Vertical Frequency : 50-160Hz

Use the graphics board's utility software to change the frequency setting (Refer to the manual for graphics board).

The power LED is illuminated amber.

- Display power management mode.
- There is no active signal coming from the PC.
- The signal cable is not fastened securely.
- Check the computer power and graphics adapter configuration.

The image on the SCREEN is not centered, or too small, or not a rectangle shape.

- Image adjustment not been done yet in the current operating mode. Use the OSD, SET and Δ / ∇ / \leftarrow / \rightarrow buttons to set the image to your liking.

The monitor doesn't enter the power saving off mode (Amber).

- Computer video signal is not VESA DPMS standard. Either the PC or the video controller card is not using the VESA DPMS power management function.

An abnormal picture is displayed on the screen. For example, the upper part of the picture may be missing or dark.

- If using certain non-VESA Standard video card, an abnormal picture may be displayed. Try setting it to one of the factory preset modes, or selecting to a resolution and refresh rate within the specification limits of the monitor.

NOTE

- If the power indicator(LED) light is blinking amber, may result in abnormal condition of the monitor.
- Then press a power ON/OFF button on the front panel control and call your service technician for more information.

Specifications

Picture Tube	17 inch (16.0 inches viewable)	
	90 degree deflection	
	0.24mm Slot pitch	
	W-ARAS(Wide Anti-Reflective Anti-Static) coating	
Sync Input	Horizontal Freq.	30 - 70kHz (Automatic)
	Vertical Freq.	50 - 160Hz (Automatic)
	Input Form	Separate TTL, Positive/Negative
	Signal Input	15 pin D-Sub Connector
Video Input	Input Form	Separate, RGB Analog, 0.7Vp-p/75 ohm, Positive
	Resolution(max)	1280 x 1024@60Hz
Audio	RMS Audio Output	6W (R+L)
	Input Sensitivity	0.7 Vrms
	Built-in MIC	E.C.M type (Electret Condenser Microphone)
	Speaker Impedance	4Ω
Power Consumption	Normal(Max.)	≤ 125W
	Stand-by/Suspend	≤ 30W
	Power Off	≤ 8W
Dimensions (with tilt/ swivel stand)	Width	43.7 cm / 17.2 inches (without speaker)
		69.2 cm / 27.2 inches
	Height	46.3 cm / 18.2 inches
	Depth	41.6 cm / 16.4 inches
Power Input	Europe	AC 200-240V 50Hz 1.5A
	Others	AC 100-240V 50/60Hz 2.0A
The products should be used according to the Power requirements of each ID LABEL.		
Weight	Net	19 kg (41.9 lbs)
Environmental Conditions	Operating Condition	
	Temperature	10 °C to 40 °C
	Humidity	10 % to 90 % non-Condensing
	Storage Condition	
	Temperature	0 °C to 60 °C
	Humidity	5 % to 90 % non-Condensing

NOTE

- Information in this document is subject to change without notice and does not represent a commitment on the part of LG Electronics Inc.