

| LSP-430 | USER GUIDE

Please read this manual carefully before operating your set.
Retain it for future reference.

LIMITED WARRANTY STATEMENT

1. WHAT THIS WARRANTY COVERS:

LG offers you a limited warranty that the enclosed subscriber unit and its enclosed accessories will be free from defects in material and workmanship, according to the following terms and conditions:

- (1) The limited warranty for the product extends for ONE (1) year beginning on the date of purchase of the product.
- (2) The limited warranty extends on to the original purchaser of the product and is not assignable or transferable to any subsequent purchaser/end user.
- (3) This warranty is good only to the original purchaser of the product during the warranty period as long as it is in the U.S., including Alaska, Hawaii, U.S. Territories and Canada.
- (4) The external housing and cosmetic parts shall not be covered under these limited warranty terms.
- (5) Upon request from LG, the consumer must provide information to reasonably prove the date of purchase.
- (6) The customer shall bear the cost of shipping the product to the Customer Service Department of LG. LG shall bear the cost of shipping the product back to the consumer after the completion of service under this limited warranty.

2. WHAT THIS WARRANTY DOES NOT COVER:

- (1) Defects or damages resulting from use of the product in other than its normal and customary manner.
- (2) Defects or damages from abnormal use, abnormal conditions, improper storage, exposure to moisture or dampness, unauthorized modifications, unauthorized connections, unauthorized repair, misuse, neglect, abuse, accident, alteration, improper installation, or other acts which are not the fault of LG, including damage caused by shipping blown fuses spills of food or liquid.
- (3) Breakage or damage to antennas unless caused directly by defects in material or workmanship.
- (4) That the Customer Service Department at LG was not notified by consumer of the alleged defect or malfunction of the product during the applicable limited warranty period.
- (5) Products which have had the serial number removed or made illegible.
- (6) The limited warranty is in lieu of all other warranties, express or implied either in fact or by operations law, statutory or otherwise, including, but limited to any implied warranty of marketability or fitness for a particular use.
- (7) Damage resulting from use of non-LG approved accessories.
- (8) All plastic surfaces and all other externally exposed parts that are scratched or damaged due to normal customer use.
- (9) Products operated outside published maximum ratings.
3
- (10) Products used or obtained in a rental program.
- (11) Consumables (such as fuses).

3. STATE LAW RIGHTS:

No other express warranty is applicable to this product. THE DURATION OF ANY IMPLIED WARRANTIES, INCLUDING THE IMPLIED WARRANTY OF MARKETABILITY, IS LIMITED TO THE DURATION OF THE EXPRESS WARRANTY HEREIN. LG INFOCOMM INC. SHALL NOT BE LIABLE FOR THE LOSS OF THE USE OF THE PRODUCT, INCONVENIENCE, LOSS OR ANY OTHER DAMAGES, DIRECT OR CONSEQUENTIAL, ARISING OUT OF THE USE OF, OR INABILITY TO USE, THIS PRODUCT OR FOR ANY BREACH OF ANY EXPRESS OR IMPLIED WARRANTY, INCLUDING THE IMPLIED WARRANTY OF MARKETABILITY APPLICABLE TO THIS PRODUCT. Some states do not allow the exclusion of incidental or consequential damages or limitations on how long an implied warranty lasts; so these limitations or exclusions may not apply to you. This warranty gives you specific legal rights and you may also have other rights which vary from state to state.

4. HOW TO GET WARRANTY SERVICE:

To obtain warranty service, please call the following web address:

www.lgeservice.com

For Your Safety

Important Information

This user guide contains important information on the use and operation of this phone. Please read all the information carefully for optimal performance and to prevent any damage to or misuse of the phone. Any changes or modifications not expressly approved in this user guide could void your warranty for this equipment.

Before You Start

Safety Instructions

WARNING! To reduce the possibility of electric shock, do not expose your phone to high humidity areas, such as the bathroom, swimming pool, etc.

Always store your phone away from heat. Never store your phone in settings that may expose it to temperatures less than 32°F or greater than 104°F, such as outside during extreme weather conditions or in your car on a hot day. Exposure to excessive cold or heat will result in malfunction, damage and/or catastrophic failure.

Be careful when using your phone near other electronic devices. RF emissions from your mobile phone may affect nearby in adequately shielded electronic equipment. You should consult with manufacturers of any personal medical devices such as pacemakers and hearing aides to determine if they are susceptible to interference from your mobile phone.

Turn off your phone in a medical facility or at a gas station. Never place your phone in a microwave oven as this will cause the battery to explode.

IMPORTANT! Please read the TIA SAFETY INFORMATION on page 78 before using your phone.

Safety Information

Read these simple guidelines. Breaking the rules may be dangerous or illegal. Further detailed information is given in this user guide.

- ▶ Never use an unapproved battery since this could damage the phone and/or battery and could cause the battery to explode.
- ▶ Never place your phone in a microwave oven as it will cause the battery to explode.
- ▶ Do not dispose of your battery by fire or with hazardous or flammable materials.
- ▶ Make sure that no sharp-edged items come into contact with the battery. There is a risk of this causing a fire.
- ▶ Store the battery in a place out of reach of children.
- ▶ Be careful that children do not swallow any parts such as rubber plugs (earphone, connection parts of the phone, etc.). This could cause asphyxiation or suffocation.

- ▶ Unplug the power cord and charger during lightning storms to avoid electric shock or fire.
- ▶ When riding in a car, do not leave your phone or set up the hands-free kit near to the air bag. If wireless equipment is improperly installed and the air bag is activated, you may be seriously injured.
- ▶ Do not use a hand-held phone while driving.
- ▶ Do not use the phone in areas where its use is prohibited. (For example: aircraft).
- ▶ Do not expose the battery charger or adapter to direct sunlight or use it in places with high humidity, such as a bathroom.
- ▶ Never store your phone in temperatures less than -4°F or greater than 122°F.
- ▶ Do not use harsh chemicals (such as alcohol, benzene, thinners, etc.) or detergents to clean your phone. There is a risk of this causing a fire.
- ▶ Do not drop, strike, or shake your phone severely. Such actions may harm the internal circuit boards of the phone.
- ▶ Do not use your phone in high explosive areas as the phone may generate sparks.
- ▶ Do not damage the power cord by bending, twisting, pulling, or heating. Do not use the plug if it is loose as it may cause a fire or electric shock.
- ▶ Do not place any heavy items on the power cord. Do not allow the power cord to be crimped as it may cause fire or electric shock.
- ▶ Do not handle the phone with wet hands while it is being charged. It may cause an electric shock or seriously damage your phone.
- ▶ Do not disassemble the phone.
- ▶ Do not place or answer calls while charging the phone as it may short-circuit the phone and/or cause electric shock or fire.
- ▶ Only use the batteries, antennas, and chargers provided by LG. The warranty will not be applied to products provided by other suppliers.
- ▶ Only authorized personnel should service the phone and its accessories. Faulty installation or service may result in accidents and consequently invalidate the warranty.
- ▶ Do not hold or let the antenna come in contact with your body during a call.
- ▶ An emergency call can be made only within a service area. For an emergency call, make sure that you are within a service area and that the phone is turned on.

FCC RF Exposure Information

WARNING! Read this information before operating the phone. In August 1996, the Federal Communications (FCC) of the United States, with its action in Report and Order FCC 96-326, adopted an updated safety standard for human exposure to radio frequency (RF) electromagnetic energy emitted by FCC regulated transmitters. Those guidelines are consistent with the safety standard previously set by both U.S. and international standards bodies.

The design of this phone complies with the FCC guidelines and these international standards.

CAUTION

Use only the supplied and approved antenna. Use of unauthorized antennas or modifications could impair call quality, damage the phone, void your warranty and/or result in violation of FCC regulations. Do not use the phone with a damaged antenna. If a damaged antenna comes into contact with skin, a minor burn may result. Contact your local dealer for a replacement antenna.

Body-worn Operation

This device was tested for typical body-worn operations with the back of the phone kept 0.79 inches (2.0cm) between the user's body and the back of the phone. To comply with FCC RF exposure requirements, a minimum separation distance of 0.79 inches(2.0cm) must be maintained between the user's body and the back of the phone. Third-party belt-clips, holsters, and similar accessories containing metallic components should not be used. Body-worn accessories that cannot maintain 0.79 inches(2.0cm) separation distance between the user's body and the back of the phone, and have not been tested for typical body-worn operations may not comply with FCC RF exposure limits and should be avoided.

**Vehicle Mounted External Antenna
(optional, if available)**

A minimum separation distance of 8 inches (20cm) must be maintained between the user/bystander and the vehicle mounted external antenna to satisfy FCC RF exposure requirements. For more information about RF exposure, visit the FCC website at www.fcc.gov

Cautions for Battery

- ▶ Do not disassemble.
- ▶ Do not short-circuit.
- ▶ Do not expose to high temperature: 60°C (140°F).]
- ▶ Do not incinerate.

Battery Disposal

- ▶ Please dispose of your battery properly or bring to your local wireless carrier for recycling.
- ▶ Do not dispose in fire or with hazardous or flammable materials.

Adapter (Charger) Cautions

- ▶ Using the wrong battery charger could damage your phone and void your warranty.
- ▶ The adapter or battery charger is intended for indoor use only.

Do not expose the adapter or battery charger to direct sunlight or use it in places with high humidity, such as the bathroom.

Highlights

Congratulations on your subscription to the LSP-430 Fixed Wireless Phone. This phone has been designed to operate on the IS-2000 Air Protocol over the 800MHz band. And the phone has the advanced user interface similar to mobile phone. It has greatly enhanced voice clarity and provides various advanced features.

Key phone features:

- ▶ 2-line text + 1 Icon line LCD Display. Yellow/Green LCD backlight.
- ▶ 32 Polyphonic Ring tones: Choose from 10 melodies and 5 bell sounds.
- ▶ Large Phone Book with 300 entries.
- ▶ Speed Dialling for up to 300 numbers.
- ▶ The phone can store up to 30 Missed, 30 Received, 30 Dialed calls, and 30 In Call Memo in Call History.

- ▶ 3 Way call conferencing.
- ▶ SMS features.
- ▶ Last number redial.
- ▶ Hands free Speaker Phone.
- ▶ Receiver Off-Hook tone.
- ▶ Adjustable Ring volume, Key volume, Earpiece volume, and Speaker volume.
- ▶ Fast charging battery.

1. Introduction	4
1.1 Front View of the Phone	4
1.2 LCD Display	5
1.3 Installation	6
1.4 Installation Steps	9
2. Basic Operation	10
2.1 Making a Call	10
2.2 Messaging	10
2.3 Redialing Last Number	10
2.4 3-way Call Conferencing	11
2.5 Call Wait	11
2.6 Volume Control	11
2.7 Receiving a Call	12
2.8 Memo	12
2.9 Lock Mode	12
2.10 Entering and Editing Information	13
3. Menu Tree	14
3.1 PHONE BOOK	17
3.2 MESSAGES	18
3.3 CALL HISTORY	21
3.4 SOUND	24

3.5 DISPLAY	25
3.6 SETTINGS	26
3.7 ORGANISER	30
4. Speaker Phone	32
5. Troubleshooting	33
6. Important Information	34
6.1 Safety Instruction	34
6.2 Optimal Phone Performance	34
6.3 Care and Service	35
6.4 Safety Information	36
7. General Information	39
7.1 Main Unit	39
7.2 AC/DC Adapter	39
7.3 Battery	40
Limited Warranty Statement	41
Appendix FCC RF Exposure Information	45
LGE Service Center List	46


1. Introduction

1.1 Front View of the Phone

- ① Menu : Activates Main Menu state.
- ② Clear : Deletes the last digit, or moves previous Menu.
- ③ OK : Used to store an entry or to accept a command.
- ④ Message : Activates SMS Menu state.
- ⑤ Up Key (▲) : Moves up in the Menu or Volume Up.
- ⑥ Down Key (▼) : Moves down in the Menu or Volume Down.
- ⑦ END/PWR : Deactivates states, or Power ON/OFF.
- ⑧ Redial/Flash : Activates Redial/Flash state, or views Call History.
- ⑨ (📞) : Activates hands free (📞) function.
- ⑩ MIC
- ⑪ '*': Inputs Symbol '*', or makes a phone input 'space' during text entry operation.
- ⑫ '#': Inputs Symbol '#', or makes a phone lock after long-press.
- ⑬ Attached Antenna.

1.2 LCD Display



The LCD shows icons on the top of the LCD screen. Different indicators appear based on the phone's operating mode.



Icon	Operating Condition
	RSSI indicator: Indicates the signal strength in the service area.
	No service: The phone is not receiving any system signal.
	In use: Displayed when a call is in progress or the phone is in off-hook state.
	Text message: Displayed when a text message is received.
	Voice message: Displayed when voice message is received.
	Alarm: Displayed when alarm time is set.
	Incoming Call Indicator : Displayed when the Incoming Call is received.
	Not used.
	Battery charge level: Indicates charged battery level.

1.3 Installation

You should follow each step carefully as shown below in order to guarantee the proper operation of CDMA Fixed Wireless Phone.



STEP I. Check Components

▶ The following components are supplied Fixed Wireless Phone.

1. LSP-430 Main Phone with Handset (Including inner backup battery) -1 EA-
2. Dipole Antenna -1 EA-
3. AC/DC Power Adapter -1 EA-
4. User Guide -1 EA-

▶ Please make sure that these components are present before you begin to install the phone. If any of the components are missing or damaged, contact your service provider immediately.

STEP II. Place the Terminal

- ▶ Place the phone on the stable flat surface area (desk, table, etc). Serious damage may result if the phone is dropped. Do not place the phone within 1 meter of heaters or radiators.
- ▶ This phone is designed for desktop usage. Avoid the direct exposure to sunlight and dampness.

▶ Read the SAFETY INFORMATION located in the first part of this document before you lace the phone.

STEP III. Connect Components (Please refer to “Installation Steps” in 1.4)

- ▶ Connect the antenna to the TNC antenna connector located at the top of the phone.
- ▶ If you have placed the phone on a flat surface, position the antenna upright.
- ▶ Connect the curl cord of the handset to the RJ-11 port located on the left side of the phone.
- ▶ Connect the AC/DC Adapter cable to the DC input port located at the top of the phone.
 - If it is correct, a beep tone will be heard.
 - If it is not correct (Booting fails or beep tone is not heard), you will have to reconnect the adapter or reset the battery switch to “on”.
- ▶ Please observe the following to get better voice quality.


1. Keep away from electrical appliances such as TV, computer, radio etc.
2. Keep the phone in a high and central location without any obstructions.
3. Raise the integral antenna of the phone to get maximum strength as shown in the figure.

STEP IV. Check the LCD Display


- ▶ After you follow the installation instruction step I to step III, please check the LCD for normal operation.
- ▶ If you do not see the status of service, please repeat the 4th instruction of step III.
- ▶ Then confirm the status of phone to get the proper signal strength from the service operator system.

1.4 Installation Steps


Please follow the procedure below to install the phone properly.



Connect basehandset to the handset connector.



Connect the antenna to the TNC connector (Turn right).



Turn the antenna upright.



Connect the AC power supply.



Press END/PWR button to operate initially.

Basic Operation

2. Basic Operation

2.1 Making a Call

You can make a call as follows:

1. Pick up the handset or press **Power** button.
 2. Listen for dial tone.
 3. Enter the phone number with area code if needed.
 4. Wait for the Auto Time-out or Press **Redial/Flash** button.
 5. The call is connected and you may start conversation.
 6. To disconnect the call, replace the handset or press **Power** button.
- ※ When the user presses the **Redial/Flash** button after dialing any desired number, if the user picks up the handset or presses the **Power** button, the phone makes a call immediately.

2.2 Messaging

You can send or receive a short message. If you want to send SMS, press button **Message** button + 1 (**Write**) in on-hook state and write message that you want and send your message. When the message received in idle state or during a call, you can confirm your message as follows.

1. Press **Message** button + 2 (**Inbox**).
2. Press **OK** key to confirm desired message.

2.3 Redialing Last Number

You can make a redial to last number, shown in All Calls.

1. Pick up the handset or press **Power** button.
2. Listen for dial tone.
3. Press **Redial/Flash** button.
4. The call is connected and you may start conversation.

5. To disconnect the call, replace the handset or press **Power** button.

- ※ You can also dial any of the last 120 (Missed+Received+Dialled+In Call Memo) numbers stored in All Calls.

2.4 3-way Call Conferencing

You can start tripartite conversation.

Method 1

1. Enter the phone number of the 2nd party phone while you are in telephonic conversation with 1st party.
2. Press **Redial/Flash** button. And press **Redial/Flash** button again.

Method 2

1. Press **Redial/Flash** button while you are in telephonic conversation with 1st party.
2. If you listen to the dialing tone, Press the phone number of the 2nd party phone.

Basic Operation

3. Press **Redial/Flash** button.

And press **Redial/Flash** button again.

This service should be provided by your service provider.

2.5 Call Wait

While a call is in progress, you may hear two beeps indicating another incoming call. When call wait is enabled, you may put the active call on hold while you answer the other incoming call.

1. Press **Redial/Flash** button, you may start conversation with called number.
2. Re-press **Redial/Flash** button, you may start conversation with previous number.

2.6 Volume Control

1. Press **Up/Down** button of navigation while in a call, to adjust speaker volume.

Basic Operation

2. Press **Menu** + 1 (**Mute/Unmute**) to prevent sound from your end during the call. To cancel Mute, Press again **Menu** + 1 (**Mute/Unmute**).
3. Press **Menu** + 4 (**MIC Level**) during a call and select Low or High by pressing **Up/Down** button, to adjust MIC volume.

2.7 Receiving a Call

When the bell rings in idle state, you can receive a call as follows:

1. Pick up the handset or press the **📞** button.
2. Start a conversation.
3. To disconnect the call, replace the handset or press the **📞** button.

2.8 Memo

Allow you to store number during the call.

To store number:

1. Press **Menu** + 2 (**Memo**).
2. Enter up to 32 numbers using the keypad.
3. Press **OK** key to save.

To retrieve an In Call Memo:

1. Press **Redial/Flash** button to see saved number.

Note: You can store the number by pressing **OK** key.

2.9 Lock Mode

Keeps your phone from unauthorized use. Once the phone is locked, it is in restricted mode, until the in lock code is entered. This will allow you to receive phone calls and still make emergency calls. The lock code on your phone is "0000" by default.

If you need to modify the lock code, you may modify it using the **New Lock Code** within the security

Menu. You can lock your phone using the '#' (**🔒** :Lock) key, also you can lock your phone manually.

Lock Mode

1. Press '#' button for some time. The phone is now locked.
2. To unlock, press **Menu** .
3. Enter lock code. (Default "0000").

2.10 Entering and Editing Information

You can edit the phone book and short messages using various text input mode.

Key Functions

- Message key : Press to select a character mode(ABC, abc, Sym1, Sym2) in edit state.
- **⌘** SPACE key : Press to insert a space.
- Clear key : Press to delete a single space or character. Press and hold to delete entire words.

Basic Operation

Input Mode

Text Input provides four modes for entering text, special characters, and punctuation.

- ABC / abc Mode : Use ABC or abc mode to input text in English.
 - ⇒ ABC Mode : All subsequent letters are capitalized.
 - ⇒ abc Mode : All subsequent letters are lowercase.
- Sym1 / Sym2 Mode : Insert special characters and punctuation. You may use any of the special characters. When the special characters are displayed, you can select the number corresponding to the character that you want to input.
- For number entry, first select the key button you want to input in ABC / abc mode and then press the key button until the number is displayed.

3. Menu Tree

Main Menu	Sub-Menu	Setting Value
1. PHONE BOOK	1. Find	1. Address / 2. Name / 3. Number
	2. Add	Number / Name / Address / Secret
	3. Erase All	Yes / No
2. MESSAGES	1. Write	Number / Contents
	2. Inbox	CALL FORWARD / CALL WAIT / CALL TIMER
	3. SMS 8282	1. What's New? / 2. Jokes / 3. News / 4. Astrology / 5. Win Prizes / 6. LifeStyle / 7. More
	4. Outbox	OK / EDIT
	5. Voice Mail	For 10 Secounds / For 30 Secounds / Always On / Always off
	6. Erase Messages	1. Inbox & Voice / 2. Outbox / 3. All Messages
	7. MSG Settings	1. Priority / 2. Delivery ACK / 3. Defer Delivery / 4. Valid Period / 5. Save Sent MSG / 6. Auto Del. Inbox
3. CALL HISTORY	1. All Call	View / Erase / Save Number
	2. Missed	View / Erase / Save Number

Main Menu	Sub-Menu	Setting Value
	3. Received	View / Erase / Save Number
	4. Dialed	View / Erase / Save Number
	5. In Call Memo	View / Erase / Save Number
	6. Call Duration	1. Last Dialed / 2. All Dialed / 3. All Calls / 4. Reset
4. SOUND	7. Erase History	1. Erase All Call / 2. Erase Missed / 3. Erase Received 4. Erase Dialed / 5. Erase Memo
	1. Ring Type	Ring / One-Beep / Light
	2. Ring Tone	15 ea (Midi 10 + Bell 5)
	3. Ring Volume	4 Steps (1-4)
	4. Ear Volume	4 Steps (1-4)
	5. Key Volume	5 Steps (0-4)
	6. Message Alert	1. Alert Type / 2. Alert Tone / 3. MSG Reminder
5. DISPLAY	1. Banner	1. My Banner / 2. Banner On/Off
	2. Clock Type	Type-A_AM/PM / Type-A_24Hour / Type-B_AM/PM / Type-B_24Hour
	3. Backlight	For 10 Seconds / For 30 Seconds / Always On / Always Off

Main Menu	Sub-Menu	Setting Value
6. SETTINGS	1. Phone	1. Auto Time-Out / 2. Speed Dialing / 3. DTMF Length / 4. Version / 5. My Number
	2. Calling	1. Call Divert / 2. Call Waiting / 3. Call Timer
	3. Security	1. Lock Phone / 2. Emergency No / 3. New Lock Code 4. Restrict Call / 5. Hot Line / 6. Hot Line Time
7. ORGANISER	1. Alarm	1. Set Time / 2. Set Ringer

3.1 PHONE BOOK

This function allows you to search the phone number in three way (Address, Name, Number), which you have stored in the phone book memory.

Up to 300 entries can be listed here.

To store phone number:

1. Enter the area code and phone number (Max. 32 digits) in on-hook state.
 2. Press **OK** key
 3. Enter the name. Refer to the 2.10 Entering and Editing Information about text input.
 4. Enter the desired memory location.
 5. The phone will display a message asking you whether to keep your number as secret or not. Select **No** or **Yes** using **Up/Down** button and press **OK** key.
- ⇒ You will see a confirmation message and the status of memory used.

3.1.1 Find

To find phone numbers you have stored in the Phone Book.

1. Press **MENU** + 1 (**PHONE BOOK**) + 1 (**FIND**) in on-hook state.
2. Select a desired search Menu.
⇒ Address, Name, Number : Enter full or part of name(number), select **OK**.
3. Select desired item.
⇒ **OK** key : can edit item.
⇒ **Message key** : can delete item.

3.1.2 Add

You can save up to 300 entries in your LSP-430 phonebook.

1. Press **MENU** + 1 (**PHONE BOOK**) + 2 (**Add**) in on-hook state.

2. Enter the information (Number, Name, Memory Location).

3.1.3 Erase All

You may erase all phonebook items.

1. Press **Menu** + 1 (**PHONE BOOK**) + 3 (**Erase All**) in on-hook state.
2. Select **Yes/No** and press **OK** key.

3.2 MESSAGES

Text messaging, page and voice mailbox become available as soon as the power is on.

You may access the above type of messages using the Message key. The phone can store up to 50 messages in each Inbox and Outbox.

If you press **Message** Key, SMS Menu is activated.

At any point of time, to return to the initial screen, press **END/PWR** button and to return to the previous screen, press **Clear** button.

In the list of Inbox, all sorts of the icon have the meaning as follows:

! : Unread message

V : Read message

Press **Menu** + 2 (**Message**) in on-hook state to access messages. In Inbox, the meaning of (5/37) beside Inbox is that 5 out of 37 messages are unread.

3.2.1 Write

This function allows you to compose and send message.

1. Press **Message** + 1 (**Write**) in on-hook state.
2. Enter phone number or press **Message** to search from phone book or call history.
3. Write messages. Refer to the 2.1.0 Entering and Editing Information about text input.
4. Press **OK** key to send message.

3.2.2 Inbox

Received messages are stored here.

1. Press **Message** + 2 (**Inbox**) + in onhook state.
2. To view desired message, select **OK** .
3. To delete desired message, select **Message** key.
4. Press **Menu** to reply, forward, erase a message or save the sender's number in the phone-book. Select 1. **Reply** , 2. **Forward** , 3. **Save Number** , or 4. **Erase** using **Up/Down** button.

3.2.3 SMS 8282

Exciting SMS-based Infotainment services such as News, Jokes, Astrology etc are available to TATA subscribers. Using the SMS 8282 services, the user will be able to access interesting information on common subjects through SMS. User needs to send Keyword in specified format to 8282 to access these services.

1. Press **Message** + 3 (**SMS8282**) in on-hook state.
2. You may select from seven items (1. What's New? / 2. Jokes / 3. News / 4. Astrology / 5. Win Prizes / 6. Lifestyle / 7. More)
3. You may select the number corresponding to the item that you want to send in subsequent-menu.

3.2.4 Outbox

All your successfully sent messages are saved here.

1. Press **Message** + 4 (**Outbox**) in on-hook state.
2. To delete desired message, select **Message** key.
3. To view or edit desired message, select **OK** key.

3.2.5 Voice Mail

Voice Mail notifications indicate the number of new voice messages in your mailbox.

Only the most recent voice mail notification will be stored in your phone, previous message will be overwritten.

1. Press **Message** + 5(**Voice Mail**) in on-hook state.
2. Pick up the handset or press **Ⓜ** button to make a call back your voice mailbox if the number of the voice mailbox is provided by the telecom service company's system.

3.2.6 Erase Messages

This function allows you to erase all messages.

1. To delete all received and voice messages, Press **Message** + 6(**Erase Messages**) + 1(**Inbox & Voice**) in on-hook state.

2. To delete all sending messages, Press **Message** + 6(**Erase Messages**) + 2(**Outbox**) in on-hook state.
3. To delete all messages, Press **Message** + 6(**Erase Messages**) + 3(**All Messages**) in on-hook state.

3.2.7 MSG Settings

Priority

1. Press **Message** + 7(**MSG Settings**) + 1(**Priority**) in on-hook state.
2. You may select from four options (Normal / Interactive / Urgent / Emergency).

Delivery ACK

1. Press **Message** + 7(**MSG Settings**) + 2(**Delivery ACK**) in on-hook state.
2. Select **On** or **Off** .

Defer Delivery

1. Press **Message** + 7(**MSG Settings**) + 3(**Defer Delivery**) in on-hook state.
2. Select one of the following.
(**Immediate/After 30 Min./After 1 Hour/After 2 Hours/After 12 Hours/After 1 Day/After 2 Days**)

Valid Period

1. Press **Message** + 7(**MSG Settings**) + 4(**Valid Period**) in on-hook state.
2. Select one of the following.
(**Default/30 Minutes/1 Hour/2 Hours/12 Hours/1 Day/2 Days**)

Save Sent MSG

1. Press **Message** + 7(**MSG Settings**) + 5(**Save Sent MSG**) in on-hook state.
2. Select **On** or **Off** .

Auto Del. Inbox

1. Press **Message** + 7(**MSG Settings**) + 2(**Auto Del. Inbox**) in on-hook state.
2. Select **On** or **Off** .

3.3 CALL HISTORY

The phone can store up to 30 Missed, 30 Received, 30 Dialed calls, and 30 In Call Memo in Call History.

When you press the button, all calls are displayed. In the list of all calls, all sorts of the icons have the meaning as follows :

- Received : ←
- Dialed : →
- Missed : !
- In call Memo : ↵
- Call Waiting : →
- Call Conferencing : **G**

3.3.1 All Call

[In on-hook state]

1. Press **Menu** + 3(**CALL HISTORY**) + 1(**All Call**) or **Redial/Flash** button.
2. Press **Up/Down** button to select a number or name in the Call history list.
3. To view desired item, press **OK** key.
4. To erase desired number, press **Message** key.
5. After you press **OK** key, press **Message** key to see more information and press **OK** key to save the number in the phone book.

3.3.2 Missed

1. Press **Menu** + 3(**CALL HISTORY**) + 2(**Missed**) in on-hook state.
2. Press **Up/Down** button to select a number or name in the missed call list.

3. To view desired item, press **OK** key.
4. To erase missed call, press **Message** key.
5. After you press **OK** key, press **Message** key to see more information and press **OK** key to save the number in the phone book.

3.3.3 Received

1. Press **Menu** + 3(**CALL HISTORY**) + 3(**Received**) in on-hook state.
2. Press **Up/Down** button to select a number or name in the received call list.
3. To view desired item, press **OK** key.
4. To erase received call, press **Message** key.
5. After you press **OK** key, press **Message** key to see more information and press **OK** key to save the number in the phone book.

3.3.4 Dialed

1. Press **Menu** + 3(**CALL HISTORY**) + 4(**Dialed**) in on-hook state.
2. Press **Up/Down** button to select a number or name in the dialed call list.
3. To view desired item, press **OK** key.
4. To erase dialed number, press **Message** key.
5. After you press **OK** key, press **Message** key to see more information and press **OK** key to save the number in the phone book.

3.3.5 In Call Memo

1. Press **Menu** + 3(**CALL HISTORY**) + 5(**In Call Memo**) in on-hook state.
2. Press **Up/Down** button to select desired item in the In Call Memo list.
3. To view desired item, press **OK** key.

4. To erase In Call Memo, press **Message** key.
5. After you press **OK** key, press **Message** key to see more information and press **OK** key to save the number in the phone book.

3.3.6 Call Duration

Last Dialed

You may confirm last dialed call duration.

1. Press **Menu** + 3(**CALL HISTORY**) + 6(**Call Duration**) + 1(**Last Dialed**) in on-hook state.

All Dialed

You may confirm all dialed call duration.

1. Press **Menu** + 3(**CALL HISTORY**) + 6(**Call Duration**) + 2(**All Dialed**) in on-hook state.

All Calls

You may confirm all calls duration.

1. Press **Menu** + 3(**CALL HISTORY**) + 6(**Call Duration**) + 3(**All Calls**) in on-hook state.

Reset

You may erase all calls duration.

1. Press **Menu** + 3(**CALL HISTORY**) + 6(**Call Duration**) + 4(**Reset**) in on-hook state.

3.3.7 Erase History

You may erase all history from five options (1: Erase All Call, 2: Erase Missed, 3: Erase Received, 4: Erase Dialed, 5: Erase Memo).

1. Press **Menu** + 3(**CALL HISTORY**) + 6(**Erase History**) in on-hook state.

2. Select history that you want to erase and press **OK** key.

3.4 SOUND

This menu let you choose your phone's sound settings(volume and ring type) to your environment.

3.4.1 Ring Type

1. Press **Menu** + 4(**SOUND**) + 1(**RING TYPE**) in on-hook state.
2. Select one of the following.
(Ring / One-Beep / Light)

3.4.2 Ring Tone

1. Press **Menu** + 4(**SOUND**) + 2(**Ring Tone**) in on-hook state.
2. Select from Bell / Melody.

3.4.3 Ring Volume

1. Press **Menu** + 4(**SOUND**) + 3(**Ring Volume**) in on-hook state.
2. Change using **Up/Down** key.

3.4.4 Ear Volume

1. Press **Menu** + 4(**SOUND**) + 4(**Ear Volume**) in on-hook state.
2. Change using **Up/Down** key.

3.4.5 Key Volume

1. Press **Menu** + 4(**SOUND**) + 5(**Key Volume**) in on-hook state.
2. Change using **Up/Down** key.

3.4.6 Speaker Volume

1. Press **Menu** + 4(**SOUND**) + 6(**Speaker Volume**) in on-hook state.
2. Change using **Up/Down** key.

3.4.7 Message Alert

1. Press **Menu** + 4(**SOUND**) + 7(**Message Alert**) in on-hook state.
2. Select from Alert Type(**Ring/One-Beep/Light/Off**) / Alert Tone(**SMS Alarm 1~5**) / MSG Reminder(**Once/Every 2 Min/Off**).

3.5 DISPLAY

Lets you personalize your phone's display by selection of various display setting like banner, clock type, and backlight.

3.5.1 Banner

Allow you to choose the settings of the LCD banner.

1. If you want to edit banner, press **Menu** + 5(**DISPLAY**) + 1(**Banner**) + 1(**My Banner**) + **OK** key in on-hook state.
2. If you want to activate or deactivate the banner, press **Menu** + 5(**DISPLAY**) + 1(**Banner**) + 2(**Banner On/Off**) in on-hook state.
And select from **On** or **Off**.

3.5.2 Clock Type

You can select time format for your phone.

1. Press **Menu** + 5(**DISPLAY**) + 2(**Clock Type**) in on-hook state.
2. Select from **Type-A_AM/PM**, **Type-A_24Hour**, **Type-B_AM/PM**, or **Type-B_24Hour**.

3.5.3 Backlight

Allows you to choose the settings of the LCD backlight.

1. Press **Menu** + 5(**DISPLAY**) + 3(**Backlight**) in on-hook state.
2. Select among **Always Off** / **For 10 Seconds** / **For 30 Seconds** / **Always On**.

3.6 SETTINGS

3.6.1 Phone

Auto Time-Out

Setting the length of time the phone waits before automatically dialing a number. You can select this duration to be between 2 and 9 seconds.

1. Press **Menu** + 6(**SETTINGS**) + 1(**Phone**) + 1(**Auto Time-Out**) in on-hook state.
2. Press **Up/Down** button to select Auto Time Out between (2~9 Sec.).
3. Press **OK** key to select.

Speed Dialing

This function allows you to make a call faster by just pressing a corresponding number. Up to 300 memory locations can be assigned for speed dial. To speed dialing press the memory number (1 through 300) corresponding to the appropriate memory location and hold for a few seconds.
⇒ This function can be used when the speed dialing is set to enable.

1. Press **Menu** + 6(**SETTINGS**) + 1(**Phone**) + 2(**Speed Dialing**) in on-hook state.
2. Press **Up/Down** button to select Enable or Disable.
3. Press **OK** key to save and exit.

DTMF Length

This function allows you to the setting of Key beep playback length. Possible settings are **Short** and **Long**.

1. Press **Menu** + 6(**SETTINGS**) + 1(**Phone**) + 3(**DTMF Length**) in on-hook state.

2. Press **Up/Down** button to select **Short** or **Long**.
3. Press **OK** key to select.

Version

You can confirm your phone S/W version.

1. Press **Menu** + 6(**SETTINGS**) + 1(**Phone**) + 4(**Version**) in on-hook state.
2. To confirm next page, press **Message** key and press **OK** key to exit.

My Number

You can confirm and edit your phone number.

1. Press **Menu** + 6(**SETTINGS**) + 1(**Phone**) + 5(**My Number**) in on-hook state.
2. To modify your phone number, press **OK** key. Enter the phone number, and press **OK** key to save and exit.

3.6.2 Calling

Call Divert

Call Divert lets you forward your incoming calls to another number.

1. Press **Menu** + 6(**SETTINGS**) + 2(**Calling**) + 1(**Call Divert**) in on-hook state.
2. Select from **All Voice Call / If Busy / If Not Answerd / Disable All**. Disable All deactivates the already activated call divert option.
3. Select **Enable** or **Disable**. If you are select **Enable**, enter another phone number and press **OK** key.

⇒ You would need to call “121” to get this service activated.

Call Waiting

While a call is in progress, you may hear two beeps indication another incoming call.

When call wait is enabled, you can put the activate call on hold while you answer the other incoming call.

1. Press **Menu** + 6(**SETTINGS**) + 2(**Calling**) + 2(**Call Waiting**) in on-hook state.

2. Select **Enable** or **Disable**.

⇒ You would need to call “121” to get this service activated.

Call Timer

This function allows you to select call timer indication.

1. Press **Menu** + 6(**SETTINGS**) + 2(**Calling**) + 3(**Call Timer**) in on-hook state.
2. Press **Up/Down** button to select **Enable** or **Disable**.
3. Press **OK** key to save and exit.

3.6.2 Calling

1. Press **Menu** + 6(**SETTINGS**) + 3(**Security**) in on-hook state.
2. Enter password. (Default “0000”)

Lock Phone

1. Press **Menu** + 6(**SETTINGS**) + 3(**Security**) + 1(**Lock Phone**) in on-hook state.
2. Press **Up/Down** button to select **Enable** or **Disable** and press **OK** key.

Emergency No

Emergency number can store up to three numbers. (Default 100, 101, 102)

1. Press **Menu** + 6(**SETTINGS**) + 3(**Security**) + 2(**Emergency No**) in on-hook state.
2. To edit a number, press **OK** key.

New Lock Code

New Lock Code allows you to enter a new four-digit lock code.

1. Press **Menu** + 6(**SETTINGS**) + 3(**Security**) + 3(**New Lock Code**) in on-hook state.
2. Enter the new four-digit lock code that you want and press **OK** key.
3. Verify new lock code and press **OK** key.

Restrict Call

You can restrict your outgoing calls including numbers / numbers beginning with specified digit in the Black List.

For example: If “9” is stored in the Black List, all number beginning with “9” cannot be called. However if “92” is stored in White List, you can call numbers beginning with “92” successfully.

1. Press **Menu** + 6(**SETTINGS**) + 3(**Security**) + 4(**Restrict Call**) in on-hook state.

2. Select among **No Restriction**, **Restriction** or **Emergency Only** and press **OK** key.
3. If **Restriction** is selected,
 - Enter the numbers / starting digit of specific numbers to be restricted in the **Black List**.
 - Enter the number / starting digits of the numbers to be allowed in the **White List**.
 - Press **OK** key to save and press **Clear** or **END/PWR** key to exit.
4. If **Emergency Only** is selected, your phone is enabled for only emergency numbers.
(Default **100, 101, 102**)

Hot Line

Hot Line automatically calls to registered number by passing setup time in off-hook state.

1. Press **Menu** + 6(**SETTINGS**) + 3(**Security**) + 5(**Hot Line**) in on-hook state.
2. Select **Enable** or **Disable** and press **OK** key.

3. If **Enable** is selected, press **OK** key and enter the hotline number.

Hot Line Time

1. Press **Menu** + 6(**SETTINGS**) + 3(**Security**) + 6(**Hot Line Time**) in on-hook state.
2. Press **Up/Down** button to select Hot line connection time (2~9 Sec).
3. Press **OK** key to select.

3.7 ORGANISER

3.7.1 Alarm

Set Time

This function allows you to set alarm time.

1. Press **Menu** + 7(**ORGANISER**) + 1(**Alarm**) + 1(**Set Time**) in on-hook state.
2. Press **Up/Down** button to select from off, once or always and press **OK** key.

3. Press **OK** key to enter alarm time and press **Message** key to select AM or PM.
4. Press **OK** key to save and exit.

Set Ringer

This function allows you to select ringer for alarm alert.

1. Press **Menu** + 7(**ORGANISER**) + 1(**Alarm**) + 1(**Set Ringer**) in on-hook state.
2. Press **Up/Down** button to select from Alarm Ring 1~5.
3. Press **OK** key to save and exit.

4. Speaker Phone

This function is a convenient feature, which enables you to make a call using the **Speaker Phone** (🔊) button in on-hook state.

5. Troubleshooting

Please check the following items before contacting service center.

Item	Remedy
Phone doesn't operate at all.	<ul style="list-style-type: none">• Check that the phone is installed correctly.• Check that the battery is fully charged.• Check that the power is on.
Because of noise and cross talking, call status is bad.	Keep away from electrical application such as TV, computer, radio and so on.
When I press button to call, can't hear the dial tone.	Check that phone cord or power is connected correctly.
Phone does not switch on.	Check that the battery is fully charged and correctly connected to the phone.
Calls cannot be received.	Check incoming calls may be barred.
Emergency calls cannot be made.	Check that the antenna symbol is displayed- Move to the coverage area and operate your phone when the antenna symbol is displayed.
Battery fails to charge.	Ensure that adapter is approved LSP-430 adapter and ON/OFF switch is on.
Bell sound isn't heard.	If bell sound is low, please adjust the volume level.

Important Information

6. Important Information

6.1 Safety Instruction

WARNING / CAUTION

To reduce the risk of fire or electric shock, do not expose this unit to rain or moisture. Do not use this unit in swimming pools or other water bodies.

6.2 Optimal Phone Performance

- ▶ Do not hold the antenna when operating the unit, or operate the unit when someone is within four inches (ten centimeters) of the antenna. Both cases affect the call quality and may cause the phone to operate at a higher power level than required.
- ▶ For the best call quality, keep the antenna free from obstructions and position the antenna upright.
- ▶ Do not use the unit if the antenna is damaged. Get the damaged antenna replaced through a qualified technician. Use only a manufacturer-approved antenna.

Non-approved antennas, modifications or attachments may impair call quality and damage the unit.

- ▶ RF (Radio Frequency) energy may affect improperly installed or inadequately shielded personal medical devices such as pace-makers or hospital monitors. Consult the manufacturer of any personal medical devices to determine whether they are adequately shielded from external RF energy. Turn your unit OFF in health care centers if any regulations posted in the area instruct you to do so. Hospitals or health care centers may be using equipment that may be sensitive to external RF energy.
- ▶ If this unit causes harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
 - Reorient or relocate the receiving antenna.
 - Place the radio or television farther away from the unit.

- Connect the equipment to an outlet on a circuit different from that to which the unit is presently connected.
- Consult the Authorized LGE Dealer for assistance of an experienced radio/TV technician.
- ▶ Use battery, antenna and AC power supply provided by LGE. Using spares made by any other manufacturer may invalidate the warranty.
- ▶ Only authorized personnel should service the unit and its accessories. Faulty installation or service can be dangerous and may invalidate the warranty.
- ▶ Do not use the unit in any designated "no cellular phone use" area.
- ▶ Avoid using the unit in high temperature or humidity.
- ▶ Avoid spilling any liquid on the unit. If the unit gets wet, turn the power off immediately and remove the backup battery and AC power supply. If the unit doesn't work, please contact service provider immediately.
- ▶ Avoid shock or impact.
- ▶ We recommend you to charge the backup battery before initial use. The backup battery may be discharged during delivery.

Important Information

6.3 Care and Service

Before cleaning, always unplug the unit from the wall outlet and remove the antenna (or disconnect the antenna cable). Do not use liquid or aerosol cleaners; use a damp cloth for cleaning.

If the unit doesn't work, do not attempt to disassemble it; contact the phone service agent for assistance.

If any of the following conditions exist, unplug the unit from the wall plug, remove the battery and call a qualified technician.

- ▶ The power supply cord is damaged or frayed.
- ▶ Liquid has spilled into the unit.
- ▶ The unit has been exposed to rain or water.
- ▶ The unit has been dropped or damaged.
- ▶ The unit does not function normally even after following the operating instructions.

Important Information

6.4 Safety Information

WARNING



- ▶ For safety, use only an adapter approved by LG.

LG does not bear responsibility for any faults that may arise due to non-conformance to this guide.



- ▶ Do not, in any way, cause a short-circuit. It may start a fire or the unit may explode causing injury.



- ▶ Do not create a sudden impact on the battery by throwing it. Do not dispose of batteries by putting them in a fire. They may explode or catch fire due to the electrolyte within.



- ▶ Do not use the unit with a car battery. It may cause electric shock, fire, breakdown or transformation.



- ▶ Avoid using the unit in high temperature or humidity. Avoid spilling any liquid on this unit. If the unit gets wet, turn the power off immediately and remove the backup battery and AC power supply.



- ▶ Keep the unit dry. Submersion, humidity and liquids containing minerals may corrode internal electronic circuits.



- ▶ Do not store or use the unit in dusty or dirty areas as this can damage the moving parts.



- ▶ Do not store the unit in hot areas. High temperatures can shorten the life of electronic devices, damage batteries, and

CAUTION



- ▶ Do not store the unit in cold areas. When the unit warms up to its normal operating temperature, moisture can form inside the unit, which can damage the internal electronic circuit boards.



- ▶ Do not attempt to open it. Non-expert handling of the device could damage it. It may cause fire, electric shock and breakdown. Consult your authorized LG dealer for assistance.



- ▶ Do not drop, knock or shake the unit. Rough handling may break the internal circuit boards.



- ▶ Do not use harsh chemicals, cleaning solvents or strong detergents to clean the unit. Wipe it with a soft cloth that has been slightly dampened in a mild soap and water solution.

warp or melt certain plastics.

Important Information



- ▶ Do not paint the unit. Paint can clog the device's moving parts and prevent proper functioning.



- ▶ During lightning, do not touch the power plug or the phone line. It may result in an electric shock or death.



- ▶ Do not install the unit under direct sunlight or on an uneven surface.



- ▶ Before using the plug, check the available power voltage. Inaccurate power voltage may cause fire and damage.




- ▶ Do not plug many power cords into one outlet. It may cause fire or electric shock.

Important Information



▶ Do not remodel the power cord or disassemble it. If the power cord or plug is impaired, do not use it. It may cause fire or electric shock.



▶ Do not install the unit in an ill-ventilated place. It may cause fire or a breakdown.



▶ Do not touch the plug with wet hands. When disconnecting the power cord of any accessory, grasp and pull out the plug itself and not the cord. It may cause fire or electric shock.



▶ Do not put heavy objects on the power cord. Do not bend the power cord too much. It may cause fire or electric shock.



▶ Use only an LG-approved battery or adapter. If not, it may cause an explosion or result in a short-circuit. LG does not bear any responsibility for the damage.



▶ When you disconnect the power cord of any accessory, grasp and pull the plug itself and not the cord. It may cause the adapter to breakdown.

General Information

7. General Information

7.1 Main Unit

Item	LSP-430
Tx Frequency	Digital: 824 ~ 849 MHz
Rx Frequency	Digital: 869 ~ 894 MHz
Channel Bandwidth	1.25 MHz
Tx Power	Digital: LOWER: 0.2W ~ UPPER:1W
Rx Sensitivity	-104 ~ -25dBm
Size (mm)	177.5(W) X 159.5(D) X 69.2(H) (with handset)
Weight (gms)	614 gram (with Ni-MH Battery)
Operating Temperature	-10 ~ 50° C

7.2 AC/DC Adapter

Item	SMPS Type Description
Rated Input Voltage	AC 100 ~ 240V
Operating Input Voltage	AC 80 ~ 420V
Rated Input Frequency	50 / 60Hz
Operating Input Frequency	47 ~ 63Hz
Rated Output Voltage, Current	12V(DC), 0.5A/5V(DC), 1A

7.3 Battery

Item	Description
Capacity	3.6V Ni-Mh / 1,00mAh(3.6V Li-ion/1,400mAh)
Talk time / Standby time	4 Hours / 120Hours (2.5Hours/80Hours)
Charging time duration	3.5 Hours

Limited Warranty Statement

LG ELECTRONICS Inc. represents and warrants that this subscriber unit and its accessories ('PRODUCT') is free from defects in material and workmanship.

This warranty is subject to the following terms and conditions;

1. This warranty of the PRODUCT extends for a period of 12 months commencing from the date of purchase or 15 months from the date of manufacture whichever is less, except for the battery, for which the warranty is 6 months from the date of purchase or 9 months from the date of manufacture whichever is less.
2. During the warranty period, LG ELECTRONICS Inc. or its authorized service network will repair or replace, at LG

ELECTRONICS Inc.'s option, the PRODUCT or any relevant parts thereof in the event that the PRODUCT is found to be defective.

The repaired PRODUCT or the Product/part provided as a replacement for a defective PRODUCT/part, shall be free from defects. The END USER/consumer purchaser of the PRODUCT or his/her assignee ('CONSUMER') shall not be charged (whether for parts, labour or otherwise) for the repair or replacement of a defective PRODUCT during the warranty period. All replaced parts, boards or equipment shall become the property of LG ELECTRONICS Inc.

3. The warranty in respect of a repaired or replaced PRODUCT/part shall extend for

Limited Warranty Statement

the remaining warranty period of the repaired PRODUCT or replacement thereof to the CONSUMER.

4. Upon request from LG ELECTRONICS Inc., the CONSUMER may be required to provide the purchase receipt or other documentation or information in respect of the date and place of purchase.

5. The CONSUMER shall have no coverage or benefits under this warranty in the event that any of the following conditions are applicable:

(a) The PRODUCT has been subject to abnormal use or conditions, improper storage, exposure to excessive moisture or dampness, exposure to excessive temperatures, unauthorized modifications, unauthorized repair (including but not

limited to use of unauthorized spare parts in repairs), abuse, accident, Acts of God, spills of food or liquids, improper installation and breakage or damage to antennae (otherwise than by reason of any defects in material or workmanship).

(b) LG ELECTRONICS Inc. has not been notified by the CONSUMER of the defects of the PRODUCT during the applicable warranty period.

(c) The PRODUCT serial number code or the accessory date code has been removed, defaced or altered.

(d) The PRODUCT has been used with or connected to an accessory (i) not supplied by LG ELECTRONICS Inc. or its affiliates, (ii) not fit for use with the PRODUCT or (iii) used otherwise than in

the manner intended.

(e) The seals of the PRODUCT'S battery enclosure have been broken or show evidence of tampering or the PRODUCT'S battery has been used in equipment other than that for which it has been specified usable by LG ELECTRONICS Inc.

(f) All plastic surfaces and all other externally exposed parts that are scratched or damages due to normal customer use.

(g) Breakage or damage to antenna unless caused by defects in material or workmanship.

6. In order to derive benefits of this warranty in respect of any defects in the PRODUCT, the CONSUMER shall ship the PRODUCTS or part thereof at its cost to the authorized service center of LG ELECTRONICS Inc. LG

Limited Warranty Statement

ELECTRONICS Inc. shall bear the cost of shipping the PRODUCT or part thereof back to the CONSUMER after the completion of the service under this limited warranty.

NO OTHER EXPRESS WARRANTY IS APPLICABLE TO THIS PRODUCT. THE DURATION OF ANY IMPLIED WARRANTIES, INCLUDING THE IMPLIED WARRANTY OF MARKETABILITY OR MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE OR USE IS LIMITED TO THE DURATION OF THE EXPRESS WARRANTY HEREIN. LG ELECTRONICS Inc. SHALL NOT BE LIABLE FOR THE LOSS OF USE OF THE PRODUCT, INCONVENIENCE, LOSS OR ANY OTHER CONSEQUENTIAL DAMAGE, ARISING

Limited Warranty Statement

OUT OF THE USE OF, OR INABILITY OF USE, OF THIS PRODUCT OR FOR BREACH OF ANY EXPRESS OR IMPLIED WARRANTY, INCLUDING THE IMPLIED WARRANTY OF MARKETABILITY OR MERCHANTABILITY OR FITNESS APPLICABLE TO THIS PRODUCT.

7. It is hereby expressly clarified that all warranties (express or implied) in respect of the PRODUCT are provided by LG ELECTRONICS Inc. alone.

Appendix FCC RF Exposure Information

Appendix FCC RF Exposure Information

WARNING!

The antenna used for this transmitter must not exceed 3.0dBi and must be installed to provide a minimum separation distance of 20 cm from all persons.

CAUTION

Use only the supplied and approved antenna. Use of unauthorized antennas or modifications could impair call quality, damage the phone, void your warranty and/or result in violation of FCC regulations. Do not use the phone with a damaged antenna. If a damaged antenna comes into contact with skin, a minor burn may result.

Contact your local dealer for a replacement of antenna.

FCC Part 15 Class B Compliance

This device and its accessories comply with part 15 of FCC rules. Operation is subject to the following two conditions:

- (1) This device and its accessories may not cause harmful interference, and (2) this device and its accessories must accept any interference received, including interference that may cause undesired operation.

LGE Service Center List

LGE Service Center List

Sr	Circle	City Name	ASCs	Address Person	Contact	Phone
1	Andhra Pradesh	Guntur	Vasavi Associates	Door no 6-20-4, Swamalak complex, 4/1 Arandtal Pet, Guntur-522003	Mr. Satyam	0863-2233678, 9848105789, 09394155554
2	Andhra Pradesh	Hydrabad	Sri Varun Electronics	D.No 5-8-344/1, " DHAN BHAGYA ESTATE ", Chirag Ali Lane, Abids, Next to Raghava Ratna Towers, Hyderabad- 500 001	Mr. Raghavendra	040-55781999, 040-55253888, 040-56878822, 09391001463
3	Andhra Pradesh	Hydrabad	JVR Infotech Pvt Ltd	Shop No 8, Vanijya Vihar, Nalanda Building, Dilsukh Nagar Main Road, Hyderabad-500060	EV Ramakanth	040-24161848, 040-55109604, 040-56524157, 09391131067, 040-36060606
4	Andhra Pradesh	Hydrabad	S V Electronics	Shop No. 41, Nilagiri Block, Aditya Enclave, Ameerpet Main Road, Hyderabad-500038	Mr. Vanktेशwara Rao	040-55754477/ 55343030
5	Andhra Pradesh	Hydrabad	Reliable Communication	G-8, 3-6-561, AALTO'S A & M Trade Centre, HIMAYATNAGAR, HYDERABAD - 500029	Mr. Mahesh Heda	04030913251, 09346320705, 09849251173
6	Andhra Pradesh	Hydrabad	Shweta Communciations	Shop No.9, Ground Floor, Pavani Ansuya Complex, Opp. Huda Complex, Tarnaka, Hyderabad	Mr. Sandeep Heda	040-55918841, 040-55918842, 09346698606
7	Andhra Pradesh	Kurnool	R K LG CDMA	#40-37-J1, Opp. Indian Bank, Near Balaji Hotel, Kurnool- 518002.	Mr.Paraveen Krishna	08518-220201, 09393810688
8	Andhra Pradesh	Nellore	Siri Enterprises	Opp. Archana Theater, A C Centre, Nellore PIN-524001	Mr. Paraveen	09398309571, 09347000000
9	Andhra Pradesh	Rajamund-hary	Siri Infotech	Police Welfare Complex, City Hospitals Junction, Danvai Pet Main Road, Rajhamundry-533103	Mr. Raghvendra	0883-2421567, 09397925799
10	Andhra Pradesh	Secundrabad	Shweta Computers	# 1-7-69/1 & 2, OPP Aditya Delux Hotel, Near Paradise circle Sarojini Devi Road, Secunderabad - 500003	Mr. Jagdish	040-55334180, 040-27721076,

LGE Service Center List

Sr	Circle	City Name	ASCs	Address Person	Contact	Phone
						09396532358, 09391041673
11	Andhra Pradesh	Tirupathi	CMT Computer Services	18-1-624 VV Mahal Road, OPP HDFC BANK, Tirupathi, PIN-517501	Mr. K Vasu Naidu	0877-5561979, 09393620209
12	Andhra Pradesh	Vijaywada	K L Computer House	39-9-46 SVS Temple Street, Labbipet, Vijaywada PIN- 520 010	Mr. Kartik	0866-5520461, 5671461, 09392105222
13	Andhra Pradesh	Visakhapa-tnam	GVS Enterprises	G5, Ground Floor, Backside of Sangam-Sarat Theatre, 1st Lane, Dwarka Nagar, Visakhapatnam - 530 016.	Mr. Satish Kumar	0891-2598610, 9394206074
14	Andhra Pradesh	Warrangal	S S Marketers	6-1-73/1, Sai Bhavan, Sri Devi Theatre Road, Hanamkonda, Warrangal-506001	Mr. L.Srinivas Rao	0870-2552223, 09390100708
15	Andhra	Kakinada	Delta Infotech	Pradesh Door No. 6-1-29, Opp. Swami Vivekananda Park, Jawahar Street, Surya Rao Pet, Kakinada - 533001	Mr. Shivanand	0884-5593533 9346846009
16	Bihar	Patna Company	Infotek Trading	1st floor, City Palace, New Dak Bunglow Road, Patna-800001	Sanjay Chowbey	0612-2227166
17	Bihar	Patna	Competent Mobile Service	Shop 1, Hotel Lalitha Complex, East Bowring Canal Road, Patna	Mohit Ahluwalia	9334022706
18	Delhi	Delhi	Comhard Systems	D-30, 31, First floor, Near Hotel Shipra, Main Vikas Marg, Lakshmi Nagar	Mr. Ravi Kant Gupta	011-30955887, 9818867678
19	Delhi	Delhi	Innovative Telecom	305, Aggarwal Millenium Tower, Netaji Subash Place, Pitam Pura, Delhi-110088	Mr. Manoj Garg	011-55154343, 9811682453, 011-30925753
20	Delhi	Delhi	Sagar Technologies	W-8, First Floor, Main Patel Road, West Patel Nagar, New Delhi - 110008	Mr. Deepak / Mr. Amit	9810320170, 011-55433100
21	Delhi	Delhi	Sagar Technologies	J-39, Central Mkt, Lajpat Nagar-II, New Delhi-110024	Mr. Prabhat	011-55425644, 011-55425645
22	Delhi	Delhi	Ucom Technologies Pvt Ltd.	45, 1st Flr, Corner Mrkt, Malviya Nagar, New Delhi - 110017	Bhuwan Chandra	011-26675900, 55655382, 09313088818
23	Delhi	Delhi	Nice Telecommunica-tion	15/23, First Floor, DDA Complex, Nangal raya, D Block, Janakpuri, Delhi - 110046	Anurag	011-28521044, 9810778310

LGE Service Center List

Sr	Circle	City Name	ASCs	Address Person	Contact	Phone
24	Delhi	Delhi Telecom	Touch Tone	B-52, First Floor, Kalkaji, New Delhi	Ashish Dey	011-30939031
25	Delhi	Delhi	Cube Engineers and Consultants Pvt Ltd	A-65, Naraina Industrial Area, Phase-1, New Delhi	Atul Gupta	09312224103, 011-55450272, 51411623
26	Delhi	Delhi	Comhard Systems	B-120, Hardev Puri, 100 Feet Main Road, Near MTNL Office, Nathu Colony Chowk, Shahdra, New Delhi - 110 093.	Mr. Ravi Kant Gupta	011-39572430, 011-39572427
27	Delhi	Delhi	R K Communications	2516 Hudson Lines, Kingsway Camp-Nr. Kamla Nagar , New Delhi	Mr.Pradeep Aggarwal	011-39508861
28	Delhi	Delhi	Arham Infotech Services	1/1, Regal Building, Near Malik Sweets, Connaught Place, New Delhi - 110 001.	Mr.Anil Surana	9350286361 9350286361
29	Gujarat	Ahmedabad	Visual Enterprises	104, Saarthak Complex, behind Urja House, Swastik Char Rasta, Navrangpura, Ahmedabad-380009	Vallabh Patel	079-26463305, 09376171851
30	Gujarat	Ahmedabad	Silicon Valley	F/6,Silver lake, Jagabhai Park, Rambaug Road, Maninagar, Ahmedabad-380008	Rajesh Patel	079-5430634, 9824025430
31	Gujarat	Ahmedabad Communication	Mishree	75,Management Enclave, Opp. Indraprastha Bungalows, Vastrapur, Ahmedabad.	Mitesh Patel	9327037582, 079-55314224, 9327800611
32	Gujarat	Ahmedabad	ACom Technologies	Shop No-40, 1st Floor, Shubh Complex, Near Rajasthan Hospital, Camp Road, Shahibaug, Ahmedabad-380004	Vijay.S.Gohel	9824544230, 079-30940560
33	Gujarat	Bhavnagar	Teletext Gold	G/8,Radheshyam Complex,Radha Mandir,Vaghavadi Road,Bhavnagar-364001	Nilesh Bagadia	0278-2415545, 9824497766
34	Gujarat	Gandhinagar	Creative Communications	Shop No 102, Suman City, Sector 11, Gandhinagar-382011	K.J.Barot	079-23226241, 9825059590
35	Gujarat	Jamnagar	Sudarshan Infosys	3, Prema Building, Cricket Bungalow-3, Indira Nagar, Jamnagar	Amit Unadkat	0288-2552696, 9824478203
36	Gujarat	Rajkot	Roopang infocare	Vinod Nivas, 4, Sardarnagar(West), Nr Astron Cinema, Rajkot-360001	Kalpesh Rugani	0281-2464485, 09374103622, 9824068880
37	Gujarat	Surat	Excel Solutions	G-48, Ascon Plaza, Anand Mahal Road, Adajan Surat-395009	Nitesh Jain	0261-5544500, 09327344500, 9825399870

LGE Service Center List

Sr	Circle	City Name	ASCs	Address Person	Contact	Phone
38	Gujarat	Surat	Omsai Services	37,Golden Point, Near Science Laboratory, Ring Road, Surat -3940003	Dharmesh Patel	0261-5593716, 9374710610, 9825406129
39	Gujarat	Vadodra	Aashnik Infotech	F 50,National Plaza, R.C.Dutt Road, Alkapuri, Vadodara-390005	Aashish Parmar	0265-3112123, 3090969, 9327230793
40	Gujarat	Vapi	Klassik Statino Products	116,Bhanudarshan Co-Op Society, Koparli Road, Near Gunjan Cinema, GDC, Vapi	Avishek Suhasana	0260-3092363, 9377000911
41	Haryana	Ambala	Bee Ess Aar Communication	92-93, Gandhi market, Ambala Cantt-133001	Rajiv Gupta	0171-2641234, 9416021234
42	Haryana	Faridabad	Hi-Tech Communication	105, Sector 10, Faridabad-121006	Rahul Jindal	0129-2223422, 9810456663
43	Haryana	Gurgaon	Signature Communications	B-100 A, South City -1, Opposite - Huda Gymkhana Club - Gurgaon 122001	Raj Kumar Garg	0124-3956565, 0124-5102709
44	Haryana	Karnal	Mass Communication	7, Dayal Singh Colony, Kunj Pura Road, Karnal-132001	Ms Pinki	0184-3090717, 09896354205
45	Haryana	Panipat	INS Telecom	2,Bishan Sarup Colony, Opp Bus Stand, Near Hotel Deep, Panipat Jagdeep	Sachdeva	0180-3091860, 5005360, 9812072860
46	Haryana	Rohtak	Telecentre	Shakti Market, Civil Hospital Road, Near Chhotu Ram Chowk, Rohtak-124001	Mr. Madaan	01262-247242, 9896243092, 09355671666
47	Haryana	Sonipat	Teleworld	Ground Floor, Main Market, Main Railway Road, Opp. Old Civil Hospital, Sonipat - 138001.	Vipin Dua	1303090889
48	Haryana	Yamunanagar	Manish Communications	Shop No.3, Sharma Colony, Near Mahindra Petrol Bunk, Yamunanagar - 135005	Vinod Kumar Mittal	9355327374
49	Jharkhand	Jamshedpur	Tirupati Teletech	Chakravarti Compound, Near Hotel Castel, Contractors area, Bistupur, Jamshedpur-831001	Abhijeet Mukherjee	09334800350
50	Jharkhand	Ranchi	Satya Systems & Solutions	158, Opp Hotel Palace, Kadru, Ranchi-834002	Amit Rastogi	0651-2341361, 9835167667

LGE Service Center List

Sr	Circle	City Name	ASCs	Address Person	Contact	Phone
51	Karnataka	Bangalore	Meenakshi Electronics	#129, Lalbagh Main Road, Bangalore-560027	Mr. Ramesh.	080-56992943, 30617345, 09341210375, 51146822
52	Karnataka	Bangalore	Optima Mobile Services	24/2, Rajkumar Road, Near Subramanyanagar Police Station, 1st Block, Rajajinagar, Bangalore - 560 010.	Unni Krishnan	080-23131953, 080-57722205, 09341266656
53	Karnataka	Bangalore	Optima Mobile Services	B-3, Mallikaarjun Complex, Opp R T Nagar Police Station, 80 Feet Road, R T Nagar, Bangalore-560032	Prasad	8030610202
54	Karnataka	Bangalore	Pranav infocom	91/92, Hemachandra complex, Near VGP Show room, 4th block, jayanagar, Bangalore-560011	S.V.Sirish	080-56697937, 26552551
55	Karnataka	Bangalore	Pranav infocom	267/1.1st Main Road, 6th Cross, Behind Shanti Sagar, Domlur Layout, Bangalore-560071	S.V.Sirish	80-56969937, 51256309
56	Karnataka	Bangalore	Ascent Communication	No:113, St Johns Church road, Bangalore - 5	Naveen	080-30914856
57	Karnataka	Belgaum	Hello India Telecom	G-4, Maratha Mandir Complex, Khanapur Road, Near Railway Flyover, Belgaum - 590 001.	Sanjay	9845327531, 09341101800
58	Karnataka	Hubli	Networld	shop no : B6, Laxmi complex, Court circle, Hubli- 580020	Mr. Mahendar	0836-3090671, 98452-54251, 0836-3090671
59	Karnataka	Mangalore	Innovative Infocom	15-10-537/11, Jayavarma Centre, Mallikatte Circle, Kadri, Mangalore - 575002.	Sebastin Fernades	0824-56632441
60	Karnataka	Mysore	K.K.Marketing,	1432/9, Tribhuvan Towers, opp Vetenary Hospital, Dewan's Road, Dhanwantri Road Cross, Mysore -570001	Mr. Karunakaran.	09342115003, 09342120789
61	Karnataka	Gulbarga	Aishwaraya Communication	G-15, G.R. Complex, Opp Mini Vidhan Soudha Main Road, Gulbarga	Mallikarjun	9342356000, 9342355116
62	Kerala	Ernakulam	Zenicon Infocom(P) limited	2nd floor, Tharian's Building, opp. Ship Yard, M.G. Road, Ernakulam-682015	Jaimon Joseph	0484-2359511, 9349271511
63	Kerala	Irinjalakuda	Akbar Mobiles	376-44, Near St. Josephs college junction, Irinjalakuda-680121	Mr. Sebastian	0480-830796

LGE Service Center List

Sr	Circle	City Name	ASCs	Address Person	Contact	Phone
64	Kerala	Karunaga pally	Supreme Enterprises	Opp to KSRTC Bus stand, Karunagapally-690518	Mr. Ratish	0476-2620282
65	Kerala	Kollam	Digital Infosystems	MC-3087, New Block, Bishop Jeromi Nagar, Chinnakada, Kollem-691001	Johnson Lawrence	0474-2760647, 9846007059
66	Kerala	Kottayam	SVM Technologies	NSS Building, Near Pallipurathukavu Temple, Kodimapha, Kottayam - 686 002	Rajesh K S	0481-2565303, 9847310123
67	Kerala	Kozhikode	Domain Infosystems	Domain Infosystems, 2nd Floor, Darussalam Complex, Mavoor Road, Kozhikode - 673 004	Mukundan	0495-2722222
68	Kerala	Manjeri	Integrated Computer Systems	Royal Tower, TB Road, Manjeri - 676121	Mr. Thomas Chacko	0483-3099686
69	Kerala	Mavellikarr	Ettutharayil Agency	Ettutharayil complex, K P Road, Kayamkulam-690502	Anu T cheriyan	0479-2441760, 09388900025
70	Kerala	Pallakad	Akbar Mobiles	N.S. Towers, Kalamandapam junction, Palakkad - 678 001	Suresh	0491-2529829, 9847086446
71	Kerala	Thiruvananthapuram	Appolo Systems	TC 20/2392, Kalpalayam, Karamana P.O., Thiruvananthapuram - 695 002.	Santosh	0471-2340523
72	Kerala	Trichur	Akbar Mobiles	Kadarathodh Building, North Bus stand, Trichur - 680 001	Sojan	0487-2323424
73	Madhya Pradesh	Bhopal	Neha Sales Corporation	F-104, Anmol Tower, E-5/14, Commercial Zone, Arera Colony, Bhopal-462016	Ashok Hirwani	0755-5277247 2424088, 9826072327
74	Madhya Pradesh	Gwalior	Computer Clinic	Global Apartments, City Centre, Opp Income Tax Office, Gwalior.	Rishi Sharma	9329302200
75	Madhya Pradesh	Indore	Neha Sales Corporation	Shop No.18, Ground Floor, Johari Palace, M.G.Road, Indore - 452001	Ashok Hirwani	0731-5091833, 9826072327
76	Madhya Pradesh	Jabalpur S M	Shopee	846, Chattarpur Bhavan, Nr. Ashoka Hotel, Wright Town, Jabalpur, Pin 482002	Vikas Jain	0761-5063183
77	Chattisgarh	Raipur Cybernet Systems		B-2, 1st Floor, Garchaz Complex, Jail Road, Raipur - 492001	Anand Singh	9826132918 9826132918
78	Madhya Pradesh	Ujjain	Galaxy Computers & Communication	43/2, Varruchi Marg, Opp Madhav Nagar Police Staion, Freeganj, Ujjain	Amitabh Chhajhlani	9893003099
79	Maharashtra	Amravati	Scorpio Services	Shop No.84, Ground Floor, Gulshan Towers, Nr. Panchasheel Cinema,	Mr. Pramod	0721-2567302,

LGE Service Center List

Sr	Circle	City Name	ASCs	Address Person	Contact	Phone
				Amrawati, Pin-444601		09370151826, 9422156874
80	Maharashtra	Aurangabad	Unique Teletmatics	Shop no.108/B, Behind Sajawat Handloom, Tapdiya Super Market, Nirala Bazar, Aurangabad-431001	Mr. Mahesh	0240-2356447, 9823007730, 09325210364
81	Maharashtra	Chinchwad (Pimpri)	Ritz Communication	Shop No 22, Gawde Kunal garden, Pimpri-Chinchwad Link Road, Chinchwad, Pune-411033	Mr. Reyaz	020-7485613, 020-30961900, 09890339777
82	Maha rashtra	Jalgaon	Saranag Services	B-288, Golani Market, Jalgaon	Mr. P.M.Waghanna	982331703
83	Maha rashtra	Kohlapur	SMS Services	S5, Diwan Tower, Opp. Nutan Marathi School, Near Mirajkar Tikky, Kolhapur, Pin -416005.	Prakash Patil	0231-2541120, 9823026120
84	Maha rashtra	Margoa	Comlink Synergies India Pvt Limited.	Ground Floor, Shop No.i, Garden view building, Next to UTI Bank, Near Margao Municipal Garden, Margao-403601	Sunil	09326105629, 9822101522, 09326105637
85	Maha rashtra	Nagpur	Spectrum Marketing	Shop No.2, Dharampeth Towers, West High Court (WHC) Road, Dharampeth, Nagpur - 440010	Sonali	0712-3095700 5618186, 2527823
86	Maha rashtra	Nasik	MOBS Associates	SHOP NO. 12, FIRST FLOOR, KAPOTE-MEHER' MARKET, RENUKA NAGAR, WADALA NAKA, DAWRKA, NASIK - 422 001.	Girish Bhangre	0253-5623613, 09370291070, 09371531078
87	Maha rashtra	Panjim	Comlink Synergies India Pvt Ltd	Shop No. 5, Dr Atmaram Borkar Road, Next to RIL Mutual Fund, Panjim, Goa-403001	Sunil	9326105629
88	Maha rashtra	Pune	Digital Concepts	Shop No. 5, Indulal Complex, Besides Kaka Halvai, LBS Marg, Navi Peth, Pune-411030	A Ahmed	020-4012921, 09371029798
89	Maha rashtra	Pune	Mobile World	G-25, AKSHAY COMPLEX, DHOLE PATIL ROAD, PUNE-411 001	Pawan Mantri	098230 93335
90	Maha rashtra	Sangli	Ramesh Electronics	Opp. Kanya Purohit prashala, Rajwada, Sangli-416416	Suresh Shegane	0233-2327601, 9823085176, 09372107601
91	Maha rashtra	Solapur	Jawaharlal	184, Gold Finch Peth, nr Hotel Ritesh, Solapur - 413007.	Prasanna J	0217-2725030.

LGE Service Center List

Sr	Circle	City Name	ASCs	Address Person	Contact	Phone
			Radio Service	Chavan		9422458830, 9823317081
92	Mumbai	Kalyan	Vintech Solutions	SHOP- 14, GROUND FLR, ARCHIES APARTMENT, OAK BAUG,KALYAN-421301	Pawan	09322877555
93	Mumbai	Vasai	E-Link Solutions	Shop No.5, Type C, Bldg no.5/6, Shanti Vihar, Mira Road -E, Pin Code : 401107.	Kamlesh	022-28552087, 09323182084
94	Mumbai	Mumbai	Asbolute Networks	A007, Vishal Shopping Centre, Next to Vishal Hall, Near Station, M.V.Road, Andheri (E), Mumbai - 400 069	Arun	022 39544800, 9322252390
95	Mumbai	Mumbai	Bombay Telecom Services	211, 212, Navjeevan Commercial Society. Building No:3., Second Floor, Above Hasumkh Tea, Mumbai Central (E), Mumbai: 400004	Tejinder Singh Kalha	9323900612,
96	Mumbai	Mumbai	Sai Tele Services	A-110, Satyam Commercial Complex,M.G.Road, Ghatkoper (E), Mumbai - 400 077.	Mr. Suresh Kotle	022-56299540, 39533603, 9820188338
97	Mumbai	Mumbai	Creative Solutions	SHOP NO 6 AMBIKA COOPERATIVE HOUSING SOCIETY, JAWAHAR NAGAR ROAD NO 2 NEAR RAILWAY CROSSING, GOREGAON WEST, MUMBAI 400062	Anand	022-28769003, 022-39533603, 9820188338
98	Mumbai	Mumbai	LG Service Centre	Third Floor, Trade World,Kamala Mills Compound, Senapati Bapat Marg, Lower Parel, Mumbai-400013	Rajib Saha	022-24947375, 09323190401
99	Mumbai	Thane	Vinay Technologies Pvt Ltd	Shop no 3, Minal Chhaya Aptt, Muncpal Corporation Road, Panch Pakhadi, Thane (W) - 400601	Vinod Jakotiya	022-25304960, 9821068231, 09322213342
100	Mumbai	Navi Mumbai	Hello World	Shop No 53,Gf, Welfare Chambers, Sector-17, Vashi, Mumbai-400703	Mahesh	022-27657705, 09322641396
101	Mumbai	Khar(W) Telecom Corporation	Komplex	1.Satguru Shopping Center, Illrd road, Khar(W), Mumbai	Mr. Mohammad	022-26461917, 09323395024
102	Mumbai	Panvel	Oceanic Tele System	Shop.No.10, Prajapati Arcade,Sector 15, New Panvel (E), Dist. Raigad.	Shailash Bobade	022-56104542, 09322217221
103	Orissa	Bhubneshwar	S.A.INFOSYS	291.Bomikhal, Opp.Akamra cinema hall, Bhubaneswar-751010	Sarabjeet Singh	0674-2573113/4
104	Orissa	Cuttack	O.A. INFOTECH	Behind Govt Bus Stand, Badambadi, Cuttack -753012	Manas Mahapatra	0671-2312613
105	Punjab	Amritsar	Bajaj	87, G Floor, Nehru Complex, Lawrence Road,	Suman Bajaj	09356024827,

LGE Service Center List

Sr	Circle	City Name	ASCs	Address Person	Contact	Phone
			Telecommunication	Amritsar-143001		9814650314, 0183-3958859
106	Punjab	Barnala	Unique Infotech	Mittal Street, Near M C Office, Barnala-148101	Pankaj Goyal	01679- 238007
107	Punjab	Bathinda	Lalli's Lalli's Gallery	1139-A, First Floor, Amrik Singh Road, Nr Gole Diggi, Bhatinda-151005	Ashok Kakria	0164- 2239500 2236337, 9814222310
108	Punjab	Chandigarh	Vignesh Services	S.C.O- 189-90, Sec- 34, Chandigarh	Mukesh Arya	0172-3018028, 09316134655
109	Punjab	Hoshiarpur	Kuldip's Mobile Care	Dhobian Wali Gali, Phagwara Road, Hoshiarpur-146001	Kuldip	01882-226906, 9815073906
110	Punjab	Jalandhar	Mobile Center	Shop No-7, Gobind Market, Opp-Beri Hospital, Nakodar Road, Jalandhar.	Jogesh Diwan	0181-3092666, 9814029696, 9815314060
111	Punjab	Ludhiana	Shahi Communication	Shop No.5, 4X International, 583 L, Model Town, Ludhiana	Amit Shahi	0161-3944190
112	Punjab	Malerkotla	Prime Infocomm	Opp. Main gate, Govt College, Malerkotla-148023	Rohit Bansal / Raj Verma	01675-253899, 9814040066, 01675-331979
113	Punjab	Moga	Super Communication	Pawan Market, Opp shankar Batteries, Court Road, Moga-142001	Jai Deep Mehta	9356314398
114	Punjab	Patiala	Image Services	84, First Floor, Leela Bhawan, Patiala-147001	Rohit Bansal	0175-2222796, 9815761262
115	Rajasthan	Jaipur	Kamakshi Telecom	105, 1st floor, Paradise, C-61 (A), Sarojini Marg, C-Scheme, Jaipur-302001	Rahul Bhargav	0141-2365575, 09314512863
116	Rajasthan	Jaipur	Alpha Infotech Systems	F-1, First Floor, Krishna Mall, Lakshmi Mandir Crossing, Tonk Road, Jaipur-302015	Shatrughan Mangal	0141-5106777, 09314717171 0141-3099724
117	Rajasthan	Jodhpur	Omega Electronics	UG/4, Adeshwar Tower, Main Chopasani Road, Opp.Gehlot Watch Co, Jodhpur-342003	Pratap Singh	0291-3091214, 09314717171
118	Rajasthan	Kota	Cyber	26, Ground floor, Kalawati Paliwal market,	Shyam	0744-2398153,

LGE Service Center List

Sr	Circle	City Name	ASCs	Address Person	Contact	Phone
			Infosystems	Gumanpura, Kota-324007	Maheshwari	09352603354, 09352620153
119	Rajasthan	Udaipur	Ficusa Enterprises	13, Darshanpura, Opp. M.B. Commerce College Gate, Nr Computer Zone, Udaipur-313002	Virendra Ranka	0294-2410002, 2413002, 09314410002
120	Tamilnadu	Chennai	Unicare Infocomm Services	73, Nutech Plaza, Shop no G-3, G Floor, Arcot Road, Kodambakkam Chennai - 600 024.	R M Rajesh / Kartik	044-24724666, 9841036466
121	Tamilnadu	Chennai	GS Systems	547/352, F M Towers, Mount Road, Nandanam, Chennai-6000035	Kanirajan	044-24330889, 9884160010
122	Tamilnadu	Chennai	U Com Technologies Pvt. Ltd.	Shop #3, Door # 24, New #30, Balfour Apartments, Balfour Road, Kilpauk. Chennai - 600 010.	Shyam	044-52174656, 52175115, 9884187800
123	Tamilnadu	Chennai	Escomm Systems India P Ltd	No 57-7, Arunodaya Apartments Next to Hotel Sindhoori, Near by Everest Bus Stop, Ponnammalai High Road, Chennai-600003	Mrs N S Vijaysri	044-30901688, 25612212
124	Tamilnadu	Chennai	Genesis Communication	63/3, First main road, Gandhi Nagar, Adyar, Chennai-600020	Mr. Suresh	044-24401188
125	Tamilnadu	Coimbatore	Fast Track	Sudera Complex, 354B, 100 Feet Road, COIMBATORE - 641012	Anand Prakash	0422-2490577, 9843080040, 09363100080
126	Tamilnadu	Cuddlore	Kasturi Cellular Service	NO: 37 (2C) BHARATHI ROAD, CUDDALORE. 607 001, CUDDALORE DISTRICT, TAMIL NADU.	Mr. Raghupati	04142-220183
127	Tamilnadu	Erode	JANS Electronics	148, Mettur Road, Opposite shakti vinayak temple, Dana Complex, Erode-638011	M Kanan	0424-2258526, 9443263508
128	Tamilnadu	Madurai	Devaa Electronics	No.4, Thirumakulam North Street, Near Ayyappan koil, Thhallakulam, Madurai-625002	Guna	0452-5360995, 0452-2526179, 09344107995
129	Tamilnadu	Pondicherry	Digital Logistics	126/2, Perumal Koil Street (Bharathi Street Cutting), Pondicherry-605001	G Singaravelu	9843093348, 09345453531, 0413-5210148

LGE Service Center List

Sr	Circle	City Name	ASCs	Address Person	Contact	Phone
130	Tamilnadu	Salem	Global Care Service	Sixer Complex, 121/19A, Sarada College Road, Next to Abi Medical Centre, Salem - 636007	Vasudev Nayak	0427-3090535
131	Tamilnadu	Thanjavur	Z M Electronics	33, New Municipal Shopping Complex, Opp LIC, Gandhi ji road, Thanjavur-613001	Ziauddin	04362-272595, 09360313254
132	Tamilnadu	Tirunneveli	Classic Electronic	39, Trivendrum Road, Opposite Kalimark, Welcome Complex, Palayamkottai, Tirunilveli-627002	Erkins	0462-2575801
133	Tamilnadu	Tirupur	Shri Vasavi Electronics	# 155-303, Mangalam Road, Karuvam palayam, Tirupur -641604	MR.U.B. Bala Murali	0421-3091438, 98422-74300, 09363005560
134	Tamilnadu	Trichy	S K Electronics	Raj Complex, 9/A EVR Road, Puthur, Trichy- 620017	Krishnan	0431-2771946, 9843178104, 09345101502
135	Tamilnadu	Vellore	Matha Communication	4, S.LN Plaza, Opposite Odai Pilliar Koil, Gandhinagar, Vellor - 632006	Gunaa Shekhar	0416-2240800
136	Uttar pradesh	Agra	NSC Computers	Shop No G-124, Block No- 29, Sanjay Place, Agra - 282 002	Rajiv Singhal	0562-2520032, 09319111350
137	Uttar pradesh	Agra	Space Consultancy & Services	UG 1 & 2, & Opp. Jaihind Hotel, Merchant Chamber, Sadar Bazar, Agra-282001.	Tanviir	9358311202
138	Uttar pradesh	Aligarh	A V Computer Services	G-1, Ganpati Plaza, Jha Compund, Marris Rd, Aligarh-202001	Vaibhav	0571-2506148, 9412274391
139	Uttar pradesh	Allahbad	B. P. Electronics	G-11, Indira Bhawan, Ground Floor, Civil Lines, Allahbad-211001	Ms Naina Pandey	0532-2608088
140	Uttar pradesh	Bareilly	Sapan Infotech	G - 64 A Kunwar Complex, Near Gupta Watch Co, 116 Civil Lines, Bareilly	Sanjeev Singh	9359102467
141	Uttar pradesh	Dehradun	Krishna Communication	Shop No 15A, Meedo Plaza, Rajpur Road, Dehradun, Uttaranchal-248001	Vinod	0135 3090895, 09358112922, 09358119696
142	Uttar pradesh	Ghaziabad	Concessionair Documentation India Pvt Ltd(CDIL)	C-83, Rajnagar District Center (RDC), Ghaziabad	Arun Sharma	0120-3092011

LGE Service Center List

Sr	Circle	City Name	ASCs	Address Person	Contact	Phone
143	Uttar pradesh	Gorakhpur	Eternal Electronics	Shop No.11 , Pandey Complex, 33, Kasya Road, Opp DIG Bunglow, Gorakhpur -273001	Ram Pratap	0551-2204520
144	Uttar pradesh	Kanpur	AR Infotech	111/402, Ashok Nagar, Kanpur Pin 208012	Manoj Shukla	0512 3111662, 9839068734, 0512-3093011
145	Uttar pradesh	Lucknow	NET COM	3 way road, City Point, Opp Krishi Bhawan, Lucknow-226024	Kawaljeet	0522-3094222
146	Uttar pradesh	Meerut	Systech Computers	F-124/125 1st floor Ganga Plaza, Begum Bridge Road, Meerut-250002	Vineet Goyal	0121-2691167, 09358416631
147	Uttar pradesh	Muzaffarnagar	Jai Computer Services	Shop No. 4, 1st Floor, Roorkee road, Near Shiv Chowk, Central Bank Mkt, Muzaffarnagar-251001	Manohar Singh	0131-2635483, 9412110215
148	Uttar pradesh	Noida	M R Telecom	J-45, First Floor, Sector-18, NOIDA-201301	Kailash Aggarwal	0120-2591440, 9871197801
149	Uttar pradesh	Saharanpur	Maharaj Communications	Near Maharaja Palace, Delhi Road, Saharanpur-247001	Pankaj Malhotra	0132-2720881, 09358311202
150	Uttar pradesh	Varanasi	Shivam Mobile Distributers	Shop No.5, B37/115-B-1 Baradari Complex, Rathyatra Crossing, Varansi Pin 221010	Rishi Mohan	0542-2363296, 9839241004
151	W Bengal	Assansol	Sky Computer & Telecom	Islam Market, Nuruddin Road, Assansol-713301	Syed Arshad Ali	0341- 2207719, 9832160886
152	W Bengal	Burdwan	San Infosys	Tikonias Bus Stand, Central Mkt, GT Road, Burdawan-713101	Sanjit Debnath	0342-3090265, 9832192170
153	W Bengal	Calcutta	Benma Infosol Pvt Ltd.	P-168/1 CIT Road, Scheme VIII, KOLKATA 700067	Arun Surana	033-30943176
154	W Bengal	Calcutta	JP Computers	5B Ekdalia Place, Kolkata - 700019	Somim Kabir	033-24401923
155	W Bengal	Calcutta	Jaksom Engineering Pvt Ltd	Block-A, Shop-1, Ambika Vihar, 1/1 Harduttrai Chamaria Road, Howrah- 711001	P.Mukherjee	033- 30950383
156	W Bengal	Calcutta	Skylink	8/1A, Little Russel Street, Calcutta-700071	H R Molla	033-30903814, 033-32091037
157	W Bengal	Durgapur	Tech International	Red Cross Road, City Centre, Durgapur-713216	Amitava Banerjee	0343-2546893, 9434002244

LGE CDMA Fixed Wireless Phone LSP-430

Licensed by QUALCOMM Incorporated under one or more of the following Patents:
U.S. Patent No. 4,901,307 U.S. Patent No. 5,056,109 U.S. Patent No. 5,099,204
U.S. Patent No. 5,101,501 U.S. Patent No. 5,103,459 U.S. Patent No. 5,107,225



P/N : MMBB

MAR/2007/ISSUE 1.0
PRINTED IN KOREA