

Quick Start

Status LED
Camera lens
Earpiece



3.5 mm
headset jack

Micro USB
charging port

Camera lens

Laser auto
focus

Volume keys

Flash

Power/lock key



LG G3 Vigor™





AT&T Ready2Go





Set up your device quickly and easily by using Ready2Go:

- Set up Email accounts
- Sync your contacts
- Connect to Wi-Fi®

You can use Ready2Go when you first activate your device or open it later from the app tray. The wizard will guide you through the setup process.




Note: To skip the wizard, tap **not now** > **exit**. To return to the wizard from the home screen, tap  > .

Customize Your Phone

Home screen

- ① Press and hold an empty spot on a home screen and choose a category:
 - **Apps:** Add shortcuts from the app tray.
 - **Widgets:** Add dynamically updating widgets.
 - **Wallpapers:** Change your wallpaper.
- ② To move an item, press and hold it and drag it to a new location. To delete it, drag it to **Remove**.

Your Sounds

From the home screen, press and hold  and tap **All settings** > **Sound**. You can change your ringtones, set notification sounds, and adjust your touch feedback options.



Touch Screen

KnockON

KnockON is enabled at default. Double-tap an empty part of the screen or the top bar to lock the phone. Double-tap again to wake it.

Notifications Panel


Tap to adjust your Quick Settings

Access all settings


Tap to respond to a notification

Remove all notifications


Swipe left or right to remove a notification



Camera, Video, and Sharing Photos





Share photos

- ① Tap the thumbnail in the lower right of the screen.
- ② Tap .
- ③ Tap an option and follow on-screen instructions.

Transfer Music and Pictures

- ① Connect your LG G3 Vigor™ to your computer with a USB cable. Steps may vary depending on your operating system.
- ② You may be prompted to install PC programs. Tap **OK > Media sync (MTP)**.
- ③ On your PC, choose **Open device to view files** using Windows Explorer.
- ④ Your phone will appear as another hard drive on your computer. Click on the drive to view it.
- ⑤ Drag and drop your files* into the corresponding folders, such as Music, Movies, or Pictures. You can also transfer files from your PC to your phone.
- ⑥ When you're finished, swipe down on top of the screen. Tap **Media device (MTP) > Charge phone**. You may now unplug your device.




*Files must be Digital Rights Management (DRM) free.

Calls and Voicemail




Visual Voicemail

View your voicemail messages as a list in your mailbox and play them in the order you like.

From the home screen, tap  > .

Make a Call




HD HD Voice Capable™ - Clear conversations and reduced background noise.

LG G3 Vigor supports AT&T HD Voice which enables background noise reduction and crisp audio quality when both callers are using AT&T HD Voice compatible phones within the AT&T HD Voice coverage area and have HD Voice provisioned on their account. HD Voice has limited availability in select markets. For further details on AT&T HD Voice and service restrictions, visit att.com/hdvoice.

Note: To reset your voicemail password, go to att.com/resetvm.

Text Messaging





Please don't text and drive.

Messaging rates apply.

Email



- View folders and additional email accounts
- Refresh your inbox
- Compose a new email
- Access settings and additional options
- Choose a recipient from your contact list



Attach a picture or other file

Send your message

Note: Contact your IT administrator to help set up your corporate Microsoft® Exchange account.

Web








Note: To disable the Browser Bar, tap  >  > **Toolbar**.

MBM64538901 (1.0)

Input Language

Change Device and Input Language





- ① From the home screen, press and hold  and tap **All settings > General > Language & input**.
- ② To change the device language, tap **Language**.
- ③ To change the keyboard input language, tap  next to the desired keyboard.
- ④ Tap **Input language and keyboard layout**.
- ⑤ Tap a language to select it. You can change languages by tapping  when you have a keyboard open, for instance while typing a text message.



QuickMemo+




Create a Memo with a Location Reminder

- ① From the home screen, tap  > **QuickMemo+**.
- ② Tap  to begin a new memo, and then enter your message.
- ③ Tap  to save the memo.
- ④ To create an location-based reminder alert, tap the saved memo > **Add reminder** > **Location reminder**.
- ⑤ Enter the location in the Search location field and tap **Done**.
- ⑥ Tap the location and then tap  to save the reminder alert.

Tap to write the memo with your finger

Tap to use the keyboard to type a memo





Tap to erase the memo

Tap to save the memo

QSlide Function

The QSlide function enables an overlay on your phone's display for easy multitasking. You can open two QSlide apps on top of a third app from your library.


QSlide apps



Knock Code™

Get direct access to the home screen while keeping your phone secure.

Setup

- ① From the home screen, press and hold  and tap **Lock screen settings > Select screen lock > Knock Code > Next**.
- ② Follow the on-screen prompts to set up a Knock Code and backup PIN.

Use


- When the screen is dark, enter your Knock Code anywhere on the screen.
- If you enter your Knock Code incorrectly 5 times, you'll be prompted to enter your backup PIN.



AT&T DriveMode®





When your vehicle is in motion, automatically respond to incoming calls, texts, and emails.





AT&T DriveMode is free to AT&T customers. Standard data and messaging rates apply to auto-reply messages.



Wi-Fi and Bluetooth®

Connect to Wi-Fi

- ① From the home screen, press and hold  and tap **All settings > Networks > Wi-Fi**.
- ② Tap  to turn on Wi-Fi.
- ③ Tap a network name. Enter a password if required and then tap **Connect**.


Use Bluetooth


- ① From the home screen, press and hold  and tap **All settings > Networks > Bluetooth**.
- ② Tap  to turn on *Bluetooth*.
- ③ The LG G3 Vigor will automatically search for devices. Tap a device to pair. See the *Bluetooth* device's user manual for more information on pairing.




Network Indicators

Your 4G LTE wireless device will indicate which of the AT&T wireless networks you are connected to. A network indicator does not necessarily mean that you will experience any particular upload or download data speeds.

 **4G LTE:** Connected to the AT&T 4G LTE network.

 **4G:** Connected to the AT&T HSPA+ network. The AT&T HSPA+ network is capable of delivering 4G speeds when combined with enhanced backhaul. 4G availability is increasing with ongoing backhaul deployment.


 **E:** Connected to the AT&T EDGE/2G network.

Actual data upload and download speeds depend on various factors, including the device, network utilization, file characteristics, terrain, etc. Learn more at: wireless.att.com/learn/articles-resources/wireless-terms.jsp, your AT&T Wireless Customer Agreement, Section 3.2 "Where and How Does AT&T Service Work?"

4G LTE not available everywhere. LTE is a trademark of ETSI. Learn more at att.com/network.

Google Play™ Store

Once you have set up your Google™ account, you can download apps, music, movies, and more from the Play Store.



Notes:

- To purchase a paid app, you will need to set up a payment method with Google Wallet™.
- You may want to download apps over Wi-Fi to save on your data plan usage.

AT&T Services

AT&T offers a multitude of apps designed to make your everyday life easier.



myAT&T: Track your usage, review and pay your bill, and update your data plan services.



AT&T Mobile Hotspot: Share your mobile network data connection with other Wi-Fi devices.



AT&T Locker™: Safely store and share all your photos, videos, and documents with up to 5 GB of free storage.



AT&T Mobile Locate: Back up contacts and media, locate a lost device, and get device support.



AT&T Navigator®: Get voice-guided, turn-by-turn driving directions and traffic updates.



Mobile TV: Watch LIVE, on-demand, and downloadable mobile TV.



AT&T Smart Wi-Fi: Maximize your battery performance and data plan, simplify access to AT&T Hot Spots and Wi-Fi networks, automate your Wi-Fi connections, and track your data usage.

Data rates may apply. Mobile TV and AT&T Navigator require a separate subscription. Mobile TV requires mobile broadband service. Service not available in all areas. Programming subject to blackout restrictions. Download and watch capability available for select content, requires Wi-Fi connection, and is available for viewing for limited time periods.

Find More Information

On your phone

- Tutorials and videos: **Apps > DeviceHelp**
- Access your account: **Apps > myAT&T**

On the Web

- Tutorials and videos: **att.com/DeviceHowTo**
- Manage your wireless account, including suspending service if your phone is stolen: **att.com/MyATT**

Give us a call

- 800-331-0500
- 611 from any AT&T wireless phone

Accessories

- **att.com/WirelessAccessories**
- Visit your AT&T store

Portions © 2014. LG, LG Life's Good, and the LG logo are registered trademarks of LG Corp. G3 Vigor is a trademark of LG Electronics, Inc. Portions © 2014 AT&T Intellectual Property. All rights reserved. AT&T, the AT&T logo and all other AT&T marks contained herein are trademarks of AT&T Intellectual Property. All other marks contained herein are the property of their respective owners.

Printed in China