

LG optimus^S



QUICK START GUIDE



Set Up Gmail™



Sprint ID



Download an App from
Android Market™



Set Up Portable
Wi-Fi® Hotspot



Manage Your
Wireless Settings



Use Google™
Voice Actions



Bluetooth® Pairing



LG


Life's Good

lgusa.com/OptimusS

Getting to Know Your Phone



FRONT



BACK



SIDES



1. Earpiece
2. LCD Touch Screen
3. Menu Key
4. Home Key
5. Micro USB Charging Port
6. Microphone



7. Search Key
8. Back Key
9. Power/Lock Key
10. Camera Lens
11. 3.5mm Headset Jack
12. Speaker

13. microSD™ Memory Slot
14. Camera Key
15. Voice Command Key
16. Volume Up/Down Keys

In addition to providing mobile access to your Gmail inbox and syncing your Gmail contacts, setting up a Google™ Account on Optimus S will allow you to take advantage of many of your phone's other great features, such as Google Talk™ and Android Market.



Sign in to a Google Account

1. From the Home screen, touch the **Launcher icon**  > **Gmail**.
2. Read the information and touch **Next** to continue.
3. Touch **Sign in**. (You may also create a Google Account if you don't yet have one. Just touch **Create** and follow the on-screen steps.)
4. Enter the username and password associated with your Google Account and touch **Sign in** again.
5. Touch **Finish setup**.
6. Once syncing is complete, you'll be taken to your Gmail inbox. Touch an email to read it, or press  for more options.



Sprint ID



It's simple to personalize your phone using Sprint ID,* which allows you to download, install, and switch between up to five complete experience packs, each containing ringtones, wallpapers, apps, and more. Sprint ID is the easiest way to customize your Android experience!



1. From the Home screen, touch the **Sprint ID icon** .
2. Touch **Get New** to download a new Sprint ID pack.
3. Swipe up to scroll through the available ID packs. Touch one to select it.
4. Touch **Install**.
5. Read the Terms of Service and touch **Agree**.
6. Once the pack has been downloaded, touch **OK**.
7. To switch from one ID pack to another that you've previously downloaded, just touch the **Sprint ID icon**  and select the ID you'd like to use.

*Sprint service required. Product features subject to change. Features based on carrier program availability. Additional charges may apply.



With thousands of apps available in Android Market, you're sure to find just the right one for every need. Find apps for organization, shopping, communication, and more, or download a game to enjoy a little downtime.


1. From the Home screen and with a Google Account already set up on your phone, touch the **Launcher icon**  > **Market**.
2. Read the Terms of Service and touch **Accept**.
3. You can browse featured apps, select a category, or search for an app. To search, tap the **Search icon** , enter the search term, and touch **Go**.
4. Touch an app to view details.
5. Touch **Buy** (paid apps) or **Install** (free apps). (To purchase a paid app, you'll need to set up a payment method with Google Checkout™.)
6. Read the application access information and touch **OK**.
7. Once the app has been downloaded and installed, you can find it in alphabetical order on the Launch Screen.



Set Up Portable Wi-Fi® Hotspot

Need a wireless Internet connection for your laptop, but there's no Wi-Fi signal to be found? Let your Optimus S step in. Optimus S can share its data connection to serve as a portable Wi-Fi hotspot for other devices.*


1. From the Home screen and with Wi-Fi inactive, press .
2. Touch **Settings** > **Wireless & networks** > **Portable hotspot**.
3. Touch **Portable Wi-Fi hotspot** to turn the feature on.
4. You can now connect other devices to the network you've created. To check or change your network's password and other settings, touch **Portable Wi-Fi hotspot settings**.



*Wi-Fi® Hotspot feature may require an additional optional service plan from your carrier. Wi-Fi networks should be encrypted by users to prevent unauthorized access.

Optimus S offers a variety of wireless options, and there are two easy ways to adjust them when needed.

Via Settings

1. From the Home screen, press .
2. Touch **Settings** > **Wireless & networks**.
3. From here, you can manage the following settings:
 - Airplane mode
 - Wi-Fi power and settings
 - *Bluetooth* power and settings
 - Portable hotspot
 - VPN (Virtual Private Network) settings
 - Mobile networks

Via the Power Control widget

1. From the Home screen, swipe left or right to find a screen with room to add a widget, and then touch and hold an empty place on the screen.
2. Touch **Widgets** > **Power Control**.
3. From this widget, you can control Wi-Fi and *Bluetooth* power as well as a variety of other settings.





Use Google™ Voice Actions

Google Voice Actions let you perform many of your everyday tasks on your phone using only your voice!


Just touch the **Launcher icon** , select **Voice Search**, and say a command:



- To send a text message, say "**Send text to [recipient] [message]**." For example, "Send text to Chloe Smith I'll be there in fifteen minutes."
- To get directions, say "**Navigate to [address/city/business name]**." For example, "Navigate to 101 Peach Street," or "Navigate to the Getty Center."
- To place a call, say "**Call [contact name] [phone type]**" or "**Call [business name] [location]**." For example, "Call Ben Davis mobile," or "Call Sal's Deli Minneapolis."

Many other Voice Actions are available, such as visiting a website, viewing a map, or listening to music. Learn more by touching **Voice Search** on your phone or visiting google.com/mobile/voice-actions.



Take advantage of the freedom of *Bluetooth* wireless technology with Optimus S.

1. From the Home screen and with the device you wish to pair with in pairing mode,* press .
2. Touch **Settings** > **Wireless & networks**.
3. Touch **Bluetooth** to turn *Bluetooth* power on.
4. Touch **Bluetooth settings** > **Scan for devices**.
5. Touch the name of the device you wish to pair with.
6. Touch **Pair** to pair and connect.



*Please consult the documentation included with the *Bluetooth* device for information on placing the device into pairing mode.



Bluetooth Headset
(HBM-235 – Purple and Black)



Bluetooth Headset
(HBM-570 – Silver, Dark Blue,
Pink, and Purple)



*Bluetooth Headset with Vehicle
Power Charger* (HBM-585)



Bluetooth Stereo Headset
(HBS-700)



*Bluetooth Headset with
Speakerphone/Solar Charging
Cradle* (HBM-810)



Vehicle Power Charger



Maximize your phone with these cutting-edge accessories at
lgusa.com/OptimusS

All materials in this guide including, without limitation, the design, the text, and any marks are the property of LG Electronics, Inc. Copyright © 2010 LG Electronics, Inc. ALL RIGHTS RESERVED. Features and specifications are subject to change without prior notice. Optimus S is a trademark of LG Electronics, Inc. microSD™ is a trademark of SanDisk. The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. Other trademarks and trade names are those of their respective owners. Unless otherwise specified herein, all accessories referenced herein are sold separately.



Mixed Sources
Product group well-managed
forests, controlled sources and
recycled wood or fiber
www.fsc.org Cert no. XXX-XXX-XXX
© 1996 Forest Stewardship Council

