



Headphone A standard stereo mini headphone jack.



Line In A standard stereo mini line in jack.



USB Port The USB port can be used to attach an external USB drive to the Conductor.



Eject Button used to eject a CD from the slot loading CD player.



Slot Loading CD You can play standard audio CDs in the slot loading CD player on the Conductor.



NOTE: Only audio CDs can be used with the CD player on the Conductor. Data CDs will not work in the CD player.

Back Panel



Power Connector The Power connector is where you will connect the power cord.



S/PDIF Jack The S/PDIF jack provides an output connector for a digital optical cable to deliver digital audio.



Ethernet The Ethernet port connects the Conductor to your router or switch.



iPod Dock Port This connector attaches an iPod to the Conductor using the optional Docking Station for iPod (MCC-140).