

Lofree

EP206 TV ALARM BLUETOOTH SPEAKER

Designed by SHIMON & SHINE
Assembled in China

EP206

Product Specifications

Product size	98*70*75mm
Product weight	about 470g
Wireless range	about 10 meters (open area)
Bluetooth version	Bluetooth V4.2
Bluetooth name	TVBLDFREE
Speaker Specifications	40mm Speaker x1
Rated power	5W
Playback time	about 5 hours
Charging time	about 2 hours
Stand by time	about 150 hours
Battery capacity	17V 2000mAh
Power supply	built in lithium battery
Available alarm for scheduling	2
Clock format	24-hour

Box Contents

QTV Bluetooth Alarm Speaker	x1
USB Cable	x1
Manual	x1
Package	x1

Product Illustration

Buttons Illustration

- Power Button**
ON: Power on. OFF: Power off.
- Antenna**
Short Press (1 Second): Press to enter Snooze mode while the alarm is ringing. Press to play the default video at other interfaces.
Long Press (2 Seconds): Press to play the default video at any interfaces.
- Operation Buttons**
Knob switch: Adjust volume (main interface), select number (other interfaces)
Short press: Adjust alarm volume and screen brightness level (main interface) confirm selection (other interfaces) Long press: Bluetooth search mode.
- Alarm Button**
Short press: Enter alarm 1, alarm 2, and scheduling alarm.
- Timer Button**
Short press: Enter Timer setting interface. Once time is set, it will turn on timer mode. Long press: Press the Timer button at anytime before the set time to cancel the existing timer.
- Micro USB Charging Port**
Icon explanation
- Bluetooth Status Icon**
The flashing icon means Bluetooth is pairing a static icon indicates that the Bluetooth is paired. Grey icon indicates Bluetooth is off.
- Alarm Status Icon**
A static icon indicates that the alarm is on; grey icon indicates that the alarm is off.
- Timer Status Icon**
A static icon indicates that the timer is on; grey icon indicates that the timer is off.
- Battery Status Indicator**
Each bar in the icon represents 20% of the battery. When the battery is less than 20%, please plug it in to charge. During the charging process, you will see the charging battery icon; when it is fully charged, a static icon will appear.

Function Description

- Turn on the device**
Turn on the device by switching the button. It'll enter standby mode in 30 seconds if not used. You can press any button to wake up the screen.
- Bluetooth Mode**
 - When power is on, the Bluetooth peripheral automatically pairing, a flashing Bluetooth icon will display at the time. Turn on Bluetooth on your second device and search for "TVBLDFREE". When they are paired, a static Bluetooth icon will appear.
 - Long press operation buttons for 2 seconds to disconnect the Bluetooth pairing and search for another device.
- Music Playing**
 - When the Bluetooth is successfully connected, you can play music on the connected device; use the button to adjust the volume.
 - If there are an incoming calls, the music will pause until the voice call ends.
- Adjust Alarm Volume**
 - Short press operation button at the main interface to enter the alarm volume interface. Use the function button to adjust the volume; there are eight levels to select.
- Screen Brightness Adjustment**
 - At the main interface, press the Short press control button twice to enter the screen brightness adjustment interface, use the function button to adjust the screen brightness, and there are eight levels to select.
- How to Set the Alarm and Record Notifications**
 - Alarm Setting**
 - Short press alarm button at any interface to enter alarm setting. Use the control button to select schedule alarms.
 - Enter alarm setting interface, open alarm 'On / Off' icon and set the alarm.
 - Turn the control button to select 'HOURS' or 'MINUTES' and short press the control key to make adjustments. When the alarm time is set, turn the control button to the 'Save / Return' icon, and short press the control button to save the alarm and return to the previous interface.
 - If the alarm 'On / Off' icon is off, turn the control button to the 'Save / Return' icon and then short press control button to return to the previous screen. The alarm will be off.
 - Record Alarm Notification Sound**
 - At the alarm interface, turn the control button to the 'record' icon and short press the control button to enter the record interface.
 - Short press control button to click on the 'record / pause' icon. You'll see the music playing reminder and can start recording after the reminder. The music played by the paired device or your recording will be used as the customized notification alert.
 - Short press the control button to pause the recording and press the control button again to continue recording.
 - Turn the control button to the 'playback' icon and short press control button to listen to the recording.
 - Note:** If you click 'return' at the recording interface without record your sound, the alarm will use the default notification tone.
 - Listen to the Recording**
 - Turn the control button to select the 'Save' icon. Short press control button to save the recording and return to the alarm setting interface.
 - Turn the control button to select 'Cancel' icon, short press the control button to return to the previous interface. The alarm will use the default notification sound.
 - Note:** Maximum time for customized recordings are 60 seconds.
- Clock Setting**
 - Short press alarm button to enter clock setting at any interface. Turn the control button to select clock setting and short press control button to confirm the corresponding setting.
 - Enter clock setting interface; the clock is displayed with a 24-hour format.
 - Select the 'HOURS' or 'MINUTES' and short press control button to set the hour and minute. Use the control button to select the desired time and press the control button to save the setting.
 - Turn the control button to the 'Save' icon to save the setting. Short press the control button to return to the previous interface.
 - Turn the control button to the 'return' icon and short press to return to the previous interface.
- Timer Setting**
 - Short press the timer button to enter the timer setting interface.
 - Turning the control button to 'MINUTES' or 'SECONDS' and short press control button to set timer.
 - When the timer is set, turn the control button to the 'Save' icon and short press the control button to start the countdown.
 - Short press timer button to return to the main interface and the timer will continue to run in the background.
 - Long press timer button to cancel the timer before the set time and return to the main interface.
- Timer**
 - When the timer rings, press any button to stop the timer. Timer will automatically ring for 5 minutes if no button is pressed.
- Snooze Mode**
 - Short press the antenna when the alarm goes off to enter snooze mode. Snooze will continue to repeat in 10 min increments if you keep pressing the antenna. Press any other button to stop snooze mode.
- Factory Setting**
 - Long press control button and timer button to return to the factory setting.

Remarks

- Please use a 5V / 1A adapter for charging.
- Playback duration: The playback duration depends on the volume, song, environment, as well as other factors.
- Audio QTV playback and phone volume can be adjusted separately.
- Speaker noise: Outside Noise may be generated if the speaker is not placed on a flat surface. Please select an appropriate location. The audio output may be distorted if playing at high volume or the battery power is too low. Please adjust the volume appropriately or timely charge the speaker.
- If you need to input the Bluetooth pairing code, the default Bluetooth pairing code is 0000 / 1234.
- Bluetooth authentication: The Bluetooth module of this device has passed BQB certification.
- Implementation standards: national standard GB8898-2011, GB / T13887-2012, GB / T625.1-2012.

■ PANTONE Black C
■ C:43 M:0 Y:100 K:0

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.