SLIM VIBE ONLY PAGER

INSTRUCTIONAL MANUAL

1. To Turn Pager ON

Press the button for more than 3 seconds at the side of pager

2. To Turn pager OFF

Press the button for more than 5 seconds at the side of pager

3. To stop the alert

Press the button shortly at the side of pager

4. Program-mining page alert mode

Pager will light up to tell you that they have received new message and pager will alert with the programmed alert type when receive a message

Alert Type	Description
9292	Vibe only
9797	Flash only
9898	Vibe, Flash and Beep
9696	Vibe and Flash
9595	Flash and Beep
9393	Turn out of range OFF
9494	Turn out of range ON
99	Sleep
9090	8 sec (alert time)-flash once
9091	15 sec (alert time)-flash two times
9092	30 sec(alert time)-flash three times
9093	60 sec (alert time))-flash once

WARRANTY

LeeTek warrants this product against any defects that are due to faulty material or workmanship for a one-year period after the original date of consumer purchase. This warranty does not include damage to the product resulting from accident, misuse or improper electrical connection. **Power supplies are warranted for 60 days. We recommend the use of a surge protector with all equipment**. If this product should become defective within the warranty period, we will repair or replace with equivalent product, free of charge. We will return your product, transportation charges prepaid standard shipping mode, provided the product is shipped prepaid to:

LEETEK, 3rd FL #499-2 Sang 3-dong, Wonmi-gu, Puchon-city, Kyunggi-do, KOREA

No return will be received without prior authorization and the proper RMA # posted to the outside of the shipping container.

This warranty gives you specific legal rights and you may also have rights which vary from state to state.

I need to send some transmitter in for repair - What do I do?

Within warranty period / Covered by our Product-Care Program:

Ship malfunctioning components to the following address:

 $3^{\rm rd}$ FL, #499-2 Sang 3-dong, Wonmi-gu, Puchon-city, Kyunggi-do, Korea

Tel: 82-32-678-8605 Fax: 82-32-324-9840

- 1. Pack the components securely
- 2. Enclose a note with a brief description of the problem
- 3. Include a business card
- 4. Ship the equipment in a traceable manner for your protection. (ie UPS).
- 5. Insure the shipment for replacement value.

There are no charges for repaired equipment within the warranty period, or if covered by Product-Care, other than your shipping costs. We will pay shipping one way back to you.

(Shipping by the courier service is available at an additional charge on request)

Out of warranty items will be repaired and sent back C.O.D.

Hints and Tips

Training is the key to success with a paging system.

Orientating your entire staff and training your host staff on the use of the paging system is key to the success of the system.

As a part of the general host training program, time must be set aside to teach new hires about the use and care of the paging system. Be certain staff members understand the importance of asking for the transmitter back after work.

Benefits of a VISUAL paging system

Staff members are alerted thru the pager and know to quickly close the tab of a guest to help speed table turns.

FCC NOTICE

THIS DEVICE COMPLIES WITH PART 15 OF THE FCC RULES.

OPERATION IS SUBJECT TO THE FOLLOWING TWO CONDITIONS:

- (1) THIS DEVICE MAY NOT CAUSE HARMFUL INTERFERENCE, AND
- (2) THIS DEVICE MUST ACCEPT ANY INTERFERENCE RECEIVED, INCLUDING INTERFERENCE THAT MAY CAUSE UNDESIRED OPERATION.

NOTE: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.

LEE Technology Korea Co., Ltd.