

ThinkPad Helix, MT 3697, 3701

PN	CRU ID	Description
POWER ADAPTERS		
45N0290	1	Common Delta 45W 3pin <PRIMARY>
45N0292	1	Common Delta 45W 2pin <PRIMARY>
45N0294	1	Common Liteon 45W 3pin <SECONDARY>
45N0296	1	Common Liteon 45W 2pin <SECONDARY>
45N0298	1	Common Chicony 45W 3pin <SECONDARY>
45N0300	1	Common Chicony 45W 2pin <SECONDARY>
BLUETOOTH CARDS		
60Y3303	N	Bluetooth Card - Foxconn
60Y3305	N	Bluetooth Card - Liteon
04W3824	N	Bluetooth Card 4.0 Brazil PPB
WIRELESS LAN CARDS		
04W3769	N	Intel WLAN Adapter
04W3793	N	NFC WLAN Module
WIRELESS WAN CARDS		
04X3797	N	Ericsson C5621gw WWAN LGA Module
04W3784	N	Sierra EM7700 WWAN Module
ADAPTERS		
03X6601	1	Mini Display Port to VGA Adapter
04W6947	1	USB 2.0 Ethernet Adapter - External Cable
SUBCARDS		
04X0511	N	Tablet I/O Board
04X0524	N	Keyboard Dock I/O Board
BATTERIES		
45N1101	N	Base Built-in Battery, Simplo 4cell
45N1103	N	Tablet Built-in Battery, Simplo 3cell
04X0443	N	Backup Battery
PLANARS WITH DIGITIZER		
04X0357	N	Planar i5-3427U with AMT, TPM and Digitizer; Win 8 Pro
04X0358	N	Planar i5-3427U with AMT and Digitizer; Win 8 Pro
04X0359	N	Planar i5-3317U with TPM and Digitizer; Win 8 Pro
04X0360	N	Planar i5-3317U with Digitizer; Win 8 Pro
04X0363	N	Planar i5-3427U with AMT, TPM and Digitizer; Win 8 Std
04X0364	N	Planar i5-3427U with AMT and Digitizer; Win 8 Std
04X0365	N	Planar i5-3317U with TPM and Digitizer; Win 8 Std
04X0366	N	Planar i5-3317U with Digitizer; Win 8 Std
04X0369	N	Planar i5-3427U with AMT, TPM and Digitizer; No O/S
04X0370	N	Planar i5-3427U with AMT and Digitizer; No O/S
04X0371	N	Planar i5-3317U with TPM and Digitizer; No O/S
04X0372	N	Planar i5-3317U with Digitizer; No O/S
04X0711	N	Planar i5-3337U with TPM and Digitizer; Win 8 Pro
04X0712	N	Planar i5-3337U with Digitizer; Win 8 Pro
04X0713	N	Planar i5-3337U with TPM and Digitizer; Win 8 Std
04X0714	N	Planar i5-3337U with Digitizer; Win 8 Std
04X0715	N	Planar i5-3337U with TPM and Digitizer; No O/S

04X0716	N	Planar i5-3337U with Digitizer; No O/S
04X0837	N	Planar i7-3667U with AMT, TPM and Digitizer; Win 8 Pro
04X0838	N	Planar i7-3667U with AMT and Digitizer; Win 8 Pro
04X0839	N	Planar i7-3667U with AMT, TPM and Digitizer; Win 8 Std
04X0840	N	Planar i7-3667U with AMT and Digitizer; Win 8 Std
04X0841	N	Planar i7-3667U with AMT, TPM and Digitizer; No O/S
04X0842	N	Planar i7-3667U with AMT and Digitizer; No O/S
PLANARS WITH NO DIGITIZER		
04X1623	N	Planar i7-3667U with AMT, TPM; No Digitizer; Win 8 Pro
04X1624	N	Planar i7-3667U with AMT; No Digitizer; Win 8 Pro
04X1625	N	Planar i5-3427U with AMT and TPM; No Digitizer; Win 8 Pro
04X1626	N	Planar i5-3427U with AMT; No Digitizer; Win 8 Pro
04X1627	N	Planar i5-3317U with TPM; No Digitizer; Win 8 Pro
04X1628	N	Planar i5-3317U No Digitizer; Win 8 Pro
04X1629	N	Planar i5-3337U with TPM; No Digitizer; Win 8 Pro
04X1630	N	Planar i5-3337U No Digitizer; Win 8 Pro
04X1631	N	Planar i7-3667U with AMT and TPM; No Digitizer; Win 8 Std
04X1632	N	Planar i7-3667U with AMT; No Digitizer; Win 8 Std
04X1633	N	Planar i5-3427U with AMT and TPM; No Digitizer; Win 8 Std
04X1634	N	Planar i5-3427U with AMT; No Digitizer; Win 8 Std
04X1635	N	Planar i5-3317U with TPM; No Digitizer; Win 8 Std
04X1636	N	Planar i5-3317U No Digitizer; Win 8 Std
04X1637	N	Planar i5-3337U with TPM; No Digitizer; Win 8 Std
04X1638	N	Planar i5-3337U No Digitizer; Win 8 Std
04X1639	N	Planar i7-3667U with AMT and TPM; No Digitizer; No O/S
04X1640	N	Planar i7-3667U with AMT; No Digitizer; No O/S
04X1641	N	Planar i5-3427U with AMT and TPM; No Digitizer; No O/S
04X1642	N	Planar i5-3427U with AMT; No Digitizer; No O/S
04X1643	N	Planar i5-3317U with TPM; No Digitizer; No O/S
04X1644	N	Planar i5-3317U No Digitizer; No O/S
04X1645	N	Planar i5-3337U with TPM; No Digitizer; No O/S
04X1646	N	Planar i5-3337U No Digitizer; No O/S
CABLES		
04X0509	N	DC-in Cable Assembly (including cable and bracket)
04X0525	N	Dock Connectors and Cables (includes both left and right cables)
CAMERAS		
04Y0114	N	Camera Assembly with Cable; Chicony <PRIMARY>
04Y0115	N	Camera Assembly with Cable; LiteOn <SECONDARY>
TABLET COVERS (includes speakers, label trays, and wireless antennas)		
04X0503	N	Tablet base cover assembly with WiFi Antenna
04X0504	N	Tablet base cover assembly with 3G Antenna
04X0505	N	Tablet base cover assembly with LTE Antenna
04X0506	N	Tablet base cover assembly with WiFi/NFC Antenna
04X0507	N	Tablet base cover assembly with 3G/NFC Antenna
04X0508	N	Tablet base cover assembly with LTE/NFC Antenna
04X0510	N	SIM Card Tray
KEYBOARD DOCK COVERS		
04X0520	N	Base Cover

04X0521	N	Dock and Hinge assembly back cover
04X0522	N	dock and hinge assembly
mSATA DRIVES		
04Y2139	N	mSATA 128GB Micron <PRIMARY>
45N8399	N	mSATA 128GB Toshiba <SECONDARY>
04Y2141	N	mSATA 256GB Micron <PRIMARY>
45N8401	N	mSATA 256GB Toshiba <SECONDARY>
45N8461	N	mSATA 180GB Intel
THERMAL ASSEMBLIES		
04X0431	N	Tablet Thermal/Fan Assembly (fan cable included)
04X0432	N	Thermal Fan Assembly for Keyboard Dock (fan cable included)
HINGES		
04X0523	N	Hinge (single hinge included)
KEYBOARD BASE ASSEMBLIES		
03X6843	N	FRU for Helix complete keyboard base - French
03X6844	N	FRU for Helix complete keyboard base - UK English
03X6845	N	FRU for Helix complete keyboard base – German
03X6583	N	FRU for Helix complete keyboard base – US English
KEYBOARDS		
04X0627	N	KBD USE CHY <PRIMARY>
04X0628	N	KBD CFR CHY <PRIMARY>
04X0629	N	KBD ARA CHY <PRIMARY>
04X0630	N	KBD BEL CHY <PRIMARY>
04X0631	N	KBD CZH CHY <PRIMARY>
04X0632	N	KBD DEN CHY <PRIMARY>
04X0633	N	KBD SPA CHY <PRIMARY>
04X0634	N	KBD FRA CHY <PRIMARY>
04X0635	N	KBD GER CHY <PRIMARY>
04X0636	N	KBD GRK CHY <PRIMARY>
04X0637	N	KBD HGN CHY <PRIMARY>
04X0638	N	KBD HBW CHY <PRIMARY>
04X0639	N	KBD ITA CHY <PRIMARY>
04X0640	N	KBD NET CHY <PRIMARY>
04X0641	N	KBD NOR CHY <PRIMARY>
04X0642	N	KBD POL CHY<PRIMARY>
04X0643	N	KBD POR CHY <PRIMARY>
04X0644	N	KBD RUS CHY <PRIMARY>
04X0645	N	KBD SLK CHY <PRIMARY>
04X0646	N	KBD SCB CHY <PRIMARY>
04X0647	N	KBD SWE CHY <PRIMARY>
04X0648	N	KBD SWS CHY <PRIMARY>
04X0649	N	KBD TUR CHY <PRIMARY>
04X0650	N	KBD UKE CHY <PRIMARY>
04X0651	N	KBD USI CHY <PRIMARY>
04X0652	N	KBD ICE CHY <PRIMARY>
04X0653	N	KBD BUL CHY <PRIMARY>
04X0654	N	KBD JPN CHY <PRIMARY>
04X0655	N	KBD TWN CHY <PRIMARY>

04X0656	N	KBD THA CHY <PRIMARY>
04X0657	N	KBD KOR CHY <PRIMARY>
04X0658	N	KBD IND CHY <PRIMARY>
04X0659	N	KBD LAS CHY <PRIMARY>
04X0660	N	KBD BRA CHY <PRIMARY>
04X0661	N	KBD CFA CHY <PRIMARY>
04X0662	N	KBD CFB CHY <PRIMARY>
04X0663	N	KBD USE SRX <SECONDARY>
04X0664	N	KBD CFR SRX <SECONDARY>
04X0665	N	KBD ARA SRX <SECONDARY>
04X0666	N	KBD BEL SRX <SECONDARY>
04X0667	N	KBD CZH SRX <SECONDARY>
04X0668	N	KBD DEN SRX <SECONDARY>
04X0669	N	KBD SPA SRX <SECONDARY>
04X0670	N	KBD FRA SRX <SECONDARY>
04X0671	N	KBD GER SRX <SECONDARY>
04X0672	N	KBD GRK SRX <SECONDARY>
04X0673	N	KBD HGN SRX <SECONDARY>
04X0674	N	KBD HBW SRX <SECONDARY>
04X0675	N	KBD ITA SRX <SECONDARY>
04X0676	N	KBD NET SRX <SECONDARY>
04X0677	N	KBD NOR SRX <SECONDARY>
04X0678	N	KBD POL SRX <SECONDARY>
04X0679	N	KBD POR SRX <SECONDARY>
04X0680	N	KBD RUS SRX <SECONDARY>
04X0681	N	KBD SLK SRX <SECONDARY>
04X0682	N	KBD SCB SRX <SECONDARY>
04X0683	N	KBD SWE SRX <SECONDARY>
04X0684	N	KBD SWS SRX <SECONDARY>
04X0685	N	KBD TUR SRX <SECONDARY>
04X0686	N	KBD UKE SRX <SECONDARY>
04X0687	N	KBD USI SRX <SECONDARY>
04X0688	N	KBD ICE SRX <SECONDARY>
04X0689	N	KBD BUL SRX <SECONDARY>
04X0690	N	KBD JPN SRX <SECONDARY>
04X0691	N	KBD TWN SRX <SECONDARY>
04X0692	N	KBD THA SRX <SECONDARY>
04X0693	N	KBD KOR SRX <SECONDARY>
04X0694	N	KBD IND SRX <SECONDARY>
04X0695	N	KBD LAS SRX <SECONDARY>
04X0696	N	KBD BRA SRX <SECONDARY>
04X0697	N	KBD CFA SRX <SECONDARY>
04X0698	N	KBD CFB SRX <SECONDARY>
LINE CORDS		
42T5004	1	US/Canada-1.0M
42T5008	1	US/Canada-1.0M
42T5014	1	Japan-1.0M
42T5020	1	Argentina-1.0M

42T5029	1	Europe-1.0M
42T5035	1	UK-1.0M
42T5041	1	Denmark-1.0M
42T5044	1	SWS-1.0M
42T5047	1	Italy-1.0M
42T5050	1	ANZ-1.0M
42T5056	1	SA-1.0M
42T5062	1	Israel-1.0M
42T5065	1	China-1.0M
42T5071	1	Taiwan-1.0M
42T5077	1	Korea-1.0M
42T5083	1	India-1.0M
42T5180	1	Brazil-1.0M 2p
LCD'S (includes LCD cable and LCD Bezel)		
04X0373	N	AUO 11.6 FHD LCD + Touch
04X0374	N	AUO 11.6FHD LCD + Touch + Digitizer
DIGITIZER PEN		
04X0381	1	Tablet Digitizer Stylus Pen
RECOVERY MEDIA		
04T8739	1	Win8_64 CT/EN
04T8740	1	Win8_64 CZ/EN
04T8741	1	Win8_64 EI
04T8742	1	Win8_64 FR
04T8743	1	Win8_64 GK/EN
04T8744	1	Win8_64 GR
04T8745	1	Win8_64 HB/EN
04T8746	1	Win8_64 HK/EN
04T8747	1	Win8_64 HU/EN
04T8748	1	Win8_64 JP
04T8749	1	Win8_64 KR/EN
04T8750	1	Win8_64 PL
04T8751	1	Win8_64 PO/EN
04T8752	1	Win8_64 RO/EN
04T8753	1	Win8_64 SK/EN
04T8754	1	Win8_64 SP
04T8755	1	Win8_64 UD
04T8756	1	Win8_64 US
04T8757	1	Win8_64 C&L Nordics
04T8758	1	Win8_64 C&L EMEA
04T8759	1	Win8_64 C&L Croatian
04T8760	1	Win8Pro64 AR/EN
04T8761	1	Win8Pro64 BR
04T8762	1	Win8Pro64 CS
04T8763	1	Win8Pro64 CT/EN
04T8764	1	Win8Pro64 CZ/EN
04T8765	1	Win8Pro64 EI
04T8766	1	Win8Pro64 FR
04T8767	1	Win8Pro64 GK/EN

04T8768	1	Win8Pro64 GR
04T8769	1	Win8Pro64 HB/EN
04T8770	1	Win8Pro64 HK/EN
04T8771	1	Win8Pro64 HU/EN
04T8772	1	Win8Pro64 JP
04T8773	1	Win8Pro64 KR/EN
04T8774	1	Win8Pro64 PL
04T8775	1	Win8Pro64 PO/EN
04T8776	1	Win8Pro64 RO/EN
04T8777	1	Win8Pro64 RU
04T8778	1	Win8Pro64 SK/EN
04T8779	1	Win8Pro64 SP
04T8780	1	Win8Pro64 SR/EN
04T8781	1	Win8Pro64 TR/EN
04T8782	1	Win8Pro64 UD
04T8783	1	Win8Pro64 US
04T8784	1	Win8Pro64 C&L Nordics
04T8785	1	Win8Pro64 C&L EMEA
04T8786	1	Win8Pro64 C&L Croatian
04T8787	1	Win8SL64 AR/EN
04T8788	1	Win8SL64 BR
04T8789	1	Win8SL64 EI
04T8790	1	Win8SL64 FR
04T8791	1	Win8SL64 PO/EN
04T8792	1	Win8SL64 RU
04T8793	1	Win8SL64 SP
04T8794	1	Win8SL64 SR/EN
04T8795	1	Win8SL64 TR/EN
04T8796	1	Win8SL64 US
04T8797	1	Win8China64 CS
MISC AND OTHER		
04X0527	N	Label kit for bottom cover (shipped with base cover; can be ordered separately)
04X0519	N	Pad Miscellaneous kit
04X0526	N	Base Assembly Misc kit
04X3790	N	Kensington Lock Bar (includes 10 lock bars)