

# Lenovo IdeaPad U330

## Setup Poster v1.0



Read the safety notices and important tips in the included manuals before using your computer.


**lenovo**

ideapad


### Initial setup instructions

#### 1 Install battery pack


Unlock both switches and insert the battery pack. After inserting the battery pack, make sure both switches are in the lock position.



#### 2 Connect to the power



#### 3 Turn on the Power



#### 4 Configure the Operating System following on-screen instructions

Slide your finger across the TouchPad surface to move the cursor. Click the left button to select items.




### Supplied software

#### VeriFace™

VeriFace is a face recognition software which takes a digital snapshot, extracts key features of your face, and creates a digital map that becomes the system's "password".

#### OneKey Rescue System

OneKey Rescue System is an easy-to-use system which includes several applications to help you detect and remove viruses, and recover Windows system and personal data.

You can press OneKey Rescue System button  to activate OneKey Rescue System when your PC is turned off. Within the program, you can upgrade the virus definition and use antivirus tools, repair system kernel files, restore your system partition to the original factory status or to a previously generated backup. You may also transfer critical data or documents to other storage devices. All these features make OneKey Rescue System an important utility to secure your data.

#### EasyCapture

EasyCapture helps you to make entertaining mug shots and videos with the integrated camera on your computer.

#### Energy Management

Energy Management manages your computer's power supply. It makes your computer work effectively at a low energy cost according to different modes.

#### Power2Go

Power2Go is software for burning data, music, videos and photos onto CDs, DVDs.

#### Norton Internet Security

Norton Internet Security is the latest product launched by Symantec in 2008. It is customized against the latest threats to network safety that concern the user, and includes features like anti-virus, firewall, anti-spyware, privacy protection and anti-phishing.

#### Adobe Reader

Adobe Acrobat Reader is software for viewing PDF files. With its snapshot tool and text selector, you can copy the content into various editing softwares.

#### ReadyComm

ReadyComm is a software for intelligent wireless connection configuration and safe, quick resource sharing.

Lenovo, lenovo logo, IdeaPad, VeriFace, OneKey Rescue (OneKey Recovery, OneKey AntiVirus), APS, Power Express, Energy Management and ReadyComm are either registered trademarks or trademarks of Lenovo in the United States and/or other countries.

© Copyright Lenovo 2008 All rights reserved.

### Unpack

Computer



Battery pack



AC adapter



Power cord



Remote



(Specific models only)

Manuals



- Setup Poster  
- User Guide  
- Other publications

① Some models may contain items that are not listed.

② If any item is missing or damaged, please contact your retailer.



③ Everything for recovering factory-installed files and applications is on your hard disk eliminating the need for a recovery disc. For more information, see the included manuals.




P/N:148000486  
Printed in China

# Buttons and functions


















## Power button / OneKey Rescue System button

-  Start the computer.
-  Repair windows system kernel files or restore system to its original state in case of an unrecoverable error.

## Fn key

-  Use in combination with other keys to access special features.

## Function key combinations +

- |   |   |
|---|---|
|  Turn on/off integrated camera.                    |  Enter sleep mode.                           |
|  Turn on/off the LCD screen.                       |  Choose the display scheme.                  |
|  Select the aspect ratio.                        |  Turn on/off the wireless device function. |
|  Enable/disable TouchPad.                        |  Play/Pause                                |
|  Stop  |  Previous                                  |
|  Next  |   |
|  Switch between character or numeric input mode. |  Activate the system request.              |
|  Stop the scrolling of text.                     |  Activate the break function.              |
- 
- |   |   |
|---|---|
|  Adjust the volume |  Adjust the display brightness |
|---|---|






## Integrated camera

The integrated camera offers an improved notebook experience for video-centric applications.





## Wireless LAN antennas

An isotropic antenna system is built into the display for optimal reception, enabling wireless communication wherever you are.






## Touch Inductive panel

-  Switch between Multi-media control and Equalizer buttons.
-  Mute
-  Open the User Define Utility.
-  Open the Dolby function setup screen.
-  Adjust the volume.


## Multi-media control buttons

-  Play / Pause
-  Stop
-  Previous
-  Next

## Equalizer buttons

-  Jazz
-  Pop
-  Dance
-  Classical
-  Normal

## Wireless device switch

-  Turn on/off both Wireless LAN and Bluetooth.

\* The illustrations in this manual may differ from the actual product.