

The best tool to follow up TV plays

Structure diagram

Parameters

Dimensions

Weight

Charge battery, view battery level, press for 1s

WiFi on: press and hold for 5s until the blue WiFi indicator remains on.

WiFi off: press and hold for 5s until the blue WiFi indicator turns off.

Turn off WiFi by force

Power output

Power input

Power indicator – white, power level indicator by 4 different levels

WiFi indicator – blue, WiFi working state indicator

Direction for use

### 1.1 Charging Moovid

Connect Moovid to power source via USB cable, the battery level indicator flashes, showing that Moovid is being charged.

### 1.2 Prepare WiFi network

Moovid requires WiFi network to access to Internet; please prepare an available Wifi network.

### 1.3 Installing App

Visit App downloading page by your mobile phone and select proper version to install. Don't click the App as soon as it is downloaded.

Method 1: scan the QR code

Method 2: visit <http://app.wefi.com.cn> by mobile phone browser.

### 2.1 Power on

Press and hold the Power key for 5s, the WiFi indicator flashes, and the system starts up; when start-up completes, the WiFi indicator will remain in blue.

### 2.2 Connect to Moovid WiFi

Moovid provides a default WiFi network named “WeFi\_XXXXXX”, no passport required.

Connect to the Wifi network by your mobile phone, the blue Wifi indicator will flash.

### 2.3 Initialization

Start the installed Moovid App, it will go to Initialization Wizard automatically. Set username and password according to the prompt. After initialization, Moovid will restart and create a new Wifi network with the username and password you have just set.

Connect to the new Wifi network of Moovid by your mobile phone, start Moovid App to enter home interface.

2.4 Before using the App, we need to access Moovid to Internet. Go to Moovid page and select “Internet”, then click “wireless relay”; select the Wifi network you prepared in 1.2 from the list; enter password if required.

### 3.1 Follow-up setting

When Moovid is accessed to Internet, go to “My TV Plays” page, click the Add button in the top right corner of the screen to enter the list of TV plays. Select some of your favorite American TV plays in the list and click “Follow-up” button, they will be added into your list of TV plays. If there is new episode of the TV plays in the list, Moovid will update the new episode synchronously for you to view via App.

### 3.2 Customized downloading

You can download any published TV plays and view off line.

### 3.3 Download management

Click the “Download” icon in the top right corner of My TV Plays page to go to Download page. Here you can see the list of TV plays being downloaded. You can pause or delete the item in the list.

### 3.4 Play video

When the video is downloaded by Moovid, you can view it off line any time by App on bus or on metro. Click the name of the TV play in the list, you will see the list of all episodes of the play, and you can click the episode marked with New to view.

## **FCC STATEMENT :**

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

**Warning:** Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and receiver.

- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

- Consult the dealer or an experienced radio/TV technician for help.

## **RF warning statement:**

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.