


Quick Start



LG **G** *Flex*





AT&T Ready2Go



Set up your device quickly and easily by using Ready2Go:

- Set up Email accounts and Facebook®
- Sync your contacts and calendar
- Connect to Wi-Fi®

You can use Ready2Go when you first activate your device or open it later from the app tray. The wizard will guide you through the setup process.



Note: To skip the wizard, tap **Remind Later** > **exit**. To return to the wizard from the home screen, tap  > .

Customize Your Phone


Customize your phone by adding shortcuts to apps and widgets to your phone's home screen.



Home screen

- ① Press and hold an empty spot on a home screen and choose a category:
 - **Apps:** Add shortcuts from the app tray.
 - **Widgets:** Add dynamically updating widgets.
 - **Wallpapers:** Change your wallpaper.
- ② To move an item, press and hold it and drag it to a new location. To delete it, drag it to **Remove**.



Knock Code™

- ① From the home screen, press  and tap **Lock screen settings > Select screen lock > Knock Code**.
- ② Enter a pattern of 2-8 taps. You can tap the same quarter more than once in a row. Tap **Continue**.
- ③ Enter the pattern again and tap **Confirm**.
- ④ Enter a backup PIN of at least four digits and tap **Continue**.
- ⑤ Enter it again and tap **OK**.
- ⑥ When your phone is locked and asleep, tap your pattern on the screen to unlock it. You can tap anywhere on screen, i.e., full screen or a single corner.



Camera, Video, and Sharing Photos



Share photos


- ① Tap the thumbnail in the lower left of the screen.
- ② Tap .
- ③ Tap an option and follow on-screen instructions.




Settings


You can change ringtones, device language input, and much more.

Sounds

- ① From the home screen, press  and tap **All settings > Sound**.
- ② You can change your ringtones, set notification sounds, adjust your touch feedback options, and more.

Device language

- ① From the home screen, press  and tap **All settings > General > Language & input**.
- ② To change the device language, tap **Language**.
- ③ Tap the desired language.




Calls and Voicemail



Note: To reset your voicemail password, go to att.com/resetvm.

Email



Note: Consult your IT department for more information when setting up an Microsoft® Exchange account.

Web



Enter a web address or search terms

Go forward a page

Go back a page

Refresh the page

Create a new browser window



Access the Browser Bar

Access bookmarks, browser settings, tabs, and more


Note: To disable the Browser Bar, swipe up on  > **Toolbar**.

QuickTheater



Access YouTube™ and your photos and videos all in one place with QuickTheater.

You can access QuickTheater from the swipe lock screen by turning the phone to landscape position and dragging both thumbs apart toward the edges of the screen.



View your
photo library

Go to the YouTube
home page

View your
video library



Voice Mate





Voice Mate allows you hands-free interaction with your device. You can ask Voice Mate to perform phone functions using your voice, such as calling a contact, setting alarms, or searching the web.




QSlide Function

The QSlide function enables an overlay on your phone's display for easy multitasking. You can open two QSlide apps on top of a third app from your library.

QSlide apps



View the application in full screen mode



Close the application


Slide to adjust transparency

Dual Window

Interact with two apps at once. To launch Dual Window, press and hold .


Tap to open your two most recently used apps

Tap or drag the icon you want to use



Slide Aside

Slide Aside allows you to quickly switch between three open applications (or tasks) using a three-finger gesture. Swipe left to save an app and swipe right to access saved apps.




Note: Some apps may restart when brought back later.

AT&T DriveMode®





When your vehicle is in motion, automatically respond to incoming calls, texts, and emails.



AT&T DriveMode is free to AT&T customers. Standard data and messaging rates apply to auto-reply messages.


Wi-Fi and Bluetooth®

Connect to Wi-Fi

- ① From the home screen, press  and tap **All settings** > **Networks** > **Wi-Fi**.
- ② Tap  to turn on Wi-Fi.
- ③ Tap a network name. Enter a password if required and then tap **Connect**.


Use Bluetooth


- ① Swipe down on the top of the screen to open the Notifications Panel.
- ② Tap **Bluetooth** to enable or disable *Bluetooth*.




Network Indicators

Your 4G LTE wireless device will indicate which of the AT&T wireless networks you are connected to. A network indicator does not necessarily mean that you will experience any particular upload or download data speeds.

 **4G LTE:** Connected to the AT&T 4G LTE network.

 **4G:** Connected to the AT&T HSPA+ network. The AT&T HSPA+ network is capable of delivering 4G speeds when combined with enhanced backhaul. 4G availability is increasing with ongoing backhaul deployment.

 **E:** Connected to the AT&T EDGE/2G network.


Actual data upload and download speeds depend on various factors, including the device, network utilization, file characteristics, terrain, etc. Learn more at: wireless.att.com/learn/articles-resources/wireless-terms.jsp, your AT&T Wireless Customer Agreement, Section 3.2 "Where and How Does AT&T Service Work?"

4G LTE not available everywhere. LTE is a trademark of ETSI. Learn more at att.com/network.

Google Play Store



Once you have set up your Google™ account, you can download apps, music, movies, and more from the Play Store.



Notes:

- To purchase a paid app, you will need to set up a payment method with Google Wallet™.
- You may want to download apps over Wi-Fi to save on your data plan usage.

AT&T Services



myAT&T: Track your usage, review and pay your bill, and update your data plan services.



AT&T Navigator®: Get voice-guided, turn-by-turn driving directions and traffic updates.



AT&T Smart Wi-Fi: Maximize your battery performance and data plan, simplify access to AT&T Hot Spots and Wi-Fi networks, automate your Wi-Fi connections, and track your data usage.



Mobile Hotspot: Share your mobile network data connection with other Wi-Fi devices.



AT&T Locker™: Safely store and share all your photos, videos, and documents with up to 5 GB of free storage.

Data rates may apply. AT&T Navigator requires a separate subscription.

Find More Information

On your phone

- Tutorials and videos: **Apps > Device Help**
- Access your account: **Apps > myAT&T**

On the Web

- Tutorials and videos: **att.com/DeviceHowTo**
- Manage your wireless account, including suspending service if your phone is stolen: **att.com/MyATT**

Give us a call

- **1-800-331-0500**
- **611** from any AT&T wireless phone

Accessories

- **att.com/WirelessAccessories**
- Visit your AT&T store

Portions © 2014. LG, LG Life's Good, and the LG logo are registered trademarks of LG Corp. Portions © 2014 AT&T Intellectual Property. All rights reserved. AT&T, the AT&T logo and all other AT&T marks contained herein are trademarks of AT&T Intellectual Property. All other marks contained herein are the property of their respective owners.