

QUICK START GUIDE

# LG ENVOY™ III

U.S. Cellular® Customer Care:  
1-888-944-9400



# Getting to Know Your Phone




# Calls

The large keys on the LG Envoy™ III make calling quick and easy.

## Make a Phone Call

1. From the home screen, begin dialing a number or start spelling the name of the desired contact.
2. Press **SEND** to call the number or highlight the contact you wish to call and press **OK**.





# Messages

When you need to communicate quickly and privately, use text messaging.

## Send a Message

1. From the home screen, press .
2. Enter the recipient's number or press the **Right Soft Key** for **Add** to select a number from your contacts or call log.
3. Scroll down to the text field, enter your message, and then press  for **Send**.

**NOTE** Please don't text and drive.



# Volume and Ringtones


Customize your phone by changing ringtones and alert sounds for a more personal touch.

## Adjust Volume

To adjust the master volume, from the home screen, press the **Volume Up/Down Keys**.

## Change Ringtone

1. From the home screen, press **OK** for **Menu**.
2. Select **Settings (9) > Sounds Settings (2) > Call Sounds (2) > Call Ringtone (1)**.
3. Choose from default ringtones or your own recordings.
4. Highlight a ringtone and press **OK** for **Set**.



# Contacts



The Envoy III has plenty of space to store your contacts' information.

## Add a Contact

1. From the home screen, press the **Right Soft Key** for **Contacts**.
2. Press the **Right Soft Key** for **Options**.
3. Select **New Contact (1)**.
4. Enter the contact's information and press **OK** for **Save**.

## Edit a Contact

1. From the home screen, press the **Right Soft Key** for **Contacts**. Select a contact and then press the **Left Soft Key** for **Edit**.
2. Change or add information as needed and press **OK** for **Save**.



# Camera

Capture every moment with the 1.3 megapixel camera.

## Take a Photo

1. From the home screen, press .
2. You may adjust settings such as white balance and brightness. Press the **Right Soft Key** for more options. Press  or  to take a photo.
3. To save your photo, press the **Left Soft Key** for **Save**.




# Browsing

Browse the web with ease on the Envoy III.

## Browse the Web

1. From the home screen, press **OK** for **Menu**.
2. Select **Browser (7)**.
3. If prompted, press **OK** for **Yes**.
4. Press the **Right Soft Key** for **Menu** and select **Go To URL (5)**.
5. Enter a web address, scroll down to **Go**, and press **OK**.
6. To exit the browser, press **END**.




## Browsing (continued)

Add bookmarks for quick access to frequently visited websites.

### Add and Use Bookmarks

1. Access the browser and navigate to a site you wish to bookmark.
2. Press the **Right Soft Key** for **Menu** and select **Bookmarks (4)**.
3. Press the **Left Soft Key** for **Select** to mark the site, scroll down to **Save**, and press **OK**.
4. To access a bookmarked site, press the **Right Soft Key** for **Menu** and select **Bookmarks (4)**.
5. Scroll down to the desired bookmark and press **OK**.



# Customize


Personalize your Envoy III by changing the wallpaper and home screen banner.

## Change Wallpaper

1. From the home screen, press **OK** for **Menu**.
2. Select **Settings (9)** > **Display Settings (3)** > **Wallpaper (4)** > **My Pictures (1)**.
3. Highlight an image and press **OK** for **Set**.

## Change Banner

1. From the home screen, press **OK** for **Menu**.
2. Select **Settings (9)** > **Display Settings (3)** > **Banner (1)**.
3. Enter a new banner and press **OK** for **Set**.





# Apps

Download applications and games from **easyedge**.

## Download Applications

1. From the home screen, press **OK** for **Menu**.
2. Press **OK** for **easyedge (5)**.
3. Press **OK** for **easyedge Shop**.
4. Choose to view the catalog, search for apps, or learn more about **easyedge**.




# Bluetooth® Wireless Technology

Connect to headsets, computers, and more via *Bluetooth* wireless technology.

## Connect to a Device

1. Place the *Bluetooth* device you wish to pair with in pairing mode. From the home screen, press **OK** for **Menu**.
2. Select **Bluetooth (0)** > **Bluetooth Menu (1)** > **Add New Device (1)**.
3. Press **OK** to begin searching for devices.
4. Highlight a device name and press **OK** for **Pair**.
5. Select **Yes** to connect to the device.





# Tone Room Deluxe

Download ringtones and ringback tones on your Envoy III.

## Download Ringtones

1. From the home screen, press **OK** for **Menu**.
2. Select **Tone Room Deluxe (\*)**.
3. Read the terms of service and press **OK** for **Accept**.
4. Select a category and then follow on-screen prompts to download ringtones and ringback tones.



All materials in this QSG including, without limitation, the design, the text, and any marks are the property of LG Electronics USA, Inc. Copyright © 2014 LG Electronics USA, Inc. ALL RIGHTS RESERVED. LG, LG Life's Good, and the LG logo are registered trademarks of LG Corp. Envoy is a trademark of LG Electronics, Inc. The *Bluetooth*® word mark and logos are registered trademarks owned by *Bluetooth* SIG, Inc. and any use of such marks by LG Electronics USA, Inc. is under license. **easyedge**<sup>SM</sup> is a service mark of U.S. Cellular. Other trademarks and trade names are those of their respective owners. Unless otherwise specified herein, all accessories referenced herein are sold separately. All features, functionality, and other product specifications are subject to change without notice. Screen shots are simulated and subject to change.



**LG**

Life's Good

[lg.com/us/envoylll](http://lg.com/us/envoylll)

P/N. MBM64776401

Printed in China