

Phone Overview

Most of what you need can be accessed from the Home screen canvases and three simple keys on the front of the device:

- **Menu Key:** Open available menu options.
- **Home Key:** Go to the Home screen.
- **Back Key:** Go back one screen or menu.



Setting Up Your Phone

Let's get you up and running.

**Caution**

Before assembling, charging, or using your phone for the first time, please read the important legal and safety information packaged with your product.



Using Your Phone

**Turning Your Phone On/Off**

- To turn your phone on, press and hold the **Power/Lock Key** for a couple of seconds until the screen lights up.
- To turn your phone off, press and hold the **Power/Lock Key** until the Phone options are displayed. Tap **Power off** > OK.

**Turning the Screen On**

- **Traditional Way:** To turn the screen on, press the **Power/Lock Key** once and the screen will light up.
- **KnockON Feature:** Quickly double-tap the center of the screen to turn the screen on.

**NOTE** The KnockON feature can be turned off in Settings. From the Home screen, tap **Apps** > **Settings** > **General tab** > **Gestures** > touch the **Screen on/off** checkbox.

Unlocking the Screen

**Using the Power/Lock Key**

1. Press the **Power/Lock Key** to turn on your screen. Your Lock screen will appear.
  2. Swipe in any direction to unlock it.
- OR**
- To use a shortcut, swipe the shortcut icon at the bottom of the screen in any direction. The screen will unlock and open the app.

**Unlocking the Screen Using the Knock Code Feature**

You can unlock the screen when the screen is off by tapping the correct area and sequence.

1. From the Home screen, tap **Apps** > **Settings** > **Display tab** > **Lock screen**.
2. Tap **Select screen lock** > **Knock Code**.
3. Follow the instructions to create your unlock sequence, as well as Backup PIN in case you forget your unlock sequence.

Using the Touchscreen

**Touch tips**

Use touch gestures to move around the screen, open menus, select items, zoom in or out on web pages, and more.

- **Swipe:** Swipe by quickly sliding your finger in any direction.
- **Drag:** Touch and hold an item and then slide it to a new position.
- **Double-Tap:** Tap two times rapidly to zoom in or out on a web page or picture.
- **Multi-touch:** Pinch or pinch open to zoom in or out.

**Notifications Panel**

Swipe down on the top of the screen to open the Notifications Panel.

- To respond to a notification, tap it.
- To remove a notification, swipe it left or right.
- To remove all notifications, tap **Clear**.
- Adjust the Quick Settings by tapping them (i.e., **Sound**).
- Tap **Settings** at the upper-right corner of the screen to access the Settings menu.

Selecting the Home screen mode

You can select one of the two modes: **Home** and **EasyHome**. Instructions in this guide are written based on the Home mode.

To change mode, tap **Apps** > **Settings** > **Display tab** > **Home screen** > **Select Home**.

- **Home mode:** Standard experience for users who are familiar with Android.
- **EasyHome mode:** Simplified and easier experience for the first time smartphone user.




Calls

You can dial phone numbers manually or make calls from your phone's memory. From the Home screen, tap **Phone** in the Quick Keys bar.

**Making a Call**

1. Tap **Phone** on the Home screen.
2. Enter the number you want to call.
3. Tap **Call** to place a call.

**TIP** During a call, press **Home** or tap **Back** to hide the active call screen and use other apps. To reopen it, touch **Phone**.




Messages

Your phone combines text and multimedia messaging into one intuitive, easy-to-use application.

**Sending a message**

1. From the Home screen, tap **Messaging** in the Quick Keys bar, then tap to create a new message.
2. Enter a contact name or contact number in the **To** field. You can touch a suggested recipient and add multiple contacts.
3. Enter the desired text and touch **Send**.


**NOTE** You will be charged for a message for every person you send the message to.



## Contacts

You can store names, phone numbers, and other information in your phone's memory. Use the **Contacts** app to add, view, and communicate with your friends, acquaintances, and associates.

**TIP** To quickly find a contact, use the alphabet letter list at the right of the contacts list. To search the list, just tap the **Search contacts** field and type a name.



## Google Account and Email

### Setting Up Your Google Account

Now your Gmail, Google contacts, and Google calendar events can all be loaded to your phone automatically.

1. From the Home screen, tap **Apps** > **Settings** > **General** tab > **Accounts & sync** > **Add account** > **Google** > **Existing** or **New**.
2. Enter your username and password or any other necessary information (if creating an account).
3. Tap the **Continue** button to sign in.

### Setting Up Other Email Accounts.

1. From the Home screen, tap **Apps** > **Settings** > **General** tab > **Accounts & sync** > **Add account**.
2. Tap **Email** and select the desired provider.
3. Enter your email address and password and any other necessary information.

## Camera and Video

### Taking a photo

1. From the Home screen, tap **Camera**.
2. Tap the **Shutter button** to take a photo.

• **Time catch shot:** Allows you to capture the missing moment by taking five sequential pictures at once prior to tapping the shutter button.

1. Tap **Camera** > **Mode** > **Time Catch Shot**.
2. Tap the **Shutter Button** to take a picture, then tap to review the missing moments.
3. Select the photos that you want to keep, then tap to save them.

### Recording a video

1. From the Home screen, tap **Camera**.
2. Tap and slide the **Mode switch** downwards and tap the **Record button** to record a video.

- Tap the **Pause button** to pause the recording.
- Tap the **Screen capture button** to capture a screen shot of the recording.
- Tap the **Stop button** to stop the recording.

## Web and Maps


### Browse web pages

The Chrome app allows you to access the Internet from your phone.

1. From the Home screen, tap **Chrome**.
2. Tap the URL input field to access a specific web page. Enter the web address (URL) of the webpage, the tap **Go** on the on-screen keyboard.
3. Tap the **Menu Key** to access Chrome options.

### Open the Maps app

The Maps app allows you to find places and get directions. From the Home screen, tap **Apps** > **Maps**.



## Apps

All of the apps on your phone, including any apps that you downloaded and installed from Play Store or other sources, are grouped together on the Apps screen, which you access from your Home screen. To open the Apps screen, tap **Apps** from the Home screen.

### Installing Apps

Play Store allows you to browse and search for free and paid apps.

1. From the Home screen, tap **Play Store**.
2. Tap a category from the homepage or tap the search icon to search for an app.
3. Tap the app you want, to view its details screen.
4. Tap **INSTALL** or the **Price** button to download an app.
5. If you agree with the app's access requirements, tap **ACCEPT**. The app will be downloaded and installed.

## Improving Accessibility

Adjust the accessibility settings to assist users who have impaired vision or hearing, or reduced dexterity.

1. From the Home screen, tap **Apps** > **Settings** > **General** tab > **Accessibility**.
2. Set the desired options to improve accessibility.

### Using TalkBack

TalkBack provides screen reading to assist people with impaired vision.

1. Tap **TalkBack**, then tap the **TalkBack** switch to turn it on.
2. Tap **Settings** at the bottom of the screen to adjust the TalkBack settings.

**NOTE** When TalkBack is on, tap an option once to highlight it, then double-tap it to select it. (You can change to single-tap in Settings.)

## QuickMemo

Use the **QuickMemo** feature to capture a screen shot and use it to write a memo.

1. Drag the Status bar downward, then tap the **QuickMemo** icon.
2. Tap an option from the tool bar to create your memo.

• **Overlay:** Tap to keep the memo on top and continue using other phone features.

- **Memo background:** Tap to choose the type of background you want to use.
- **Undo:** Tap to undo the most recent action.
- **Redo:** Tap to redo the action you just undid.
- **Pen:** Select the pen type, pen color, and the cropping tool.

- **Erase:** Erase pen marks using your fingertip.
- **Share:** Select how to share your memo.
- **Save:** Save the captured memo to your Gallery.

**NOTE** Use your fingertip rather than your fingernail to draw or erase pen marks.

### Viewing the saved QuickMemo

Open the **Gallery** and tap the **QuickMemo** album.


## QSlide

Use the **QSlide** feature to overlay apps on your phone's screen for easy multi-tasking.

1. Drag the Status Bar downward, then tap the desired app from the **QSlide apps** section.
2. Drag the title bar to move the app, or drag the bottom right corner to resize it.

- Tap to return to full window view.
- Slide to adjust transparency.
- Tap to exit the QSlide function.

Tap the desired app from the **QSlide apps** bar.



Life's Good