



In response to the increasing desire for improved health, personal balance and overall well-being, we developed the LifeWise brand of personal and home health products. This comprehensive suite of technologically advanced and easy-to-use products offers a variety of smart ideas designed to help keep you, your family and your home happier, healthier and more at ease.




**PLEASE READ AND SAVE THESE INSTRUCTIONS!**

**True HEPA Air Purifier  
63-1540**



**using your air purifier**



**before you begin**

Carefully unpack your Air Purifier. Select a flat, level, firm place where there are no obstructions to the air inlet or filtered air outlet. A good location in a room is approximately 1 foot away from the wall, in a central location of your home.

1. **Read all instructions before using appliance!**
2. Remove protective plastic bag from the filter cartridge.
3. Install the filter as shown in "Replacing your Filter."
4. Press **RESET** with a pointed object.

**product specifications**

Electrical.....	120 VAC, 60 Hz
Filter Size.....	4.95" x 14.4" x 1.5"
<b>Cleaning Coverage</b>	
Low Speed.....	CADR 60 (Approx 90 sq. ft.)
HighSpeed .....	CADR 100 (Approx 150 sq. ft.)
AC Power Cord .....	6 ft.
<b>AHAM Certification</b>	
Room Area .....	144sq. ft.
<i>Specifications are subject to change and improvement without notice. Individual units may vary.</i>	

**frequently asked questions**

**Why isn't my air purifier working?**

- Check to make sure unit is properly plugged in.
- Check to make sure the unit is on by pressing the power button.
- Make sure the plastic has been removed from the filter cartridge.

**My air purifier is on, but not much air is coming out. What's going on?**

- Check the filters to see if they are in good condition or if they need to be changed.
- Check to ensure nothing is blocking air inlet or filtered air outlet.
- Make sure the plastic has been removed from the filter cartridge.

Thank you for purchasing the LifeWise True HEPA Air Purifier. Your new True HEPA (High Efficiency Particulate Air) Purifier has an attractive, sleek, compact tower design. Its versatility and quiet operation make this unit perfect for both the home and office. It is 99.97% effective at removing particles such as bacteria, airborne allergens, cigarette smoke, pollen, dust, mold spores, and pet hair as small as 0.3 microns from the air that passes through the filter.



- For optimum air filtration, we recommend that you operate your air purifier continuously.
- For quieter operation or use in a bedroom, select **Low** speed. When high levels of air pollution are present, select **High** speed to quickly circulate and filter the room air.

**what's included**

- True HEPA Air Purifier
- Washable Foam Prefilter
- User's Guide
- HEPA filter

**limited 3-year warranty**


This product is warranted by RadioShack against manufacturing defects in material and workmanship under normal use for three (3) years from the date of purchase from RadioShack company-owned stores and authorized RadioShack franchisees and dealers. For complete warranty details and exclusions, check with your local RadioShack store.  
RadioShack Customer Relations  
200 Taylor Street, 5th Floor, Fort Worth, TX 76102  
04/04



Take the LifeWise Heart Truth Pledge and begin making one change a month to improve the health of you and your family.

## replacing the filter

1. Remove the air inlet grill and prefilter. If the HEPA filter is dirty, remove and properly dispose of it. **DO NOT** try to wash and re-use the HEPA filter.
2. Remove the protective polybag from your new filter. Position the filter so that the side with the soft gasket is facing inward. Insert the new filter.
3. Replace the prefilter and air inlet grill.



### NOTES

- Under normal conditions of continuous use, the HEPA filter will operate efficiently for 8 months.
- When you replace the filter, write the date on the sticker and attach the sticker to a visible location on the unit. In order to guarantee True HEPA efficiency, we strongly recommend that you replace the filter when the FILTER indicator turns red or the filter has been used for 8 months. Replacements (63-1550) are available at RadioShack or online at [radioshack.com](http://radioshack.com).
- Catalog number for replacement filter is 63-1550.
- Check the condition of the filter every few weeks.
- Reset the unit every time you replace the HEPA filter.

## important safety instructions

### NOTE

### **PLEASE READ AND SAVE THESE IMPORTANT SAFETY INSTRUCTIONS!**

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons, including the following:

1. Read all instructions before using appliance.
2. To avoid fire and shock hazard, plug the appliance directly into a 120V AC electrical outlet.
3. If the filter is covered by a bag when shipped, remove plastic bag before use.
4. Keep the cord out of heavy traffic areas. To avoid fire hazard, never put the cord near heat registers, stoves, heaters, or under rugs.
5. To protect against electrical hazards, do not immerse in water or other liquids. Do not use near water.
6. Close supervision is necessary when any appliance is used by or near children or disabled persons.
7. Always unplug the air purifier before moving it, opening the grill, changing the filters, and whenever the air purifier is not in use. Unplug by pulling on the plug and not the cord.
8. Never drop or insert any object into any openings.
9. Do not operate any appliance with a damaged cord or plug, if the motor fan fails to rotate, after the appliance malfunctions, or if it has been dropped or damaged in any manner. Return the appliance to the manufacturer for examination, electrical or mechanical adjustment, or repair.
10. Use appliance only for the intended household use as described in this manual. Any other use not recommended by the manufacturer may cause fire, electric

shock, or injury. The use of attachments not recommended or sold by RadioShack may be hazardous.

11. Do not use outdoors.
12. Never block the air openings or place on soft surfaces, such as a bed or sofa, as this could cause the unit to tip over, thus blocking the air intake opening.
13. Keep the unit away from heated surfaces and open flames.
14. Do not attempt to repair or adjust any electrical or mechanical functions on this unit. Doing so will void the warranty. The inside of the unit contains no user serviceable parts. All servicing should be performed by qualified personnel only.
15. **WARNING:** To reduce the risk of fire or electrical shock, do not use this air purifier with any solid-state control device.
16. Do not place anything on top of the unit.
17. This product is equipped with a polarized plug (a plug having one blade wider than the other). This plug will fit into the power outlet only one way. If the plug does not fit fully into the outlet, reverse the plug. If it still does not fit, contact qualified personnel to install the proper outlet. **Do not defeat the safety purpose of this polarized plug in any way!**

### **Cord and Plug Installation Safety Instructions**

We selected this length of cord for this appliance to reduce tangle and trip hazards. If you need to use a longer cord, use an approved extension cord. Make sure that the electrical rating of the extension cord is equal to or greater than the rating of the air purifier. Take care to arrange the extension cord so that it will not drape over a countertop or tabletop, or any place where it can be pulled on by children or accidentally tripped over.

## caring for your air purifier

- Keep the main housing of your air purifier dry. If it gets wet, wipe it dry immediately.
- Use and store the air purifier only in room temperature environments.
- Handle the air purifier carefully. Do not drop it.
- Turn off and unplug the unit before cleaning.
- Clean the outside of the air purifier with a soft, damp cloth.
- Dust off the top air outlet grill with a small, soft brush.
- To clean the air inlet grill, remove it and wash it in warm soapy water (not dishwasher safe). Dry before replacing in the unit.
- Periodically remove the air inlet grill. Remove and examine the foam pre-filter. If it has collected a noticeable amount of dust or lint, remove it from the inlet of the grill and wash it in warm soapy water. Rinse and drip-dry the pre-filter thoroughly before replacing it into the inlet of the grill.