



## I. Appearance & functions



- |   |                           |
|---|---------------------------|
| 1. Mode switch  | 7. Mic                    |
| 2. Volume down/Previous song  | 8. DC5V Input             |
| 3. Power on/off   | 9. TF                     |
| 4. TWS  | 10. USB/DC5V 300mA output |
| 5. Volume up/Next song  | 11. External audio input  |
| 6. Play or pause/answer a phone call<br>Reject the phone call/Make a phone call |                           |

## II. Instructions for use

Brief description of the function keys	
	Mode switch
	Volume down / Previous song
	Volume up / Next song
	Turn on/off the machine
	TWS sound box pairing function
	Play or pause/Answer a phone call Reject the phone call/Make a phone call
DC/5V	Micro USB charging jack
TF	TF music player
USB	USB music player/DC5V 300mA output
AUX	External sound source input jack

## 1. Bluetooth connection

- After entering the Bluetooth mode, the blue LED light will flash quickly. If the match is successful, the Bluetooth signal light will stay on. When playing Bluetooth music, the Bluetooth light will flash slowly. When the Bluetooth device is connected, it will display xxx (Bluetooth name) on the screen.
- Bluetooth playing**  
After the Bluetooth connection is successful, press the button to play/pause the music. Press to select the next song. Press to select the previous song. Press to pause the music being played, and press the button again to resume playing the music.
- Volume up/down -/+**  
When playing, long press to adjust the volume level.
- Previous or next song -/+**  
When playing, shortly press to go to the previous song or next song.
- Mute**   
When playing, shortly press to mute/pause the music.
- Turn on/off the machine**   
Long press turn on/off the machine.

## (7) Hands-free calling

- Answering a phone call: If someone calls you after the Bluetooth has been connected, the phone will automatically be connected. Shortly press the key to answer the phone call and shortly press the key to hang up the phone call (when you refuse to answer). After the call, the Bluetooth playing function will automatically resume.
- Making a phone call: After the Bluetooth has been connected, shortly press the button twice to dial the number of the last call made by your phone.

## 2. DC/5V charging

When charging, the white LED flashes, and then lights up, the unit becomes fully charged.

## 3. AUX input

After inserting the 3.5 stereo head line, the system will automatically enter the external AUX mode. Long press the button to adjust the volume level, and shortly press the button to mute the music being played.

## 4. TF USB

After inserting the TF USB card, the system will automatically enter the TF USB mode. Long press the button to adjust the volume level, shortly press the button to select the track, and shortly press the button to play or pause the music.

## 5. \* (MODE)

Shortly press the \* button successively to switch between the Bluetooth, USB, TF and AUX modes.

## 6. TWS sound box pairing function:

Switch on the two sound boxes simultaneously, and shortly press the button on one sound box to enter the TWS pairing mode, after which you will hear the prompt of successful pairing. Next, activate the bluetooth on the mobile phone to search for pairing of XX-XXX, and the 1+1 bluetooth play will be on the way.

## III. Specifications

Bluetooth technology	4.2 low power consumption
Acceptable distance	10M
Power	5W*2 + 15W*1
Impedance	4Ω
Speaker size	φ89mm/φ64m
Speaker	3
Frequency response	20-20,000Hz
Noise-signal ratio	70DB
Connection method	Bluetooth and AUX input
Physial dimension	L366*W138*H192mm
Battery	7.4V/400mAh
DC/5V	Input DC 5V/2000mA
Playing time	2-3H
Charging time	6-7H
USB TF	Player
AUX input sensitivity	300mv

## IV. Solutions to possible malfunctions

Phenomenon Malfunction	Solutions
Connection and pairing unsuccessful for many times	1. Check whether the device is in the search mode or restart the device. 2. Search difficulties occur because there are too many Bluetooth devices around. Turn off the other Bluetooth devices.
The sound too small or distorted	1. Check the volume of the Bluetooth device and adjust its volume to the appropriate position. 2. Low battery, please charge the device.
The music is interrupted	Check whether the paired device is beyond the effective connection distance of the speaker or there are obstacles between the speaker and the Bluetooth device.
The Bluetooth status indicator does not light	1. It indicates that the battery is low. Check again after charging the device. 2. Restart the device.

## V. Precautions

- Avoid placing the device in wet areas.
- Regularly charge the device at regular intervals.
- Do not touch the case using hard objects.
- Use the accessories equipped by our factory to charge the device.
- Do not use a damp cloth to wipe the device.
- The ios 9 system only be charged when it is powered on

## VI. Packing list

- Speaker: 1
- Charging line: 1
- Audio cable: 1
- Use's Manual: 1
- Certificate: 1

## VII. Warranty

### 1. Warranty regulations:

The warranty period of this product is valid for 12 months from the date of sale. In case of normal use and maintenance within the warranty period, if the hard materials and functions of the machine appear problematic due to non-human damage, preventing the machine from being used normally, the company will provide free maintenance service.

### 2. Paid warranty:

- Beyond the warranty period.
- The purchase voucher and warranty card could not be presented at the same time.
- Wrong use (e.g. over-pressure charging) or unauthorized removal or modification.
- Failure and damage caused by transport, dropping, or natural disasters.

### 3. Notes for Warranty:

Rong Li reserves the right to change the maintenance mode. If the product cannot be repaired in china, you may be required to bear the freight and handling fees. If you are looking for repair in a non-original country, you are required to comply with all applicable import and export laws and regulations and bear all customs duties, value added tax and other related taxes and charges.

# BS-888 User's Manual

## **FCC Statement**

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

To assure continued compliance, any changes or modifications not expressly approved by the party.

Responsible for compliance could void the user's authority to operate this equipment. (Example- use only shielded interface cables when connecting to computer or peripheral devices).

This equipment complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

## **FCC Radiation Exposure Statement:**

The equipment complies with FCC Radiation exposure limits set forth for uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.