PBT80





4 0 0

0

FRONT SIDE (front) 1. LED indicator + H (2) 3. [U]: Quick press - Play/pause ()) 5. USB charging port Powering ON/OFF

•Turn the earbuds ON by long pressing the [O] button. A

• Turn the earbuds OFF by long pressing the [the statement of the statemen

NOTE: After 15 minutes of inactivity, the earbuds will turn

•To end a call, quick press the [the left] button. Music playback

•To answer a phone call quick press the [6] button.

OFF automatically.


will automatically resume.

Answering Phone Calls

tone will be heard indicating that the earbuds are powered

tone will be heard indicating that the earbuds are powered

Attach the small end of the micro USB cable to the micro USB charging port on the side of the dongle. Attach the large end of the micro USB cable to your computer or other USB charging device. The LED indicator will turn RED while 2. [+]: Quick press - Skip to next track Long press - Increase volume Quick press - Answer/end call Long press - Power ON/OFF 4. [-]: Quick press - Skip to previous track Long press - Decrease volume



To enjoy music wirelessly on your Wireless Earbuds, make sure that

the earbuds are properly paired to your Bluetooth-enabled device. If you are pairing the device for the first time, please consult the "Pairing the Earbuds" section of this user guide.

Playing/Pausing Music

- Quick press the [O] button to pause the music.
- Quick press the [₺] button again to resume music playback.

- Skipping Songs
 Quick press the [] button to go to the previous song.
- Quick press the [+] button to go to the next song.

Adjusting the Volume

- Long press the [] to decrease the volume of music
- Long press the [+] to increase the volume of music playback.



- 1. Long press the [の] switch on the side of the earbuds. A tone will indicate that the earbuds are powered ON and in pairing mode and the LED indicator will slowly flash BLUE.
- 2. Set your Bluetooth-enabled device to search for Bluetooth
- 3. When your mobile phone (or other Bluetooth-enabled device) finds the earbuds, select "PBT80" from the list of found
- 4. After a successful pairing, a tone will indicate that the earbuds are connected and the LED indicator will slowly



This product as supplied and distributed new by ATI. Inc. ("ATI" to the original consumer purchaser is warranted by ATI against defect in material and overdmenship for a period of one year floor your date of purchaser. ("Marranto"), in the unlikely event that this product is defective, or does not perform properly, you may within one year from your original date of purchase return it to the authorized service center for regain or exchange.

- TO OSTAIN WARRANTY SERV.CE:

 Call the Customer Support number located below, or go to our website portal to receive an SRO number.

 Provide proof of the date of purchase within the package (dated bill of sale).

 Prepay all shipping costs to the authorized service center, and remember to insure your return.

 Recicular serum shipping address in POT Somes/a letelphone contact number, and the defective unit within the
- package.

 Describe the defect or reason you are returning the product.

Your product will be repaired or replaced, at our option, for the same or similar model of equal value if examination by the service center determines this product is defective. Products received damaged as a result of shipping, will require you to file a claim with the carrier.

The shipping address of the authorized service center is:

14-C 53rd Street Brooklyn, NY 11232

IN NO EVENT WILL AIT, ITS MANUFACTURERS, DISTRIBUTORS OR PLR IP HOLDINGS, LLC BE LIABLE FOR ANY INCIDENTAL.
DIRECT, INDIRECT, SPECIAL, PUNITIVE OR CONSEQUENTIAL DAMAGES (SUCH AS, BUT NOT LIMITED TO, DAMAGES FOR LOS
OF PROFTIS, BUSINESS, SAVINGS, DATA OR RECORDS) RELATED TO THE PRODUCT. EXCEPT AS STATED HEREIN, NO OTHER

