

Logitech® Cordless MouseMan® Optical

Getting Started Guide

1 Important Safety Information

Before using your mouse, please read the Comfort Guidelines that come with your product.

2 Install the Battery

1. Use your finger to remove the battery compartment cover.
2. Insert the battery. Follow the diagram inside the battery compartment.
3. Replace the cover.

3 Connect the Receiver


1. For installation on a PS/2 mouse port, turn off the computer. Connect the receiver cable to the PS/2 mouse port on the computer, then turn on your system.
2. For USB-PORT INSTALLATION (Windows® 98 or higher or Macintosh® OS 8.6 or higher required) REMOVE THE PS/2 ADAPTER. Connect the receiver cable to the USB port on the computer. For Windows, you may be prompted to insert the Windows software CD. Insert this software CD into the computer's CD-ROM drive when asked to do so, then follow the on-screen instructions.



USB Port



PS/2 Port



PS/2 Port Adapter

4 Install the Software

1. For PCs, start Windows®, insert the Logitech® software CD into the computer's CD-ROM drive, then follow the on-screen instructions. (If Autorun is not enabled, select Run from the Start Menu on the Taskbar. Next, type D:\Setup.exe, where D: is the designation of the CD-ROM drive.)
2. For the Macintosh®, start the Macintosh operating system, insert the Logitech software CD into the computer's CD-ROM drive, find the Installer icon in the appropriate language folder, double-click the icon, then follow the on-screen instructions.

English

中文

한국

5 Establish Communication between Mouse and Receiver

Press the connect button on the receiver, then press the connect button on the bottom of the mouse.

6 Battery Life

The surface on which you use the mouse can significantly affect battery life. Lighter surfaces extend battery life, darker ones shorten it. Bright, matt surfaces (not glossy ones) are recommended.

7 Get More Information!

To help you get the most from your mouse, a User's Guide is located on the Logitech® software CD. This User's Guide contains valuable information about your product, and it has Logitech world-wide addresses and telephone numbers. During software installation, this User's Guide is copied to your hard drive automatically.

For PCs

1. From the Windows® Taskbar, select **Start, Programs, Logitech®, MouseWare®, then User's Guide.**
2. **The User's Guide displays automatically. To view a topic, click one of the bookmarks listed on the left side of the title page.**

For Macintosh®

1. **On your desktop, find the MouseWare® folder, then open the folder by double-clicking it.**
2. **Find the icon for the User's Guide, then double-click the icon to open the document.**

8 Troubleshooting

The Mouse Does Not Work after Installation or Is Not Detected

- Make sure you have connected the receiver correctly. The receiver cable goes into the computer's USB port or PS/2 mouse port. For optimal performance, place the receiver at least 8 inches or 20 centimeters away from other electrical devices, such as the computer, the computer monitor, or external storage drives. If you are working on a metallic surface, try turning the receiver on its side for better reception.
- For PCs, make sure the PS/2 mouse port has the proper configuration. Refer to your computer documentation for the correct port configuration. You may also have other system devices that conflict with the mouse. Check the IRQ/address settings of these devices for conflicts, and change the settings as required.
- Establish communication between the receiver and the mouse. Press the Connect button on the receiver, then press the Connect button under the mouse.
- Make sure you have installed the battery correctly.
- Try unplugging then reconnecting the receiver cable to the computer.

羅技® 無線飛貂™ 極光版滑鼠

使用說明

1 重要安全資訊

在開始使用您的滑鼠之前，請先閱讀產品包裝內的「舒適指南」手冊。

2 安裝電池

1. 將電池槽的蓋子用手指移開。
2. 將電池放入。請按照電池槽內的圖示放入電池。
3. 將蓋子蓋上。

3 連接接收器

1. 若安裝於 **PS/2 滑鼠連接埠**，請先關閉電腦電源。將接收器的電纜線連接到電腦的 PS/2 滑鼠連接埠，然後啟動系統。
2. 若安裝於 **USB 連接埠** (Windows® 98 或更新版本，或 Macintosh® OS 8.6 或更新版本)，請移除 **PS/2 連接埠轉接器**。將接收器的電纜線連接到電腦的 USB 埠。在 Windows 系統中安裝時，可能會提示您放入 Windows 軟體光碟。請依提示將軟體光碟放入光碟機中，然後依照畫面上的指示進行。



4 安裝軟體

1. 在 **PC** 平台上安裝時，請先啟動 **Windows®**，再將羅技® 軟體光碟放入電腦光碟機中，然後依照畫面上的指示進行。(如果無法自動執行，可以從工作列上的 [開始] 功能表中選取 [執行]，然後輸入 D:\Setup.exe，D: 是光碟機的代號)
2. 在 **Macintosh®** 平台上安裝時，請先啟動 **Macintosh** 作業系統，再將羅技軟體光碟放入電腦光碟機中，接著在適當的語言資料夾中找到「安裝程式」圖示，按兩下圖示，然後依照畫面上的指示進行。

English

中文

한국

5 建立滑鼠與接收器間的通訊

請先按下接收器上的連接按鈕，再按滑鼠底部的連接按鈕。

6 電池壽命

您在什麼樣的表面上使用滑鼠，會大大影響電池的壽命。比較明亮的表面，會延長電池的壽命，而較暗的表面則會縮短電池壽命。建議在明亮、無光澤的表面上使用。

7 取得更多資訊！

羅技® 軟體光碟內有一份可以幫助您完整發揮滑鼠功能的使用手冊。這本手冊的內容包括了產品的重要相關資訊，以及羅技全球客戶服務中心的地址與電話。手冊的內容會在軟體進行安裝時自動複製到您的硬碟中。

PC 平台

1. 在 Windows® 工作列中選取 [開始]，按一下 [程式集]，然後選取 [Logitech®]，按一下 [MouseWare®]，然後選擇 [使用手冊]。
2. 使用手冊會自動顯示。若要檢視主題，按一下標題頁左側列出的任一書籤。

Macintosh® 平台

1. 在桌面上找到 MouseWare® 資料夾，然後在資料夾上按兩下滑鼠，開啟資料夾。
2. 找到「使用手冊」圖示，然後按兩下圖示，開啟文件。

8 簡易故障排解

安裝後無法使用或偵測不到滑鼠

- 請確認已正確連接接收器。接收器的電纜線需連接到電腦的 USB 埠或 PS/2 滑鼠連接埠。為了達到最好的效能，請將接收器放在距離其他電器設備（例如電腦、電腦螢幕或外接式儲存設備）至少 8 英吋或 20 公分以上的地方。如果在金屬表面上操作，請將接收器轉向接收較好的方向。
- 在 PC 平台上安裝時，請確認 PS/2 滑鼠連接埠已正確設定。請參閱電腦使用手冊，取得正確的通訊埠設定方式。可能有其他的系統裝置與滑鼠衝突。請檢查這些衝突裝置的 IRQ 位址設定，並依需要變更設定。
- 建立接收器和滑鼠間的通訊。按下接收器上的連接按鈕，然後再按滑鼠底部的連接按鈕。
- 請確定已正確安裝電池。
- 請將連接電腦和滑鼠的電纜線拔掉，再重新接上。

Logitech® Cordless MouseMan® Optical

설치 안내서


1 중요한 안전 정보

마우스를 사용하기 전에 제품과 함께 제공되는 Comfort Guideline을 읽어 보십시오.

2 건전지 삽입

1. 손가락을 사용하여 건전지함 덮개를 떼냅니다.
2. 건전지를 넣습니다. 건전지함 안쪽에 있는 그림대로 따라 하면 됩니다.
3. 덮개를 씌웁니다.

3 리시버 연결

1. **PS/2 마우스 포트에 설치하는 경우 컴퓨터 전원을 끕니다.** 리시버 케이블을 컴퓨터의 PS/2 마우스 포트에 연결한 다음 시스템을 켭니다.

2. **USB 포트에 설치(Windows® 98 이상 또는 Macintosh® OS 8.6 이상 필요)하는 경우에는 PS/2 어댑터를 제거합니다.** 리시버 케이블을 컴퓨터의 USB 포트에 연결합니다. Windows의 경우 Windows CD를 삽입하라는 메시지가 표시될 것입니다. 메시지가 표시되면 Windows CD를 컴퓨터 CD-ROM 드라이브에 삽입한 후 화면의 지시에 따릅니다.

4 소프트웨어 설치

1. **PC의 경우 Windows®를 시작하고 Logitech® 소프트웨어 CD를 컴퓨터 CD-ROM 드라이브에 넣은 다음 화면의 지시에 따릅니다.** 자동 실행 기능이 활성화되지 않은 경우 작업 표시줄의 시작 메뉴에서 실행을 선택합니다. 그런 다음 D:\Setup.exe를 입력합니다. 여기서 D:는 CD-ROM 드라이브를 나타냅니다.
2. **Macintosh®일 경우, Macintosh 운영 체제를 시작하고 Logitech 소프트웨어 CD를 컴퓨터 CD-ROM 드라이브에 넣은 다음 해당 언어 폴더에서 설치기 아이콘을 찾아 두 번 클릭하고 화면의 지시에 따릅니다.**

© 2000 Logitech. All Rights Reserved. 여기서 언급되는 Logitech, Logitech 로고, Logitech 제품은 Logitech의 상표이거나 등록 상표입니다. 기타 상표는 각 소유자의 재산입니다. Logitech은 이 설명서에 나타날 수 있는 모든 오류에 대해 책임지지 않으며 여기에 포함된 정보는 예고 없이 변경될 수 있습니다.
부품 번호: 622757-0311

English

中文

한글

5 마우스와 리시버 간의 통신 설정

리시버의 연결 단추를 누른 후 마우스 아래의 연결 단추를 누릅니다.

6 건전지 수명

마우스를 사용하는 표면은 건전지의 수명에 상당한 영향을 줄 수 있습니다. 밝은 색의 표면이 건전지 수명을 늘리는 반면 어두운 색의 표면은 수명을 단축시킵니다. 밝지만 광택이 없는 무광택 표면 위에서 사용하는 것이 좋습니다.

7 추가 정보

Logitech® 소프트웨어 CD에 있는 User's Guide를 참조하면 마우스를 최대한 사용할 수 있습니다. User's Guide에는 제품에 대한 귀중한 정보와 전세계 Logitech 주소 및 전화번호가 포함되어 있습니다. 소프트웨어를 설치할 때 User's Guide도 자동으로 하드 드라이브에 복사됩니다.

PC의 경우

1. **Windows® 작업 표시줄에서 시작, 프로그램, Logitech®, MouseWare®를 차례로 선택한 다음 User's Guide를 선택합니다.**
2. **User's Guide가 자동으로 표시됩니다.** 항목을 보려면 제목 페이지의 왼쪽에 나열된 책갈피 중 하나를 클릭합니다.

Macintosh®의 경우

1. **바탕 화면에서 MouseWare® 폴더를 찾은 후 두 번 클릭하여 폴더를 엽니다.**
2. **User's Guide 아이콘을 찾아 두 번 클릭하여 User's Guide를 엽니다.**

8 문제 해결

설치 후 마우스가 작동하지 않거나 마우스를 인식할 수 없는 경우

- 리시버를 올바르게 연결했는지 확인합니다. 리시버 케이블은 컴퓨터의 USB 포트 또는 PS/2 마우스 포트에 연결됩니다. 최적의 성능을 위해서는 리시버를 컴퓨터, 컴퓨터 모니터 또는 외부 저장 드라이브와 같은 기타 전기 장치에서 최소한 8인치 또는 20센티미터 이상 떨어진 곳에 놓아야 합니다. 금속성 표면 위에서 작업하는 경우 리시버를 측면으로 놓으면 수신율이 좋아집니다.
- PC의 경우 PS/2 마우스 포트를 제대로 구성했는지 확인합니다. 올바른 포트 구성에 대해서는 컴퓨터 설명서를 참조하십시오. 다른 시스템 장치가 마우스와 충돌하는 경우도 있습니다. 충돌하는 장치의 IRQ/주소 설정을 확인하고 필요한 경우 설정을 변경합니다.
- 리시버와 마우스 간의 통신을 설정합니다. 리시버의 연결 단추를 누른 후 마우스 아래의 연결 단추를 누릅니다.
- 건전지를 올바르게 삽입했는지 확인합니다.
- 마우스 케이블을 컴퓨터에서 뽑았다가 다시 꽂아 봅니다.