

M-RBG112

Logitech LX7 Cordless Optical Mouse

Installation



1

English Turn ON computer.
Deutsch Schalten Sie den Computer EIN.
Français Mettre l'ordinateur sous tension.
Italiano Accendere il computer.
Español ACTIVAR el ordenador.
Português Ligue o computador.
Nederlands Zet de computer AAN.
Svenska Starta datorn.

Dansk Tænd for computeren.
Suomi Käynnistä tietokone.
Ελληνικά Ενεργοποίησε τον υπολογιστή.
По-русски Включите компьютер.
Magyar Kapcsolja be a számítógépet.
Česká verze Zapněte počítač.
Po polsku Włącz komputer.

2

English For Desktop PCs: 1) Plug USB stand into computer's USB port. 2) Insert wireless mini-receiver into USB stand. For Notebooks: 3) Plug wireless mini-receiver directly into computer's USB port.
Deutsch Für Desktop-PCs: 1) Plug USB stand into computer's USB port. 2) Insert wireless mini-receiver into USB stand. For Notebooks: 3) Plug wireless mini-receiver directly into computer's USB port.
Français Pour Desktop PCs: 1) Plug USB stand into computer's USB port. 2) Insert wireless mini-receiver into USB stand. For Notebooks: 3) Plug wireless mini-receiver directly into computer's USB port.
Italiano Per Desktop PCs: 1) Plug USB stand into computer's USB port. 2) Insert wireless mini-receiver into USB stand. For Notebooks: 3) Plug wireless mini-receiver directly into computer's USB port.
Español For Desktop PCs: 1) Plug USB stand into computer's USB port. 2) Insert wireless mini-receiver into USB stand. For Notebooks: 3) Plug wireless mini-receiver directly into computer's USB port.
Português For Desktop PCs: 1) Plug USB stand into computer's USB port. 2) Insert wireless mini-receiver into USB stand. For Notebooks: 3) Plug wireless mini-receiver directly into computer's USB port.
Nederlands For Desktop PCs: 1) Plug USB stand into computer's USB port. 2) Insert wireless mini-receiver into USB stand. For Notebooks: 3) Plug wireless mini-receiver directly into computer's USB port.
Svenska For Desktop PCs: 1) Plug USB stand into computer's USB port. 2) Insert wireless mini-receiver into USB stand. For Notebooks: 3) Plug wireless mini-receiver directly into computer's USB port.
Dansk For Desktop PCs: 1) Plug USB stand into computer's USB port. 2) Insert wireless mini-receiver into USB stand. For Notebooks: 3) Plug wireless mini-receiver directly into computer's USB port.
Norsk For Desktop PCs: 1) Plug USB stand into computer's USB port. 2) Insert wireless mini-receiver into USB stand. For Notebooks: 3) Plug wireless mini-receiver directly into computer's USB port.
Suomi For Desktop PCs: 1) Plug USB stand into computer's USB port. 2) Insert wireless mini-receiver into USB stand. For Notebooks: 3) Plug wireless mini-receiver directly into computer's USB port.
Ελληνικά For Desktop PCs: 1) Plug USB stand into computer's USB port. 2) Insert wireless mini-receiver into USB stand. For Notebooks: 3) Plug wireless mini-receiver directly into computer's USB port.
По-русски For Desktop PCs: 1) Plug USB stand into computer's USB port. 2) Insert wireless mini-receiver into USB stand. For Notebooks: 3) Plug wireless mini-receiver directly into computer's USB port.
Magyar For Desktop PCs: 1) Plug USB stand into computer's USB port. 2) Insert wireless mini-receiver into USB stand. For Notebooks: 3) Plug wireless mini-receiver directly into computer's USB port.
Česká verze For Desktop PCs: 1) Plug USB stand into computer's USB port. 2) Insert wireless mini-receiver into USB stand. For Notebooks: 3) Plug wireless mini-receiver directly into computer's USB port.
Po polsku For Desktop PCs: 1) Plug USB stand into computer's USB port. 2) Insert wireless mini-receiver into USB stand. For Notebooks: 3) Plug wireless mini-receiver directly into computer's USB port.

3

English Slide the battery door off. Install the AA battery.
Deutsch Slide the battery door off. Install the AA battery.
Français Slide the battery door off. Install the AA battery.
Italiano Slide the battery door off. Install the AA battery.
Español Slide the battery door off. Install the AA battery.
Português Slide the battery door off. Install the AA battery.
Nederlands Slide the battery door off. Install the AA battery.
Svenska Slide the battery door off. Install the AA battery.
Dansk Slide the battery door off. Install the AA battery.
Norsk Slide the battery door off. Install the AA battery.
Suomi Slide the battery door off. Install the AA battery.
Ελληνικά Slide the battery door off. Install the AA battery.
По-русски Slide the battery door off. Install the AA battery.
Magyar Slide the battery door off. Install the AA battery.
Česká verze Slide the battery door off. Install the AA battery.
Po polsku Slide the battery door off. Install the AA battery.

4

English Turn ON mouse.
Deutsch Turn ON mouse.
Français Turn ON mouse.
Italiano Turn ON mouse.
Español Turn ON mouse.
Português Turn ON mouse.
Nederlands Turn ON mouse.
Svenska Turn ON mouse.
Dansk Turn ON mouse.
Suomi Turn ON mouse.
Ελληνικά Turn ON mouse.
По-русски Turn ON mouse.
Magyar Turn ON mouse.
Česká verze Turn ON mouse.
Po polsku Turn ON mouse.

5

English To enjoy all the features of your product, install the software. For Macintosh users, download software at www.logitech.com/LX7mac.
Deutsch Um alle Funktionen Ihres Produkts zu nutzen, installieren Sie das Softwarepaket. Macintosh-Nutzer können das Mac-Softwarepaket von www.logitech.com/LX7mac herunterladen.
Français Pour pouvoir utiliser pleinement toutes les fonctions de votre produit, installez le logiciel. Utilisateurs Macintosh: téléchargez le logiciel à partir de www.logitech.com/LX7mac.
Suomi Ennen kuin aiotte käyttää kaikkiä tuotteen ominaisuuksia, asenna ohjelmisto. Macintosh-käyttäjät voivat ladata ohjelmiston www.logitech.com/LX7mac sivustolta.
Ελληνικά Προκειμένου να απολαύσετε όλες τις λειτουργίες του προϊόντος, εγκαταστήστε το λογισμικό. Χρήστες Macintosh: κατεβάστε το λογισμικό από www.logitech.com/LX7mac.
По-русски Для использования всех возможностей устройства необходимо установить программное обеспечение. Пользователи Macintosh могут загрузить программное обеспечение с веб-сайта по адресу www.logitech.com/LX7mac.
Magyar A termék összes szolgáltatásának használatához szükséges a szoftver telepítése. Macintosh-használók letölthetik a szoftvert www.logitech.com/LX7mac címen található webhelyről.
Česká verze Chcete-li využít všechny funkce produktu, je třeba nainstalovat příslušné software. Uživatelé Macintosh mohou stáhnout software na webu www.logitech.com/LX7mac.
Po polsku Zanim używać wszystkich funkcji urządzenia, należy zainstalować odpowiednie oprogramowanie. Użytkownicy Macintosh mogą pobrać oprogramowanie z witryny www.logitech.com/LX7mac.

i

English 1) The wheel plus zoom. Push wheel to either side to scroll side-to-side. Click and roll the wheel to zoom in and out. (Works only if software is installed.) 2) Universal forward and back buttons. Launch Logitech® SetPoint™ to customize button and all wheel assignments. 3) Left and right mouse buttons. Launch Logitech® SetPoint™ to customize button and all wheel assignments. 4) Battery LED. LED turns green briefly when mouse is powered on or is lit. LED blinks red when battery level drops below 10%.
Deutsch 1) The wheel plus zoom. Push wheel to either side to scroll side-to-side. Click and roll the wheel to zoom in and out. (Works only if software is installed.) 2) Universal forward and back buttons. Launch Logitech® SetPoint™ to customize button and all wheel assignments. 3) Left and right mouse buttons. Launch Logitech® SetPoint™ to customize button and all wheel assignments. 4) Battery LED. LED turns green briefly when mouse is powered on or is lit. LED blinks red when battery level drops below 10%.
Français 1) The wheel plus zoom. Push wheel to either side to scroll side-to-side. Click and roll the wheel to zoom in and out. (Works only if software is installed.) 2) Universal forward and back buttons. Launch Logitech® SetPoint™ to customize button and all wheel assignments. 3) Left and right mouse buttons. Launch Logitech® SetPoint™ to customize button and all wheel assignments. 4) Battery LED. LED turns green briefly when mouse is powered on or is lit. LED blinks red when battery level drops below 10%.
Italiano 1) The wheel plus zoom. Push wheel to either side to scroll side-to-side. Click and roll the wheel to zoom in and out. (Works only if software is installed.) 2) Universal forward and back buttons. Launch Logitech® SetPoint™ to customize button and all wheel assignments. 3) Left and right mouse buttons. Launch Logitech® SetPoint™ to customize button and all wheel assignments. 4) Battery LED. LED turns green briefly when mouse is powered on or is lit. LED blinks red when battery level drops below 10%.
Español 1) The wheel plus zoom. Push wheel to either side to scroll side-to-side. Click and roll the wheel to zoom in and out. (Works only if software is installed.) 2) Universal forward and back buttons. Launch Logitech® SetPoint™ to customize button and all wheel assignments. 3) Left and right mouse buttons. Launch Logitech® SetPoint™ to customize button and all wheel assignments. 4) Battery LED. LED turns green briefly when mouse is powered on or is lit. LED blinks red when battery level drops below 10%.
Português 1) The wheel plus zoom. Push wheel to either side to scroll side-to-side. Click and roll the wheel to zoom in and out. (Works only if software is installed.) 2) Universal forward and back buttons. Launch Logitech® SetPoint™ to customize button and all wheel assignments. 3) Left and right mouse buttons. Launch Logitech® SetPoint™ to customize button and all wheel assignments. 4) Battery LED. LED turns green briefly when mouse is powered on or is lit. LED blinks red when battery level drops below 10%.
Nederlands 1) The wheel plus zoom. Push wheel to either side to scroll side-to-side. Click and roll the wheel to zoom in and out. (Works only if software is installed.) 2) Universal forward and back buttons. Launch Logitech® SetPoint™ to customize button and all wheel assignments. 3) Left and right mouse buttons. Launch Logitech® SetPoint™ to customize button and all wheel assignments. 4) Battery LED. LED turns green briefly when mouse is powered on or is lit. LED blinks red when battery level drops below 10%.
Suomi 1) The wheel plus zoom. Push wheel to either side to scroll side-to-side. Click and roll the wheel to zoom in and out. (Works only if software is installed.) 2) Universal forward and back buttons. Launch Logitech® SetPoint™ to customize button and all wheel assignments. 3) Left and right mouse buttons. Launch Logitech® SetPoint™ to customize button and all wheel assignments. 4) Battery LED. LED turns green briefly when mouse is powered on or is lit. LED blinks red when battery level drops below 10%.
Ελληνικά 1) The wheel plus zoom. Push wheel to either side to scroll side-to-side. Click and roll the wheel to zoom in and out. (Works only if software is installed.) 2) Universal forward and back buttons. Launch Logitech® SetPoint™ to customize button and all wheel assignments. 3) Left and right mouse buttons. Launch Logitech® SetPoint™ to customize button and all wheel assignments. 4) Battery LED. LED turns green briefly when mouse is powered on or is lit. LED blinks red when battery level drops below 10%.
По-русски 1) The wheel plus zoom. Push wheel to either side to scroll side-to-side. Click and roll the wheel to zoom in and out. (Works only if software is installed.) 2) Universal forward and back buttons. Launch Logitech® SetPoint™ to customize button and all wheel assignments. 3) Left and right mouse buttons. Launch Logitech® SetPoint™ to customize button and all wheel assignments. 4) Battery LED. LED turns green briefly when mouse is powered on or is lit. LED blinks red when battery level drops below 10%.
Magyar 1) The wheel plus zoom. Push wheel to either side to scroll side-to-side. Click and roll the wheel to zoom in and out. (Works only if software is installed.) 2) Universal forward and back buttons. Launch Logitech® SetPoint™ to customize button and all wheel assignments. 3) Left and right mouse buttons. Launch Logitech® SetPoint™ to customize button and all wheel assignments. 4) Battery LED. LED turns green briefly when mouse is powered on or is lit. LED blinks red when battery level drops below 10%.
Česká verze 1) The wheel plus zoom. Push wheel to either side to scroll side-to-side. Click and roll the wheel to zoom in and out. (Works only if software is installed.) 2) Universal forward and back buttons. Launch Logitech® SetPoint™ to customize button and all wheel assignments. 3) Left and right mouse buttons. Launch Logitech® SetPoint™ to customize button and all wheel assignments. 4) Battery LED. LED turns green briefly when mouse is powered on or is lit. LED blinks red when battery level drops below 10%.
Po polsku 1) The wheel plus zoom. Push wheel to either side to scroll side-to-side. Click and roll the wheel to zoom in and out. (Works only if software is installed.) 2) Universal forward and back buttons. Launch Logitech® SetPoint™ to customize button and all wheel assignments. 3) Left and right mouse buttons. Launch Logitech® SetPoint™ to customize button and all wheel assignments. 4) Battery LED. LED turns green briefly when mouse is powered on or is lit. LED blinks red when battery level drops below 10%.

www.logitech.com