



English 1. When not in use, store the receiver conveniently in the bottom of the number pad. 2. Turn the unit off by pressing the On/Off button for two seconds. 3. Place the unit in its protective pouch.

Español 1. When not in use, store the receiver conveniently in the bottom of the number pad. 2. Turn the unit off by pressing the On/Off button for two seconds. 3. Place the unit in its protective pouch.

Français 1. When not in use, store the receiver conveniently in the bottom of the number pad. 2. Turn the unit off by pressing the On/Off button for two seconds. 3. Place the unit in its protective pouch.

Português 1. When not in use, store the receiver conveniently in the bottom of the number pad. 2. Turn the unit off by pressing the On/Off button for two seconds. 3. Place the unit in its protective pouch.



English 1. Launches Microsoft® Excel® 2. Launches Windows® calculator 3. Launches Internet browser 4. One-touch Excel® keys 5. Internet/Excel® back key

Español 1. Launches Microsoft® Excel® 2. Launches Windows® calculator 3. Launches Internet browser 4. One-touch Excel® keys 5. Internet/Excel® back key

Français 1. Launches Microsoft® Excel® 2. Launches Windows® calculator 3. Launches Internet browser 4. One-touch Excel® keys 5. Internet/Excel® back key

Português 1. Launches Microsoft® Excel® 2. Launches Windows® calculator 3. Launches Internet browser 4. One-touch Excel® keys 5. Internet/Excel® back key



www.logitech.com

© 2007 Logitech. All rights reserved. Logitech, the Logitech logo, and other Logitech marks are owned by Logitech and may be registered. All other trademarks are the property of their respective owners. Logitech assumes no responsibility for any errors that may appear in this manual. Information contained herein is subject to change without notice.

© 2007 Logitech. Tous droits réservés. Logitech, le logo Logitech et les autres marques Logitech sont la propriété exclusive de Logitech et sont susceptibles d'être des marques déposées. Toutes les autres marques sont la propriété exclusive de leurs détenteurs respectifs. Logitech décline toute responsabilité en cas d'erreurs dans ce manuel. Les informations énoncées dans le présent document peuvent faire l'objet de modifications sans avis préalable.

620-000240.001

English Warranty. Your product comes with a limited hardware warranty. Refer to the Logitech® Warranty Document or go to <http://www.logitech.com/warranty> for more information.

Compliance and Safety. Your product has been UL tested and should only be used with other UL certified devices. For information regarding power supply and battery usage, go to <http://www.logitech.com/compliance>.

Español Warranty. Your product comes with a limited hardware warranty. Refer to the Logitech® Warranty Document or go to <http://www.logitech.com/warranty> for more information.

Compliance and Safety. Your product has been UL tested and should only be used with other UL certified devices. For information regarding power supply and battery usage, go to <http://www.logitech.com/compliance>.

Français Warranty. Your product comes with a limited hardware warranty. Refer to the Logitech® Warranty Document or go to <http://www.logitech.com/warranty> for more information.

Compliance and Safety. Your product has been UL tested and should only be used with other UL certified devices. For information regarding power supply and battery usage, go to <http://www.logitech.com/compliance>.

Português Warranty. Your product comes with a limited hardware warranty. Refer to the Logitech® Warranty Document or go to <http://www.logitech.com/warranty> for more information.

Compliance and Safety. Your product has been UL tested and should only be used with other UL certified devices. For information regarding power supply and battery usage, go to <http://www.logitech.com/compliance>.

www.logitech.com/support



Location	Hotline	Technical Help
United States	+1 702 269 3457	
Argentina	0800 555 3284	
Brazil	0800 891 4173	
Canada	+1 416 207 2782	
Chile	1230 020 5484	
Latin America	+55 11 3444 6761	
Mexico	001 800 578 9619	

Federal Communication Commission Interference Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

IMPORTANT NOTE:

FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. End users must follow the specific operating instructions for satisfying RF exposure compliance. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.