




MIXAMP™ PRO QUICK START GUIDE


MIXAMP™ PRO



USING THE MIXAMP™ PRO

Press the Power Button to get out of "standby" mode to fully power on.

Press the EQ Button to cycle through the 4x different audio presets.



Dolby® Surround Sound processing is on by default. Press the Dolby® Button again to turn it off.

Turn the dial left to hear more game audio and less voice chat, turn the dial right to hear more voice chat and less game audio.

OPTICAL CABLE

[connect to console or PC for audio]

XBOX LIVE® CABLE

[connect to controller for Xbox LIVE® Chat]

USB POWER CABLE

[connect to ANY USB port for power only]
[or connect to PS3 or PC for chat and power]

Y-ADAPTER

[connect to PC Headset]

AUX CABLE

[connect to AUX input or Daisy Chain]

Especificaciones:

Fuente de alimentación: USB mini-B (compatible con USB 2.0)

Fuente de energía: 70 mW 32 ohm por canal

Respuesta de frecuencia: 20 - 20,000 Hz

Entradas (frente): Puerto para auriculares, puerto para controlador de Xbox LIVE®, puertos de cadena de margarita

Entradas (atrás): Entrada óptica de 3.5 mm, entrada auxiliar de 3.5 mm, alimentación y voz USB (mini-B)

Salidas (atrás): Salida de transmisión de 3.5 mm

Spécifications

Alimentation électrique : USB mini-B (compatible USB 2.0)

Puissance de sortie : 70 mW, 32 ohms par canal


Réponse de fréquence : 20 à 20 000 Hz

Entrées (avant) : Port du casque, port du contrôleur de Xbox LIVE®, ports de chaîne en série

Entrées (arrière) : Entrée optique 3,5 mm, entrée auxiliaire 3,5 mm, USB puissance/voix (mini-B)

Sorties (arrière) : Sortie en continu 3,5 mm


XBOX 360 SETUP



No additional setup required.

Headset

PS3 SETUP




To setup game audio on PS3, go to Settings > Sound Settings > Audio Output Settings. Select "Optical Digital" output and scroll to the output format menu to ensure that ONLY "Dolby Digital 5.1 Ch" is checked. Make sure that "DTS 5.1 Ch" is NOT checked.

For voice chat, go to Settings > Accessory Settings > Audio Device Settings. Under both "Input Device" and "Output Device", select the "ASTRO Gaming MixAmp Pro".

Headset

PC SETUP



To setup game audio on PC using Windows 7 Pro, go to Control Panel > Sound > Playback. Click on "SPDIF Out" or your digital output and select "Set as Default Device". To guarantee full functionality, be sure your sound card supports "Dolby Digital" technology.

For voice chat, go to Control Panel > Sound > Recording. Click on "ASTRO Gaming MixAmp Pro" and select "Set as Default Device".

Headset