




# Logitech™ 2.4GHz Cordless Mouse M-R0013



**English**

Congratulations! You are now ready to use your mouse.

**繁體中文**

恭喜！現在，您可以立即開始使用滑鼠。

**简体中文**

恭喜您！您现在即可开始使用鼠标。

**한국어**

축하합니다! 이제 마우스를 사용할 준비가 되었습니다.



**English**

**Features**

- 1 Left and right mouse buttons
- 2 Battery LED flashes red when battery power is low
- 3 Scroll wheel
- 4 Press the wheel down for middle button (function can vary by software application)
- 5 On/Off slider switch
- 6 Battery door release button
- 7 USB Nano-receiver storage



**繁體中文**

**功能**


- 1 滑鼠左鍵和右鍵
- 2 電池 LED，電池電量較低時會閃爍紅燈
- 3 滾輪
- 4 按下滾輪以執行滑鼠中鍵功能（功能會因軟體應用程式而有所不同）
- 5 電源滑動開關
- 6 電池蓋釋放按鈕
- 7 USB 超小型接收器收納處



**简体中文**

**功能部件**

- 1 左、右鼠标按钮
- 2 电池 LED 指示灯，当电池电量较低时呈红色闪烁
- 3 滚轮
- 4 向下按滚轮作为中键使用，功能视具体软件应用程序而定
- 5 开/关滑动开关
- 6 电池盖释放按钮
- 7 USB Nano 接收器存放空间



**한국어**

**기능**

- 1 왼쪽/오른쪽 마우스 버튼
- 2 배터리 전원이 부족하면 배터리 LED가 적색으로 깜빡임
- 3 스크롤 휠
- 4 중간 버튼(기능은 소프트웨어 응용 프로그램에 따라 다를 수 있음)으로 사용하려면 휠을 아래로 누름
- 5 켜기/끄기 슬라이더 스위치
- 6 배터리 덮개 분리 버튼
- 7 USB Nano 수신기 보관

