



## English

### Having problems?

- 1 Is the power on?
- 2 Check the Nano receiver; change ports.
- 3 Check the battery.
- 4 Try a different surface. Remove metallic objects between mouse and the Nano receiver.
- 5 If the Nano receiver is plugged into a USB hub, try plugging it directly into a USB port on your computer.
- 6 Move the Nano receiver to a USB port closer to the mouse, or go to [www.logitech.com/usbextender](http://www.logitech.com/usbextender) for a USB extension stand that will allow the Nano receiver to be placed closer to the mouse.

## 繁體中文

### 是否存在問題？

- 1 檢查電源是否開啟。
- 2 檢查超小型接收器，更換連接埠。
- 3 檢查電池。
- 4 嘗試將滑鼠置於不同的表面上。將滑鼠與超小型接收器之間的金屬物體移開。
- 5 如果超小型接收器插至 USB 集線器，請嘗試將它直接插至電腦的 USB 連接埠。
- 6 將超小型接收器移至更靠近滑鼠的 USB 連接埠，或瀏覽 [www.logitech.com/usbextender](http://www.logitech.com/usbextender) 以了解 USB 延長插座的使用方式，它能夠讓超小型接收器放置在更靠近滑鼠的位置。

## 简体中文

### 是否存在问题？

- 1 检查电源是否开启。
- 2 检查 Nano 接收器，更改端口。
- 3 检查电池。
- 4 尝试将鼠标放到不同的表面上。移开鼠标与 Nano 接收器之间的金属物体。
- 5 如果 Nano 接收器是插入到 USB 集线器中，请尝试将其直接插入电脑的 USB 端口中。
- 6 将 Nano 接收器移到距离鼠标更近的 USB 端口，或访问 [www.logitech.com/usbextender](http://www.logitech.com/usbextender) 了解 USB 延长底座的使用方式，它能够让 Nano 接收器放置在更靠近鼠标的位置。

## 한국어

### 문제가 있습니까?

- 1 전원이 켜져 있습니까?
- 2 Nano 수신기를 확인하고 포트를 변경하십시오.
- 3 배터리를 확인하십시오.
- 4 다른 표면에서 사용해 보십시오. 마우스와 Nano 수신기 사이의 금속 물질을 제거하십시오.
- 5 Nano 수신기가 USB 허브에 연결된 경우에는 직접 USB 포트에 연결해 보십시오.
- 6 Nano 수신기를 마우스와 가까운 USB 포트에 연결하거나 [www.logitech.com/usbextender](http://www.logitech.com/usbextender)에서 Nano 수신기를 마우스에 가까이 배치할 수 있도록 하는 USB 연장 스탠드를 찾아 보십시오.