


PROJECT TYPE:  
O MOCK-UP / FINISHED ARTWORK

FORMAT (SOFTWARE VERSION):  
Adobe Creative Suite 4 (ILLUSTRATOR)

PRINT PROCESS:  
B&W, 1C x 1C (Front & Back printing)  
Half/Single folding, 4-pages

SUBSTRATE/MEDIA:  
White art paper, Size: 254(W) x H 127(H)mm

COLOR USAGE:  
Black  
Half/Single folding



SEE ACTUAL PANTONE SWATCHES FOR ACCURATE COLOR REPRESENTATION.

FONTS USAGE:  
Museo Sans for Dell

OTHER INSTRUCTIONS:

PROJECT COORDINATOR /  
STUDIO PRODUCTION

DATE:  
CLIENT SERVICES

DATE:

CREATIVE /  
DESIGN

DATE:  
CLIENT

DATE:

Note: This printout serves only as a guide. This artwork does not contain any choke/ grip/trap information. Whilst every effort is made to ensure the accuracy of the text in this artwork, "Chemistry" cannot accept responsibility for any errors or omissions. See terms and conditions. © Copyright protected.

PROJECT SIGN OFF

(W) 381mm
Back panel
Outside panel
Front panel

(H) 127mm

**Zoom in / out**  
放大 / 縮小  
拡大 / 縮小  
ズームイン / ズームアウト  
Увеличение / Уменьшение  
Zoom in / ut  
Zoom avant / arrière  
تكبير / تصغير  
Ingrandisci / Riduci  
Vergrößern / Verkleinern  
Zoom inn / ut  
Zoom ind / ud  
Acercar / Alejar  
Ampliar / Reduzir  
Piiblit / oddilit  
Μεγάλυνση / Σμίκρυνση  
התקרב / התרחק  
확대 / 축소  
Ampliar / Reduzir  
Büyütmek / Küçültmek

**Back**  
返回  
前退  
戻る  
戻る  
Назад  
Tilbake  
Retour  
Zoom avant / arrière  
تكبير / تصغير  
Ingrandisci / Riduci  
Vergrößern / Verkleinern  
Zoom inn / ut  
Zoom ind / ud  
Acercar / Alejar  
Ampliar / Reduzir  
Piiblit / oddilit  
Μεγάλυνση / Σμίκρυνση  
התקרב / התרחק  
확대 / 축소  
Ampliar / Reduzir  
Büyütmek / Küçültmek

**Forward**  
向前  
前進  
進む  
進む  
Навперед  
Framåt  
Suivant  
للأمام  
Avanti  
Weiter  
Fremover  
Tilbage  
Adelante  
Recuar  
Zpřed  
Προ  
הבא  
확대 / 축소  
Avançar  
ileri

**Both the slide-buttons perform the same function.**

Both slide-buttons perform the same function.  
Les deux boutons à glissement ont la même fonction.  
Ambos botones deslizaran la misma función.  
Die beiden Schieber funktionieren in einem Funktionsblock.  
Oslabí obou tlačítek stejnou funkci.  
Die beiden Schieber funktionieren in einem Funktionsblock.  
Ambos botones deslizaran la misma función.  
Die beiden Schieber funktionieren in einem Funktionsblock.  
Ambos botones deslizaran la misma función.  
Die beiden Schieber funktionieren in einem Funktionsblock.

**The utility software may be pre-installed on your computer. You can also download the software from dell.com/ur/ut. If required.**

已经预装在您的计算机上。您也可以从 [dell.com/ur/ut](http://dell.com/ur/ut) 下载。  
The utility software may be pre-installed on your computer. You can also download the software from [dell.com/ur/ut](http://dell.com/ur/ut). If required.

# Dell™ WM324

## Quick Start Guide

快速開始指南 | 快速入门指南  
クイックスタートガイド | Краткое руководство  
Guide till snabbstart | Guide de démarrage rapide  
دليل التشغيل السريع | Guida all'avvio rapido  
Schnellstartanleitung | Hurtigstartsvejledning  
Vejledning til hurtigstart | Guia de inicio rápido  
Guia de inicio rápido | Úvodní příručka  
מורה להתחלה מהירה | οδηγיו הפשוטים באינטרנט  
빠른 실행 가이드 | Guia Rápido  
Hızlı Başlangıç Kılavuzu |

[dell.com/support](http://dell.com/support)

(W) 381mm
Inside panel

(H) 127mm

**dell.com/support**

**1**

**2**

**3**

**Windows 8**

**Charms sidebar**  
Windows charms 功能表  
Windows charms  
Windows チャーム  
Чармы-панель Windows  
Windows snabbknapprätt  
kônes Windows  
Windows charms شريط  
Ecran panoramique de Windows  
Windows-Charms  
Windows charms (Windows-perler)  
Windows charms  
Accesos de Windows  
Windows charms  
Ovládací tlačítka Windows  
Windows charms  
צורת חריטות של Windows  
윈도우즈 차( Charms bar)  
Windows charms  
Windows'un Yan Çubuğu

**Windows 8**

**Apps switch**  
應用程式切換  
应用程序切换  
アプリスイッチ  
Переключение на приложения  
App-byte  
Changer d'application  
مفتاح التطبيقات  
Passa al' app  
App-Wechsel  
App-byter  
Skift af app  
Selector de aplicaciones  
Alternar aplicativo  
Přepínač aplikací  
Μεταβίση σε εφαρμογές  
תחילתן היישומים  
응용 프로그램 전환  
Mudança de aplicação  
Uygulama Seçimi

**Scroll and pan**  
推動和搖搖  
推動和平移  
スクロール / パン  
Προσγρήναση και κύλιση  
Klicka och dra  
Défilement et panoramique  
تكرير وتحرير  
Scorri e panoramica  
Scrollen und schwenken  
Bla og heft  
Rul og panorer  
Desplazarse y panorámica  
Rolagem e panorâmica  
Posunout  
Κύλιση και μετατόπιση  
גלילה וצידוד  
스크롤 및 이동  
Deslocamento e panorâmica  
Kaydırma ve tersüz