



Logitech®
Squeezebox™ Touch
Wi-Fi Music Player

Quick start guide



Thank you!

Thank you for purchasing a Logitech® Squeezebox™ Touch Wi-Fi music player. We hope you have as much fun using it as we did creating it for you.

This guide covers basic hardware setup. Once hardware setup is complete, Squeezebox Touch screens will guide you through the rest of the setup process. The **Troubleshooting section** at the end of the guide covers issues that you might encounter during the setup process.

For full documentation of Squeezebox Touch functionality, a **feature guide** is available at www.mysqueezebox.com.

Getting help

For more information about your Squeezebox, go to www.mysqueezebox.com


For phone support, call:

- Monday through Friday, from 6:00 a.m. to 9:00 p.m. (0600-2100) Pacific time
- Saturday and Sunday, from 7:00 a.m. to 5:00 p.m. (0700-1700) Pacific time

At the following numbers:

- +1 (877) 887-8889 (Toll-free in North America)
- +1 (646) 454-3237 (For all other countries)

Package contents



What you need to get started

To start using your Squeezebox Touch, you will need:

- A stereo system or set of powered speakers
- A broadband Internet connection (for example, DSL or cable modem)
- The name and password of your wireless network



A typical Squeezebox Touch setup

Find a good location

Place Squeezebox Touch where you can easily connect it to your stereo, and where the Squeezebox touchscreen is visible and accessible. Squeezebox Touch will need to be connected to an electrical outlet at all times.

	If you will be adding Squeezebox Touch to a wireless network, make sure that your Squeezebox is within range of your wireless network.
	If you will be setting up a wired connection, locate Squeezebox Touch within reach of both your home stereo and an Ethernet jack.

* Ethernet cable not included

Squeezebox at a glance


Squeezebox Touch connects directly to your stereo, allowing you to hear the music that you want on your own stereo system or powered speakers. To manage Squeezebox Touch, use the touchscreen or the remote control.



Squeezebox Front

Note: Please use only the enclosed cloth or an eyeglass cloth to clean the Squeezebox touchscreen. Tissues and other materials can cause scratches.

The back of Squeezebox Touch includes ports for connecting to your stereo or powered speakers, as well as one for connecting to a wired Ethernet network.




Squeezebox Back

Remote control

You can navigate your Squeezebox with the touchscreen or the remote control.


Note: When using the remote, maintain line of sight with your Squeezebox. The infrared light from the remote needs to be able to communicate with the sensor on Squeezebox Touch.



Squeezebox remote control




2 Connect Squeezebox



If you want to use Squeezebox Touch with powered speakers or headphones, connect them now.



1 Insert batteries into remote



3 Plug in Squeezebox

