

FRONT

mobile listening device

R/C spymobile



Your mission is to gather intelligence. And your best tool is your R/C Spymobile mobile listening device. Slowly you drive around the corner, careful not to be detected. And with a push of a button, you hear all details of their master plan. Wait! You've been detected. You react quickly and maneuver your R/C Spymobile out of the room and out of sight. Whew! That was a close one.

Important:
Please save this instruction sheet. It contains valuable product information.

Battery Safety Information:

Requires 1 "9V" and 3 "AAA" batteries (not included).

- Alkaline batteries are recommended.
- Rechargeable batteries may affect performance.
- Do not recharge non-rechargeable batteries.
- Remove dead or exhausted batteries.
- Insert batteries correctly. Match positive and negative signs.
- Do not place anything across the battery terminals.
- Only use the batteries specified above.
- Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries.
- Do not mix old and new batteries.
- Dispose of batteries safely.

Contents

Please check to see that all components are enclosed before disposing of carton. If any components are missing or damaged please contact Customer Service immediately at 1-800-379-0244.

1. Discovery Kids R/C Spymobile
2. Controller
3. Headphones

Vehicle Battery Installation

Requires 3 "AAA" batteries

1. Turn vehicle upside-down. With a small Phillips screwdriver, loosen the battery door screw by turning it counter-clockwise.
2. Remove the battery door.
3. Insert 3 "AAA" batteries as indicated in the battery compartment. (Figure 2)
4. Replace the battery door.
5. Tighten the screw until snug. Do not over-tighten.

Controller Battery Installation

Requires 1 "9V" battery

1. Turn controller upside-down. With a small Phillips screwdriver, loosen the battery door screw by turning it counter-clockwise.
2. Remove the battery door.
3. Insert the "9V" battery as indicated in the battery compartment. (Figure 3)
4. Replace the battery door.
5. Tighten the screw until snug. Do not over-tighten.





Figure 3



Figure 2



Figure 4



Figure 5



Figure 6




Figure 7



Figure 8

Connecting the headphones

1. Remove any twist ties or tape from the headphone cord.
2. Straighten the cord to get out any kinks.
3. Insert the headphone plug into the controller's headphone jack. (Figure 4)

Operating your R/C Spymobile:

1. Set the power switch on the underside of the controller to the "ON" position. (Figure 5) The red LED power indicator on the top of the controller will be illuminated when power is on. If the controller is idle for 10 minutes, it will automatically shut off and the red LED indicator will turn off. To turn the controller back on, move the power switch to the "OFF" position and then back to the "ON" position.

2. Set the power switch on the underside of the vehicle to the "ON" position. (Figure 6) The red LED power indicator on the top of the vehicle will be illuminated when power is on. If the vehicle is idle for 10 minutes, it will automatically shut off and the red LED indicator will turn off. To turn the vehicle back on, move the power switch to the "OFF" position and then back to the "ON" position.

NOTE: Turning off the controller and vehicle power switches after use will prolong battery life.

Driving:

Your R/C Spymobile has 8-function driving operation (Figure 7):

1. Forward- shift the left joystick forward.
2. Reverse- shift the left joystick backward.
3. Left turn- shift the right joystick to the left.
4. Right turn- shift the right joystick to the right.
5. Forward left turn- shift the left joystick forward and the right joystick to the left.
6. Forward right turn- shift the left joystick forward and the right joystick to the right.
7. Reverse left turn- shift the left joystick backward and the right joystick to the left.
8. Reverse right turn- shift the left joystick backward and the right joystick to the right.

NOTE: If your R/C Spymobile is not driving straight when going forward you can adjust the steering using the trim dial on the underside of the vehicle. (Figure 8)

Listening:

The listening function operates only when the vehicle comes to a complete stop. This is to avoid noise interference from the vehicle's motor.

1. To listen, place the headphones on your head with the speakers inside your ears facing forward.
2. Press the "listening" button on your controller. The green LED light on the controller will indicate that the listening feature is activated. You must hold the button and keep the vehicle still to maintain listening ability.

3. Three flashing green LED lights on the vehicle will indicate that sound is being detected. **CAUTION: Adjust the volume dial so the sound is comfortable. Do not turn the volume all the way up or it may cause damage to your hearing.**

OTHER PRECAUTIONS:

- Your R/C Spymobile operates using radio frequencies. To achieve optimal performance, avoid using your vehicle near radios, fluorescent lights, cordless phones or other electrical appliances.
- Never operate your R/C Spymobile in or around water or any other liquid or you may damage the electrical components.

For questions please call Customer Service at 1-800-379-0244

COMPLIANCE WITH FCC REGULATIONS VALID IN U.S. ONLY - VALUABLE AUXILIARY EQUIPMENT
THIS DEVICE COMPLIES WITH PART 15 FCC RULES. OPERATION OF THIS DEVICE IS SUBJECT TO THE FOLLOWING TWO CONDITIONS:
(1) THIS DEVICE MAY NOT CAUSE HARMFUL INTERFERENCE.
(2) THIS DEVICE MUST ACCEPT ANY HARMFUL INTERFERENCE THAT MAY CAUSE UNDESIRABLE OPERATION.

This device generates and uses radio frequency energy and if not used properly may cause interference to radio and television reception. It has been tested and found to comply with the limits set by the FCC, which are designed to provide reasonable protection against such interference when the device is operated in accordance with the instructions.

CAUTION: Changes or modifications not expressly approved by the manufacturer responsible for compliance could void the user's authority to operate the equipment.

© 2004 Discovery Communications, Inc. All rights reserved.
"Discovery Kids" and "R/C Spymobile" are trademarks of Discovery Communications, Inc.
Made in China for The Discovery Channel Store, Inc., Berkeley, CA 94710

BACK