

# User manual

## Declaration

Please read the user manual so as to keep your mobile phone in the best condition, The manual has been verified and reviewed to guarantee the accuracy. Instructions and descriptions contained herein are accurate at the time of publication. However, mobile phones developed afterwards and the contents of their manual are subject to modification without further notification. Our company reserves the rights in relation to the manual

## Contents

Overview.....	1
1. Introduction .....	2.
2. Function of main menu.....	2.
3. PC connect.....	6.
4. Maintenance and service.....	6.

### ■ Overview

Please read the following concise rules carefully. Nonobservance to the rules may lead to danger or violence of the laws. The user's manual gives details about the safety precautions.

### ■ Emergency call

Make sure the equipment is in the covered area of the network service and the calling function is activated. As per the specific requirements, press the key of finish to clear the screen and return to the standby state. Input the emergency call number (112) and press the call key.

### ■ Function Description

The phone is a perfect combination of humanized design and exquisite workmanship, the streamline and ingenious body is comfortable to hold. With streamline and ingenious frame, it feels comfortable to hold the mobile phone in your hand. It supports TXT electronic book, Blue-tooth, dual SIM cards with one standby, network camera, camera, FM and etc. It makes your work more convenient and your free time more fun with the combination of keyboard, florid colored screen, pleasant bells, cartoon head portrait for incoming calls, strong file management function (supporting T-FLASH card), fashionable camera function and long time tape recording function, music player, video player.

# 1. Introduction

## **Insert the SIM card and the battery**

**Ask your SIM card dealer whether he has provided SIM card service and the method of usage who may be service provider or other dealers, SIM card and its contacts are vulnerable to scratch or bending. Attention shall be attached when use, insert or take out the card.**

### ■ **Inserting/taking out T-FLASH CARD**

Only use approved and compatible T-FLASH card applicable to the mobile phone. Approved memory card trade standard is applied; however, certain bands may not be completely compatible with the mobile phone. Using incompatible memory card may damage not only the card and the mobile, but also the data stored in the card.

### ■ **Charging the battery**

Check the model number of the charger before using it to charge the mobile, Only use approved battery, charger and accessories applicable to the specific mobile model. Using other types of battery, charger and accessories may violate the certification or warranty terms of the equipment and may result in danger, Refer to the dealer for supply of relative approved accessories.

### ■ **Startup and shutdown**

Press the key of power supply to start up or shut down the mobile phone, If it is prompted to input PIN or UPIN, please input the required password (shown as \*\*\*\* on the screen).

# 2. Function of main menu

### ■ **Names**

- You may save the information of contacts including names and telephone numbers in the phonebook, which can save as much as 300 entries.

### ■ **settings**

## ■ **Call settings**

You can some on the communications aspects of setting.

## ■ **Phone settings**

Refer to settings of basic functions, including city, time and format, display language and response time, reset all settings.

### ① **date& time**

You can set the cell phone time and date.

### ② **Language settings**

You can set the phone language and input method.

### ③ **Shortcut settings**

You can set any navigation shortcut keys.

### ④ **Auto power on/off**

You can set the cell phone automatically switch machine.

### ⑤ **Restore the factory settings**

Enter the correct password of the phone will have to change your phone settings back to factory default state value, the user of the function be used with caution. (Default password: 1234).

## ■ **Display**

You may set functions in display.

## ■ **Security**

You may set functions in relations to cell phone security.

## ■ **Profiles**

You may customize the profiles and activate any profile in order to use a specific function.

You may set the ring signal, ringing mode, prompt for connecting through, answer mode, and etc.

## ■ **Connections**

You can set the network account in this menu.

## ■ **Application**

## ■ **My files**

You can insert the memory card and save files in it.

## ■ **Calculator**

You can calculate in this function.

## ■ **Snake**

Here is a game, the game help

## ■ **STK**

This function by the network providers, according to the SIM card provides services will appear different menu options. If a SIM card and network supplier does not support this service, this function will not be used. If you need to get more information please contact with network providers.

## ■ **Bluetooth**

You may establish wireless connection with other compatible devices with the Bluetooth technology; you may send images, videos, music files and etc. with the Bluetooth technology

## ■ **Message**

Write a message: You may select to send the finished message from SIM card 1 or SIM card 2  
You may select multiple receivers to send the message to more than 1 person.

## ■ **WhatsApp**

◆ WhatsApp (WhatsApp messenger) this application by the push notification service, can instantly receive messages from relatives and friends and colleagues. Free from sending text messages to use WhatsApp program, in order to send and receive information, pictures, audio and video information.

◆ operating guide:

WhatsApp is based on the mobile phone number registered, at the time of registration, need you to enter your phone number, and received a validation message, and then WhatsApp will search your phone contacts are already using people and automatically added to your mobile phone contacts list. In fact, after you registered a WhatsApp is binding you cell phone number to generate a WhatsApp number, number and a mobile phone card can only apply for a fast, in other words, the number you registered for the first time use, say, like your ID, always belong to you this card, in the mobile phone of what can be, is can't change, if you accidentally delete the program, the next installation, you as long as the input of

the original old at the time of registration number, the system will automatically skip SMS verification step.

## ■ **Call logs**

- Information, invites the menu→choosing if needing to check your communicating by phone  
→ Communicate by phone center→ Communicate by phone taking notes→SIM card 1 communicates by phone recording/ SIM card 2 communicates by phone taking notes → SIM card 1/ SIM card 2 possessions telephone , SIM card 1/ SIM card 2 has not answered the phone , SIM card 1/ SIM card 2 already answers the phone or 2 already batches of SIM card 1/ SIM card telephone.

## ■ **Multimedia**

### ■ **Camera**

In the options of camera, you may set the photometry mode, flash light, exposure compensation, avoidance of flickering, postponing shooting, white balance, photo quality, photo size, special effect, profile and etc. You may enter the album to check the formats that the cell phone supports.

### ■ **DV**

In the options of the video camera, you may set the exposure compensation, avoidance of flickering, white balance, special effect, profile and etc.

### ■ **Audio**

The music player is used to play music files in supported formats in the current player's list. You may view details of the music files and set the current music file as the ring signal for incoming call.

### ■ **video**

Check the video files in the memory card supported by the cell phone. Play your favorite video files.

### ■ **FM radio**

Turn on FM broadcast, and you may press the direction keys of left and right to manually tune the channel. Press the direction key of upward to turn on or off the auto-searching mode. Press OK to record the FM broadcast. Press the direction key of downward to turn on or off FM broadcast. In the options, you may set manually or automatically searching for channels,

turning off the background during broadcasting as well as the format of recording thereof.

#### ■ **Recorder**

You can record the sounds that you want.

#### ■ **Games**

Here is the game, there are pushing and snake game, gameplay and help.

#### ■ **Internet**

your mobile Internet support based on wireless application protocol (WAP) service. You can access a variety of WAP service. WAP service need network support, the WAP service availability, price and tax, please contact your network operator or provide you with the service providers of services required..

### **3. PC connect**

#### ■ **USB**

Use the T-Flash inserted in the mobile phone as U-Disk. You can transfer music, videos, games and other files form PC to the T-Flash by USB cable. Enjoy it anytime and anywhere.

### **4. Maintenance and service**

Refer to the local dealer for supply of accessories. Hereafter are some precautions for usage of the accessories, Only use batteries, chargers and accessories approved by the manufacturer. Usage of other types of batteries, chargers and accessories may result in violence of the certification or warranty terms or even lead to danger, Keep the equipment dry, Don't keep the equipment in under cooled places; otherwise, when the temperature rises to normal, moisture may be generated within the equipment, resulting in damage of the circuit board. .Only use matched or approved antenna .