Title :	lu fa u	mation	Docum	nent —			NO.	: SCE-0205			
	Intor						Date	: 14. Jl	JN. 200		
2.3	Operation	ng summ	on/								
2.3	Operatii	ig summ	ai y								
		SMITTER									
		TRANSMITTER sends appropriate CODE by RF frequency.									
		 RECEIVER gets the code and decodes it. When Rx proves it to be the right code, Rx drive the actuator 									
		rry out the			loud, TXX c		lotaatoi				
2.3		ÚNLOCK									
		If LOCK or UNLOCK button is pushed for less than 1 sec, then TRANSMITTER sends the LOCK or UNLOCK DATA.									
	TRANSI	/IITTER se	ends the	LOCK or	UNLOCK	DATA.					
2.3	.2 PANIC										
	If PANIC	button is	pushed,	then trans	smitter se	nds the P	ANIC dat	a.			
2.4	Caution										
	Replace	 Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type recommended by the man Dispose of used batteries according to the manufacturer's instructions. 									
		_									

Page 5 of 12	T	T	
Page 5 of 12			
Page 5 of 12			
Page 5 of 12			
r. Page 5 of 12	2		
r. Page 5 of 12			
r. Page 5 of 12			
r. Page 5 of 12			
r. Page 5 of 12			
r			
r			
r. Page 5 of 12			
r			
r			
r			
r			
r			
r			
r. Page 5 of 12			
r			
r. Page 5 of 12			
r			
r			
r. Page 5 of 12			
r. Page 5 of 12			
r. Page 5 of 12			
r. Page 5 of 12			
r. Page 5 of 12			
r			
r			
r			
r			
Page 5 of 12			
Page 5 of 12			
Page 5 of 12			
Page 5 of 12			
Page 5 of 12	_		
Page 5 of 12			
Page 5 of 12			
Page 5 of 12			
Page 5 of 12			
Page 5 of 12			
Page 5 of 12			
Page 5 of 12			
Page 5 of 12			
Page 5 of 12			
Page 5 of 12			
Page 5 of 12			
Page 5 of 12			
Page 5 of 12			
Page 5 of 12			
Page 5 of 12			
Page 5 of 12			
Page 5 of 12			
Page 5 of 12			
Page 5 of 12			
Page 5 of 12			
Page 5 of 12			
Page 5 of 12			
Page 5 of 12			
Page 5 of 12			
Page 5 of 12			
Page 5 of 12			
Page 5 of 12			
raye 5 01 12			
	ח	age 5 of	1 つ